



NEW CITY

Owner's Manual

As you read this manual, you will find Information that is preceded by a symbol **NOTICE**. This information is intended to help you avoid damage to your vehicle, other property, or the environment.

Symbols    on labels attached to your vehicle are to remind you to read this owner's manual for proper and safe operation of your vehicle.

  is colour-coded to indicate "danger" (red), "warning" (orange), or "caution" (amber).

 **Safety Labels** P. 100

A Few Words About Safety

Your safety, and the safety of others, is very important. And operating this vehicle safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on labels and in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all the hazards associated with operating or maintaining your vehicle. You must use your own good judgement.

You will find this important safety information in a variety of forms, including:

- **Safety Labels** - on the vehicle.
- **Safety Messages** - preceded by a safety alert symbol  and one of three signal words: **DANGER**, **WARNING**, or **CAUTION**. These signal words mean:

 **DANGER**

You **WILL** be KILLED or SERIOUSLY HURT if you don't follow instructions.

 **WARNING**

You **CAN** be KILLED or SERIOUSLY HURT if you don't follow instructions.

  **WARNING**

You **CAN** be KILLED or SERIOUSLY HURT if you don't follow instructions.

 **CAUTION**

You **CAN** be HURT if you don't follow instructions.

- **Safety Headings** - such as Important Safety Precautions.
- **Safety Section** - such as Safe Driving.
- **Instructions** - how to use this vehicle correctly and safely.

This entire book is filled with important safety information - please read it carefully.

Event Data Recorders

Your vehicle is equipped with several devices commonly referred to as Event Data Recorders. They record various types of real time vehicle data such as SRS airbag deployment and SRS system components failure.

This data belongs to the vehicle owner and may not be accessed by anyone else except as legally required or with the permission of the vehicle owner.

However this data may be accessed by Honda, its authorised dealers and authorised repairers, employees, representatives and contractors only for the purpose of the technical diagnosis, research and development of the vehicle.

Service Diagnostic Recorders

Your vehicle is equipped with service-related devices that record information about powertrain performance and driving conditions. The data can be used to help technicians diagnose, repair and maintain the vehicle. This data may not be accessed by anyone else except as legally required or with the permission of the vehicle owner.

However this data may be accessed by Honda, its authorised dealers and authorised repairers, employees, representatives and contractors only for the purpose of the technical diagnosis, research and development of the vehicle.

This owner's manual should be considered a permanent part of the vehicle and should remain with the vehicle when it is sold.

This owner's manual covers all models of your vehicle. You may find descriptions of equipment and features that are not on your particular model.

The images throughout this owner's manual (including the front cover) that depict features, equipment, and Meter screens are only examples and may not be representative of your particular model.

The information and specifications included in this publication were in effect at the time of approval for printing. Honda Motor Co., Ltd. reserves the right, however, to discontinue or change specifications or design at any time without notice and without incurring any obligation.

Although this manual is applicable to both right-hand and left-hand drive models, the illustrations contained in this manual mainly refer to the right-hand drive models.

➤ Safe Driving P. 35

For Safe Driving P. 36

Seat Belts P. 41

Airbags P. 51

➤ Instrument Panel P. 101

Indicators P. 102

Gauges and Displays P. 128

➤ Controls P. 179

Clock P. 180

Windows P. 202

Seats P. 233

Locking and Unlocking the Doors P. 183

Sunroof* P. 207

Interior Convenience Items P. 242

➤ Features P. 265

➤ Driving P. 267

Before Driving P. 268

Refueling P. 387

Towing a Trailer P. 271

When Driving P. 272

Fuel Economy and CO₂ Emissions P. 390

➤ Maintenance P. 393

Before Performing Maintenance P. 394

Maintenance Under the Bonnet P. 411

Battery P. 446

Cleaning P. 454

Oil Monitor System* P. 397

Replacing Light Bulbs P. 428

Remote Transmitter Care P. 450

Accessories and Modifications P. 459

➤ Handling the Unexpected P. 461

Tools P. 462

Shift Lever Does Not Move P. 492

Emergency Call (eCall)* P. 518

If a Tyre Goes Flat P. 463

Overheating P. 493

➤ Information P. 523

Specifications P. 524

Identification Numbers P. 529

Contents

Child Safety P. 62

Exhaust Gas Hazard P. 99

Safety Labels P. 100

Opening and Closing the Boot P. 195

Operating the Switches Around the Steering Wheel P. 209

Heating* and Cooling System* P. 254

Security System P. 198

Mirrors P. 230

Climate Control System* P. 259

Honda SENSING* P. 308

Turbo Engine Vehicle* P. 391

Braking P. 376

Parking Your Vehicle P. 381

Maintenance Reminder* P. 402

Checking and Maintaining Wiper Blades P. 437

Heating System* and Cooling System*/Climate Control System* Maintenance P. 452

Maintenance Schedule P. 404

Checking and Maintaining Tyres P. 439

Handling of the Jack P. 482

Indicator Coming On/Blinking P. 497

Engine Does Not Start P. 483

Fuses P. 503

If the Battery Is Dead P. 488

Emergency Towing P. 517

Devices that Emit Radio Waves* P. 531

Open Source Licence P. 537

Quick Reference Guide P. 4

Safe Driving P. 35

Instrument Panel P. 101

Controls P. 179

Features P. 265

Driving P. 267

Maintenance P. 393


Handling the Unexpected P. 461

Information P. 523


Index P. 538

Visual Index

Right-hand Drive Type




Left-hand Drive Type



* Not available on all models

Visual Index

All models



Left-hand drive models

Headlights/ **Turn Signals** ➡ P. 212, 213

Rear Fog Light* ➡ P. 217

LaneWatch Button*, *1

Right-hand drive models

Wipers/ **Washers** ➡ P. 223

CAMERA Button*, *1

Brightness Control ➡ P. 226

TRIP/CLOCK Button* ➡ P. 131, 180

CRUISE Button* ➡ P. 294

Adaptive Cruise Control (ACC) Buttons* ➡ P. 337

Right-hand drive models

Headlights/ **Turn Signals** ➡ P. 212, 213

LaneWatch Button*, *1

Left-hand drive models

Wipers/ **Washers** ➡ P. 223

Cruise Control Buttons* ➡ P. 295

Paddle Shifter* (Shift Up) ➡ P. 285

Lane Keeping Assist System (LKAS) Button*

➡ P. 355

Interval Button* ➡ P. 350


Horn (Press an area around

Left Selector Wheel* ➡ P. 133, 157

Paddle Shifter* (Shift Down) ➡ P. 285

*1: Details are listed in a separate manual.


Right-hand Drive Type




* Not available on all models

Visual Index

Left-hand Drive Type




All models









* Not available on all models

Visual Index



Auto Idle Stop Function*

To improve fuel economy, the engine stops and then restarts as detailed below. When Auto Idle Stop is on, the Auto Idle Stop indicator (green) comes on. ➔ P. 290

At	Continuously variable transmission	Engine status
Deceleration 	 Stop the vehicle and depress the brake pedal.	 On
Stop 	 Keep the brake pedal depressed.	 Off
Start-up	 Release the brake pedal.	 Restarting

* Not available on all models

Eco Assist System*

Ambient Meter

- The colour of the ambient meter changes to green to indicate that the vehicle is being driven in a fuel-efficient manner.




ECON Mode Indicator ➔ P.116

Comes on when the ECON button is pressed.



ECON Button ➔ P.289

Helps to maximise fuel economy.



*1: Models with information display

*2: Models with A-type meter

*3: Models with B-type meter

Safe Driving ➡ P.35

Before Driving Checklist ➡ P.39

- Before driving, check that the front seats, head restraints, steering wheel, and mirrors have been properly adjusted.

Seat Belts ➡ P.41

- Fasten your seat belt and sit upright well back in the seat.
- Check that your passengers are wearing their seat belts correctly.



Fasten your lap belt as low as possible.

Exhaust Gas Hazard ➡ P.99


- Your vehicle emits dangerous exhaust gases that contain carbon monoxide. Do not run the engine in confined spaces where carbon monoxide gas can accumulate.

Child Safety ➡ P.62

- All children 12 and younger should be seated in the rear seat.
- Small children should be properly restrained in a front-facing child restraint system.
- Infants must be properly restrained in a rear-facing child restraint system on a rear seat.

Airbags ➡ P.51

- Your vehicle is fitted with airbags to help to protect you and your passengers during a moderate-to-severe collision.




Instrument Panel P.101


Indicators  P.102 / Gauges  P.128 / Information Display*  P.131 /

Driver Information Interface*  P.133, 157


Models with information display



Models with driver information interface (A-type meter)



* Not available on all models



Controls P.179


Clock P.180

Models with information display


You can adjust the time in the information display using the **TRIP/CLOCK**, **+** or **-** button.



Models with driver information interface (A-type meter)




Models with driver information interface (B-type meter)




ENGINE START/STOP Button P.209

Press the button to change the vehicle's power mode.




Turn Signals P.212

Turn Signal Control Lever



Lights P. 213

Light Control Switches



Wipers and Washers

 P. 223

Wiper/Washer Control Lever

MIST


OFF

AUTO*¹: Wiper speed varies automatically

INT*²: Low speed with intermittent

LO: Low speed wipe

HI: High speed wipe



Adjustment Ring*

: Low Sensitivity*¹

⬇: Lower speed, fewer sweeps*²

: High Sensitivity*¹

⬆: Higher speed, more sweeps*²

*1: Models with automatic intermittent wipers

*2: Models with manual intermittent operation


Models with automatic intermittent wipers

AUTO should always be turned OFF before the following situations in order to prevent severe damage to the wiper system:

- Cleaning the windscreen
- Driving through a car wash
- No rain present

Steering Wheel P. 229

- To adjust, push the adjustment lever down, adjust to the desired position, then lock the lever back in place.




Unlocking the Front Door from the Inside ➡ P.192

Except Latin American models


- Pull the driver's door inner handle to unlock and open it at the same time.

Latin American models

- Pull either front door inner handle to unlock and open it at the same time.



Boot ➡ P.195




- Pull the boot opener on the outside of the driver's seat to unlock and open the boot.
- Press the boot release button* on the boot lid to unlock and open the boot.
- Press the boot release button on the remote to unlock and open the boot.

Power Door Mirrors

➡ P.231


- With the power mode in ON, move the selector switch to L or R.
- Push the appropriate edge of the adjustment switch to adjust the mirror.
- Press the folding button* to fold in and out the door mirrors.



* Not available on all models

Power Windows P. 202

- With the power mode in ON, open and close the power windows.
- If the power window lock button is in the off position, each passenger's window can be opened and closed with its own switch.
- If the power window lock button is in the ON position (indicator on), each passenger's window switch is disabled.



Heating* and Cooling System*


- Press the  button to turn the system on or off.
- Rotate the fan control dial to adjust the fan speed.
- Turn the mode control dial to  /  /  /  to select the vents air flows from.
- Rotate the temperature control dial to adjust the temperature.
- Press the  button to defrost the windscreen.

 Air flows from dashboard vents and back of the console compartment*.

 Air flows from floor vents.

 Air flows from floor and dashboard vents, and back of the console compartment*.

 Air flows from floor and windscreen demister vents.



*1: Models with **MAX COOL** button

*2: Models with **MAX A/C** button

*3: Right-hand drive type

*4: Right-hand drive models shown. For the left-hand drive models, these buttons are located at the symmetrically opposite to the right-hand drive model.

* Not available on all models

Climate Control System* ➔ P. 259


- Press the **AUTO** button to activate the climate control system.
- Press the  button to turn the system on and off.
- Press the  button to defrost the windscreen.

 Air flows from dashboard vents and back of the console compartment*.

 Air flows from floor and dashboard vents, and back of the console compartment*.

 Air flows from floor vents.

 Air flows from floor and windscreen demister vents.



*1: Models with **MAX COOL** button

*2: Right-hand drive type

*3: Right-hand drive models shown. For the left-hand drive models, these buttons are located at the symmetrically opposite to the right-hand drive model.


Driving P. 267

Manual Transmission* P. 286

Continuously Variable Transmission* P. 280, 281


- Shift to **P** and depress the brake pedal when starting the engine.

Shifting



-  Depress the brake pedal and press the shift lever release button to shift.
-  Shift without pressing the shift lever release button.
-  Press the shift lever release button and shift.

Shift Lever



Release Button

P

Park

Used when parking or starting the engine.

R

Reverse

Used when reversing.

N

Neutral

Transmission is not locked.

D

Drive

Used:

- For normal driving

Models with paddle shifters

- When temporarily driving in the 7-speed manual shift mode

S

Drive (S)

Used:

- For better acceleration
- To increase engine braking
- When going up or down hills

Models with paddle shifters

- When driving in the 7-speed manual shift mode

7-Speed Manual Shift Mode* ➡ P.284

- Allows you to manually shift the transmission up or down without removing your hands from the steering wheel.


When the shift position is in **[S]**

- Pulling a paddle shifter changes the mode from continuously variable transmission to 7-speed manual shift mode.
- The **M** indicator and the selected speed number are displayed in the shift indicator.


When the shift position is in **[D]**

- Pulling a paddle shifter temporarily changes the mode from continuously variable transmission to 7-speed manual shift mode. The selected speed number is displayed in the shift indicator.


Models with A-type meter



Models with B-type meter



Models with information display



Shift Down **[−]**
Paddle Shifter



Shift Up **[+]**
Paddle Shifter



CMBS* On and Off P. 315

- When a possible frontal collision is likely unavoidable, the Collision Mitigation Braking System (CMBS) can reduce the vehicle speed and the severity of the collision.
- The CMBS is turned on every time you start the engine.
- To turn the CMBS on or off, use the safety support of the driver information interface.

VSA On and Off P. 299

- The Vehicle Stability Assist (VSA) system helps to stabilise the vehicle during cornering and helps to maintain traction while accelerating on loose or slippery road surfaces.
- VSA comes on automatically every time you start the engine.
- To partially disable or fully restore VSA function, press and hold the  (VSA OFF) button until you hear a beep.

Cruise Control* P. 294

- Cruise control allows you to maintain a set speed without keeping your foot on the accelerator pedal.
- To use cruise control, press the CRUISE button, then press the **SET/-** once you have achieved the desired speed (above 40 km/h or 25 mph).

Deflation Warning System* P. 301

- Detects a change in tyre conditions and overall dimensions due to decrease in tyre pressures.
- The deflation warning system is turned on automatically every time you start the engine.
- An initialisation/Calibration procedure must be performed when certain conditions arise.

Refueling P. 387

Fuel recommendation:

Indian, Bhutanese and Nepalese models

Unleaded petrol/gasohol up to E20 (80% petrol and 20% ethanol), research octane number 91 or higher

Thai models


Unleaded premium petrol/gasohol up to E20 (80% petrol and 20% ethanol), research octane number 95 or higher

Except Indian, Bhutanese, Nepalese and Thai models

Unleaded petrol, research octane number 91 or higher

Fuel tank capacity: 40 L

- 1** Pull on the fuel fill door release handle under the dashboard at the driver's side.
- 2** Turn the fuel fill cap slowly to remove the cap.
- 3** Place the cap in the holder on the fuel fill door.
- 4** After refueling, screw the cap back on until it clicks at least once.



Honda SENSING*

➡ P. 308

Assists with functions such as acceleration, braking, and steering in order to reduce the burden on the driver, as well as help to avoid or reduce the severity of collisions.

Honda SENSING has the following functions:

Collision Mitigation Braking System (CMBS)

➡ P. 311

The system can assist you when it determines there is a possibility of your vehicle colliding with a vehicle (including motorcycles) ahead from behind, an oncoming vehicle in front, a vehicle approaching from the side, a pedestrian, or someone riding a bicycle (moving bicycle). The CMBS is designed to alert you when the potential for a collision is determined, as well as assist in reducing speed, avoiding collisions, and reducing collision severity.

Road Departure Mitigation System

➡ P. 325

Except Mexican models

Alerts and helps to assist you when the system detects a possibility of your vehicle unintentionally crossing over detected lane markings and/or leaving the roadway altogether.

Mexican models

Alerts and helps to assist you when the system detects a possibility of your vehicle crossing over detected lane markings, or approaching the outer edge of the pavement (into grass or gravel border) or a detected oncoming vehicle.

Adaptive Cruise Control (ACC)

➡ P. 337

Helps to maintain a constant vehicle speed and a set following-interval behind a vehicle detected ahead of yours, without you having to keep your foot on the brake or the accelerator.

Lane Keeping Assist System (LKAS)

➡ P. 355

Except Mexican models

Provides steering input to help to keep the vehicle in the middle of a detected lane and provides tactile, audible and visual alerts if the vehicle is detected drifting out of its lane.

Mexican models

Provides steering input to help to keep the vehicle in the middle of a detected lane and provides tactile and visual alerts if the vehicle is detected drifting out of its lane.

Lead Car Departure Notification System*

➡ P. 368

Informs you with visual and audible alerts when your vehicle is stopped even though the vehicle ahead of you has started moving.

Auto High-Beam P. 219

The front wide view camera detects the light sources ahead of the vehicle such as the lights of a preceding or oncoming vehicle, or street lights. When you are driving at night, the system automatically switches the headlights between low beam and high beam depending on the situation.

Parking Sensor System *

 P. 383

The rear corner* and centre sensors monitor obstacles behind your vehicle, and the beeper and driver information interface lets you know the approximate distance between your vehicle and the obstacle.

Maintenance ➡ P. 393

Under the Bonnet ➡ P. 411

- Check engine oil, engine coolant, and windscreen washer fluid. Add when necessary.
- Check brake/clutch* fluid.
- Check the battery condition monthly.

- 1 Pull the bonnet release handle under the driver's side lower outside corner of the dashboard.




- 2 Locate the bonnet latch lever, pull it up, and then raise the bonnet. Once you have raised the bonnet slightly, you can release the lever.



- 3 When finished, close the bonnet and make sure it is firmly locked in place.

Wiper Blades ➡ P. 437

- Replace blades if they leave streaks across the windscreen or become noisy.



Tyres ➡ P. 439

- Inspect tyres and wheels regularly.
- Check tyre pressures regularly.
- Install winter tyres for winter driving.

Lights ➡ P. 428

- Inspect all lights regularly.

Handling the Unexpected ➡ P. 461

Flat Tyre ➡ P. 463

Models with spare tyre

- Park in a safe place and replace the flat tyre with the spare tyre in the boot.

Models with tyre repair kit


- Park in a safe location and repair the flat tyre using the tyre repair kit in the boot.



Indicators Come On

➡ P. 497

- Identify the indicator and consult the owner's manual.




Engine Won't Start ➡ P. 483

- If the battery is dead, jump start using a booster battery.



Blown Fuse ➡ P. 503

- Check for a blown fuse if an electrical device does not operate.



Overheating ➡ P. 493

- Park in a safe location. If you do not see steam under the bonnet, open the bonnet, and let the engine cool down.



Emergency Towing ➡ P. 517


- Call a professional towing service if you need to tow your vehicle.



What to Do If

Q The power mode does not change from **VEHICLE OFF (LOCK)** to **ACCESSORY**. Why?

- A**
- The steering wheel may be locked.
 - Move the steering wheel left and right after pressing the **ENGINE START/STOP** button.



Q Continuously variable transmission models
The power mode does not change from **ACCESSORY** to **VEHICLE OFF (LOCK)**. Why?

- A**
- The shift lever should be moved to **P**.




Q Why does the brake pedal pulsate slightly when applying the brakes?

- A**
- This can occur when the ABS activates and does not indicate a problem. Apply firm, steady pressure on the brake pedal. Never pump the brake pedal.
- Anti-lock Brake System (ABS) ➞ **P. 378**

Q The rear door cannot be opened from inside the vehicle. Why?

A Check if the childproof lock is in the lock position. If so, open the rear door with the outside door handle. To cancel this function, slide the lever up to the unlock position.



Q Why do the doors lock after I unlocked the doors?

A If you do not open the doors within 30 seconds, the doors are relocked automatically for security.

Q Why does the beeper sound when I open the driver's door?

A The beeper sounds when:

- The power mode is in ACCESSORY.
- The exterior lights are left on.

Models with Auto Idle Stop

- The Auto Idle Stop is in operation.

Q **Models with walk away auto lock**
Why does a beeper sound when I walk away from the vehicle after I close the door?

A The beeper sounds if you move outside the walk away auto lock operating range before the door completely closes.

🔒 Locking the doors and boot (Walk away auto lock*) ➡ P.187

Q Why does the beeper sound when I start driving?

A The beeper sounds when:

- The driver, front passenger, and/or rear passenger* are not wearing their seat belts.
- The parking brake lever is not fully released.

Q **Models with deflation warning system**
I'm seeing an amber indicator of a tyre with an exclamation point. What is that?

A The Deflation Warning System needs attention. If you recently inflated or changed a tyre, you have to recalibrate the system.

➤ Deflation Warning System* ➡ P.301

Q Why do I hear a screeching sound when I apply the brake pedal?

A The brake pads may need to be replaced. Have your vehicle inspected by a dealer.



Thai models

Unleaded petrol with a Research Octane Number (RON) of 95 or higher is recommended. Is it possible to use unleaded petrol with a Research Octane Number (RON) of 91 or lower on this vehicle?



Use of lower octane petrol can cause occasional metallic knocking noise in the engine and will result in decreased engine performance.

Use of petrol with a research octane number less than 91 can lead to engine damage.

Safe Driving

You can find many safety recommendations throughout this chapter, and throughout this manual.

For Safe Driving

Important Safety Precautions.....	36
Your Vehicle's Safety Features.....	38
Safety Checklist	39

Seat Belts

About Your Seat Belts.....	41
Fastening a Seat Belt.....	46
Seat Belt Inspection.....	49
Anchorage Points.....	50

Airbags

Airbag System Components.....	51
Types of Airbags	53

Front Airbags (SRS)	53
Side Airbags*	56
Side Curtain Airbags*	58
Airbag System Indicators.....	59
Airbag Care	61

Child Safety

Protecting Child Passengers	62
Safety of Infants and Small Children...	66
Safety of Larger Children	96

Exhaust Gas Hazard

Carbon Monoxide Gas	99
---------------------------	----

Safety Labels

Label Locations	100
-----------------------	-----

* Not available on all models

The following pages explain your vehicle's safety features and how to use them properly. The safety precautions below are ones that we consider to be among the most important.

Important Safety Precautions

■ Always wear your seat belt

A seat belt is your best protection in all types of collisions. Airbags are designed to supplement seat belts, not replace them. So even though your vehicle is equipped with airbags, make sure you and your passengers always wear your seat belts, and wear them properly.

■ Restrain all children

Children aged 12 and under should ride properly restrained in a back seat, not the front seat. Infants and small children should be restrained in a child restraint system. Larger children should use a booster seat and a lap/shoulder seat belt until they can use the belt properly without a booster seat.

■ Be aware of airbag hazards

While airbags can save lives, they can cause serious or fatal injuries to occupants who sit too close to them, or are not properly restrained. Infants, young children, and short adults are at the greatest risk. Be sure to follow all instructions and warnings in this manual.

■ Don't drink and drive

Alcohol and driving don't mix. Even one drink can reduce your ability to respond to changing conditions, and your reaction time gets worse with every additional drink. So don't drink and drive, and don't let your friends drink and drive, either.

» Important Safety Precautions

Some countries prohibit the use of mobile phones other than hands-free devices by the driver while driving.

■ Pay appropriate attention to the task of driving safely

Engaging in mobile phone conversation or other activities that keep you from paying close attention to the road, other vehicles, and pedestrians could lead to a crash. Remember, situations can change quickly, and only you can decide when it is safe to divert some attention away from driving.

■ Control your speed

Excessive speed is a major factor in crash injuries and deaths. Generally, the higher the speed, the greater the risk, but serious injuries can also occur at lower speeds. Never drive faster than is safe for current conditions, regardless of the maximum speed posted.


■ Keep your vehicle in safe condition

Having a tyre blowout or a mechanical failure can be extremely hazardous. To reduce the possibility of such problems, check your tyre pressures and condition frequently, and perform all regularly scheduled maintenance.

■ Do not leave children unattended in the vehicle

Children, pets, and people needing assistance left unattended in the vehicle may be injured if they activate one or more of the vehicle controls. They may also cause the vehicle to move, resulting in a crash in which they and/or another person(s) can be injured or killed. Also, depending on the ambient temperature, the temperature of the interior may reach extreme levels, which can result in harm or death. Even if the climate control system is on, never leave them in the vehicle unattended as the climate control system can shut off at any time.

Your Vehicle's Safety Features



The following checklist will help you take an active role in protecting yourself and your passengers.

►► Your Vehicle's Safety Features

Your vehicle is equipped with many features that work together to help to protect you and your passengers during a crash.

Some features do not require any action on your part. These include a strong steel framework that forms a safety cage around the passenger compartment, front and rear crush zones, a collapsible steering column, and tensioners that tighten the front seat belts in a sufficient crash.

However, you and your passengers cannot take full advantage of these features unless you remain seated in the correct position and always wear your seat belts. In fact, some safety features can contribute to injuries if they are not used properly.

Safety Checklist

For the safety of you and your passengers, make a habit of checking these items each time before you drive.

- Adjust your seat to a position suitable for driving. Be sure the front seats are adjusted as far to the rear as possible while allowing the driver to control the vehicle. Sitting too close to a front airbag can result in serious or fatal injury in a crash.

🔧 **Seats** P. 233

- Adjust head restraints to the proper position. Head restraints are most effective when the centre of the head restraint aligns with the centre of your head. Taller persons should adjust their head restraint to the highest position.

🔧 **Adjusting the Front Head Restraints Positions** P. 239

- Always wear your seat belt, and make sure you wear it properly. Confirm that any passengers are properly belted as well.

🔧 **Fastening a Seat Belt** P. 46

- Protect children by using seat belts or child restraint systems according to a child's age, height, and weight.

🔧 **Child Safety** P. 62

» Safety Checklist

Models with information display

If the door/boot open indicator is on, a door and/or boot is not completely closed. Close all doors and the boot tightly until the indicator goes off.

🔧 **Door and Boot Open Indicator*** P. 110



* Not available on all models



►► Safety Checklist

Models with driver information interface

If the door and/or boot open message appears on the driver information interface, a door and/or the boot is not completely closed. Close all doors and the boot tightly until the message disappears.

➤ **Driver Information Interface (A-type meter)*** P. 133

➤ **Driver Information Interface (B-type meter)*** P. 157

Models with A-type meter**Models with B-type meter**

*1: Mexican models

*2: Models for other countries

* Not available on all models

About Your Seat Belts

Seat belts are the single most effective safety device because they keep you connected to the vehicle so that you can take advantage of many built-in safety features. They also help to keep you from being thrown against the inside of the vehicle, against any passengers, or out of the vehicle. When worn properly, seat belts also keep your body properly positioned in a crash so that you can take full advantage of the additional protection provided by the airbags.

In addition, seat belts help to protect you in almost every type of crash, including:

- frontal impacts
- side impacts
- rear impacts
- rollovers

⌘ About Your Seat Belts

WARNING

Not wearing a seat belt properly increases the chance of serious injury or death in a crash, even though your vehicle has airbags.

Be sure you and your passengers always wear seat belts and wear them properly.

WARNING: Seat belts are designed to bear upon the bony structure of the body, and should be worn low across the front of the pelvis or the pelvis, chest and shoulders, as applicable; wearing the lap section of the belt across the abdominal area must be avoided.

WARNING: Seat belts should be adjusted as firmly as possible, consistent with comfort, to provide the protection for which they have been designed. A slack belt will greatly reduce the protection afforded to the wearer.

WARNING: Belts should not be worn with straps twisted.

WARNING: Each belt assembly must only be used by one occupant; it is dangerous to put a belt around a child being carried on the occupant's lap.

■ Lap/shoulder seat belts

All five seating positions are equipped with lap/shoulder seat belts with emergency locking retractors. In normal driving, the retractor lets you move freely while keeping some tension on the belt. During a collision or sudden stop, the retractor locks to restrain your body.

The seat belt must be properly secured when using a front-facing child restraint system.

📖 **Installing a Child Restraint System with a Lap/Shoulder Seat Belt** P. 93

■ Proper use of seat belts

Follow these guidelines for proper use:

- All occupants should sit upright, well back in the seat, and remain in that position for the duration of the trip. Slouching and leaning reduce the effectiveness of the belt and can increase the chance of serious injury in a crash.
- Never place the shoulder part of a lap/shoulder seat belt under your arm or behind your back. This could cause very serious injuries in a crash.
- Two people should never use the same seat belt. If they do, they could be very seriously injured in a crash.
- Do not put any accessories on the seat belts. Devices intended to improve comfort or reposition the shoulder part of a seat belt can reduce the protective capability and increase the chance of serious injury in a crash.

►► About Your Seat Belts

If you extend the seat belt too quickly, it will lock in place. If this happens, slightly retract the seat belt, then extend it slowly.

Seat belts cannot completely protect you in every crash. But in most cases, seat belts can reduce your risk of serious injury.

Most countries require you to wear seat belts. Take time to familiarise with the legal requirements of the countries in which you will drive.

Seat Belt Reminder

Models with information display



Models with driver information interface (A-type meter)



Models with driver information interface (B-type meter)



Front seats

The seat belt system includes an indicator on the instrument panel to remind the driver or a front passenger or both to fasten their seat belts.

If you set the power mode to ON before the driver's seat belt is fastened, the indicator will come on. If the driver does not fasten the belt, the indicator will remain on.

When the vehicle is moving, the beeper will sound and the indicator will blink for a while until the seat belt is fastened.

Then, the beeper will stop and the indicator will stay on.

Seat Belt Reminder

The indicator will also come on if a front passenger does not fasten their seat belt within six seconds after the power mode is set to ON.

When no one is sitting in the front passenger's seat, the indicator will not come on and the beeper will not sound.

If the indicator comes on or the beeper sounds with no one sitting in the front passenger's seat. Check if:


- There is nothing heavy placed on the front passenger seat.
- The driver's seat belt is fastened.

If the indicator does not light when the passenger is seated and is not fastened, something may be interfering with the occupant detection sensor.

Check if:

- A cushion is placed on the seat.
- The front passenger is not sitting properly.

If none of these conditions exist, have your vehicle checked by a dealer.



■ Rear seats*

Your vehicle monitors rear seat belt use. Rear seat belt reminder indicator notifies you about the status of the rear seat belts use.

The indicator comes on when:

- Any of the rear passenger seat belts are unfastened when the power mode is set to ON.
- Any of the rear passengers unfastened their seat belt.

Your vehicle monitors rear seat belt use. The driver information interface notifies you about the status of the rear seat belts use.

The display appears when:


- Any of the rear passenger seat belts are unfastened when the power mode is set to ON.
- A rear door is opened and then closed.
- Any of the rear passengers fasten or unfasten their seat belt.

The seat belt reminder indicator blinks and the beeper sounds if any rear passenger seat belts have been unfastened while driving.

■ Automatic Seat Belt Tensioners

The front seats are equipped with automatic seat belt tensioners to enhance safety.

The tensioners automatically tighten the front seat belts during a moderate-to-severe frontal collision, sometimes even if the collision is not severe enough to inflate the front airbags.



⌘ Automatic Seat Belt Tensioners

The seat belt tensioners can only operate once. If a tensioner is activated, the SRS indicator will come on. Have a dealer replace the tensioner and thoroughly inspect the seat belt system as it may not offer protection in a subsequent crash.



Models with side curtain airbags

During a moderate-to-severe side impact, the tensioners on both sides of the vehicle also activate.

Fastening a Seat Belt

After adjusting a front seat to the proper position, and while sitting upright and well back in the seat:

► **Seats** P. 233



1. Pull the seat belt out slowly.

2. Insert the latch plate into the buckle, then tug on the belt to make sure the buckle is secure.

► Make sure that the belt is not twisted or caught on anything.

►► Fastening a Seat Belt

No one should sit in a seat with an inoperative seat belt or one that does not appear to be working correctly. Using a seat belt that is not working properly may not protect the occupant in a crash. Have a dealer check the belt as soon as possible.

Never insert any foreign objects into the buckle or retractor mechanism.

If the seat belt appears to be locked in a fully retracted position, firmly pull out on the shoulder belt once, then push it back in.

Then, smoothly pull it out of the retractor and fasten. If you are unable to release the seat belt from a fully retracted position, do not allow anyone to sit in the seat, and take your vehicle to a dealer for repair.

► **About Your Seat Belts** P. 41

► **Seat Belt Inspection** P. 49



3. Position the lap part of the belt as low as possible across your hips, then pull up on the shoulder part of the belt so the lap part fits snugly. This lets your strong pelvic bones take the force of a crash and reduces the chance of internal injuries.
4. If necessary, pull up on the belt again to remove any slack, then check that the belt rests across the centre of your chest and over your shoulder. This spreads the forces of a crash over the strongest bones in your upper body.

► Fastening a Seat Belt

⚠ WARNING

Improperly positioning the seat belts can cause serious injury or death in a crash.

Make sure all seat belts are properly positioned before driving.

To release the belt, push the red **PRESS** button and then guide the belt by hand until it has retracted completely.
When exiting the vehicle, be sure the belt is properly stowed so that it will not get caught in the closing door.

■ Advice for Pregnant Women

If you are pregnant, the best way to protect yourself and your unborn child when driving or riding in a vehicle is to always wear a seat belt. When positioning the seat belt, wear the shoulder belt section across the chest, avoiding the abdomen, and keep the lap belt portion as low as possible across the hips. (See illustration.)



►► Advice for Pregnant Women

Each time you have a checkup, ask your doctor if it is okay for you to drive.

To reduce the risk of injuries to both you and your unborn child that can be caused by an inflating front airbag:

- When driving, sit upright and adjust the seat as far back as possible while allowing full control of the vehicle.
- When sitting in the front passenger's seat, adjust the seat as far back as possible.

Seat Belt Inspection

Regularly check the condition of your seat belts as follows:

- Pull each belt out fully, and look for frays, cuts, burns, and wear.
- Check that the latch plates and buckles work smoothly and the belts retract easily.
 - ▶ If a belt does not retract easily, cleaning the belt may correct the problem. Only use a mild soap and warm water. Do not use bleach or cleaning solvents. Make sure the belt is completely dry before allowing it to retract.

Any belt that is not in good condition or working properly will not provide proper protection and should be replaced as soon as possible.

A belt that has been worn during a crash may not provide the same level of protection in a subsequent crash. Have your seat belts inspected by a dealer after any collision.

Seat Belt Inspection

WARNING

Not checking or maintaining seat belts can result in serious injury or death if the seat belts do not work properly when needed.


Check your seat belts regularly and have any problem corrected as soon as possible.

WARNING: No modifications or additions should be made by the user which will either prevent the seat belt adjusting devices from operating to remove slack, or prevent the seat belt assembly from being adjusted to remove slack.


WARNING: It is essential to replace the entire assembly after it has been worn in a severe impact even if damage to the assembly is not obvious.

WARNING: Care should be taken to avoid contamination of the webbing with polishes, oils and chemicals, and particularly battery acid. Cleaning may safely be carried out using mild soap and water. The belt should be replaced if webbing becomes frayed, contaminated or damaged.

Anchorage Points



When replacing the seat belts, use the anchorage points shown in the images. The front seat has a lap/shoulder belt.



The rear seat has three lap/shoulder belts.

Airbag System Components

The front, side*, and side curtain* airbags are deployed according to the direction and severity of impact. The airbag system includes:

- Two SRS (Supplemental Restraint System) front airbags. The driver's airbag is stored in the centre of the steering wheel; the front passenger's airbag is stored in the dashboard. Both are marked **SRS**

AIRBAG.

Models with side airbags

- Two side airbags. One for the driver and one for the front passenger. The airbags are stored in the outer edges of the seat-backs. Both are marked **SIDE AIRBAG.**

Models with side curtain airbags

- Two side curtain airbags, one for each side of the vehicle. The airbags are stored in the ceiling, above the side windows. The front and rear pillars are marked **SIDE CURTAIN AIRBAG.**

- An electronic control unit that, when the power mode is in ON, continually monitors information about the various impact sensors, seat and buckle sensors, airbag activators, seat belt tensioners, and other vehicle information. During a crash event, the unit can record such information.
- Front seat belt tensioners.
- Impact sensors that can detect a moderate-to-severe front or side impact*.
- An indicator on the instrument panel that alerts you to a possible problem with your airbag system or seat belt tensioners.

* Not available on all models

■ Important Facts About Your Airbags

Airbags can pose serious hazards. To do their job, airbags must inflate with tremendous force. So, while airbags help to save lives, they can cause burns, bruises, and other minor injuries, sometimes even fatal ones if occupants are not wearing their seat belts properly and sitting correctly.

What you should do: Always wear your seat belt properly and sit upright and as far back from the steering wheel as possible while allowing full control of the vehicle. A front passenger should move their seat as far back from the dashboard as possible.

Remember, however, that no safety system can prevent all injuries or deaths that can occur in a severe crash, even when seat belts are properly worn and the airbags deploy.

Do not place hard or sharp objects between yourself and a front airbag.

Carrying hard or sharp objects on your lap, or driving with a pipe or other sharp object in your mouth, can result in injuries if your front airbag inflates.

Do not attach or place objects on the front airbag covers. Objects on the covers marked **SRS AIRBAG** could interfere with the proper operation of the airbags or be propelled inside the vehicle and hurt someone if the airbags inflate.

►► Important Facts About Your Airbags

Do not attempt to deactivate your airbags. Together, airbags and seat belts provide the best protection.

When driving, keep hands and arms out of the deployment path of the front airbag by holding each side of the steering wheel. Do not cross an arm over the airbag cover.

Types of Airbags

Your vehicle is equipped with three types of airbags:

- **Front airbags:** Airbags in front of the driver's and front passenger's seats.
- **Side airbags*:** Airbags in the driver's and front passenger's seat-backs.
- **Side curtain airbags*:** Airbags above the side windows.

Each is discussed in the following pages.

Front Airbags (SRS)

The front SRS airbags inflate in a moderate-to-severe frontal collision to help to protect the head and chest of the driver and/or front passenger.

SRS (Supplemental Restraint System) indicates that the airbags are designed to supplement seat belts, not replace them. Seat belts are the occupant's primary restraint system.

Housing Locations

The front airbags are housed in the centre of the steering wheel for the driver, and in the dashboard for the front passenger. Both airbags are marked **SRS AIRBAG**.

Types of Airbags

The airbags can inflate whenever the power mode is in ON.

After an airbag inflates in a crash, you may see a small amount of smoke. This is from the combustion process of the inflator material and is not harmful. People with respiratory problems may experience some temporary discomfort. If this occurs, get out of the vehicle as soon as it is safe to do so.


* Not available on all models

■ Operation

Front airbags are designed to inflate during moderate-to-severe frontal collisions. When the vehicle decelerates suddenly, the sensors send information to the control unit which signals one or both front airbags to inflate.

A frontal collision can be either head-on or angled between two vehicles, or when a vehicle crashes into a stationary object, such as a concrete wall.

■ How the Front Airbags Work



While your seat belt restrains your torso, the front airbag provides supplemental protection for your head and chest.

The front airbags deflate immediately so that they won't interfere with the driver's visibility or the ability to steer or operate other controls.

The total time for inflation and deflation is so fast that most occupants are not aware that the airbags deployed until they see them lying in front of them.

■ When front airbags should not deploy

Minor frontal crashes: Front airbags were designed to supplement seat belts and help to save lives, not to prevent minor scrapes, or even broken bones that might occur during a less than moderate-to-severe frontal crash.

Side impacts: Front airbags can provide protection when a sudden deceleration causes a driver or front passenger to move towards the front of the vehicle. Side airbags* and side curtain airbags* have been specifically designed to help to reduce the severity of injuries that can occur during a moderate-to-severe side impact which can cause the driver or passenger to move towards the side of the vehicle.

Rear impacts: Head restraints and seat belts are your best protection during a rear impact. Front airbags cannot provide any significant protection and are not designed to deploy in such collisions.

Rollovers: Seat belts and side curtain airbags* offer the best protection in a rollover. Because front airbags could provide little if any protection, they are not designed to deploy during a rollover.

■ When front airbags deploy with little or no visible damage

Because the airbag system senses sudden deceleration, a strong impact to the vehicle framework or suspension might cause one or more of the airbags to deploy. Examples include running into a curb, the edge of a hole, or other low fixed object that causes a sudden deceleration in the vehicle chassis. Since the impact is underneath the vehicle, damage may not be readily apparent.

■ When front airbags may not deploy, even though exterior damage appears severe


Since crushable body parts absorb crash energy during an impact, the amount of visible damage does not always indicate proper airbag operation. In fact, some collisions can result in severe damage but no airbag deployment because the airbags would not have been needed or would not have provided protection even if they had deployed.

* Not available on all models

Side Airbags*

The side airbags help to protect the torso and pelvis of the driver or a front passenger during a moderate-to-severe side impact.


Housing Locations



The side airbags are housed in the outside edge of the driver's and passenger's seat-backs.

Both are marked **SIDE AIRBAG**.

Operation



When the sensors detect a moderate-to-severe side impact, the control unit signals the side airbag on the impact side to immediately inflate.

Side Airbags*

Do not attach accessories on or near the side airbags. They can interfere with the proper operation of the airbags, or hurt someone if an airbag inflates.

Do not cover or replace the front seat-back covers without consulting a dealer. Improperly replacing or covering front seat-back covers can prevent your side airbags from properly deploying during a side impact.

Do not let the front passenger lean sideways with their head in the deployment path of the side airbag. An inflating side airbag can strike with strong force and seriously injure the passenger.

■ When a side airbag deploys with little or no visible damage

Because the airbag system senses sudden acceleration, a strong impact to the side of the vehicle's framework can cause a side airbag to deploy. In such cases, there may be little or no damage, but the side impact sensors detected a severe enough impact to deploy the airbag.


■ When a side airbag may not deploy, even though visible damage appears severe

It is possible for a side airbag not to deploy during an impact that results in apparently severe damage. This can occur when the point of impact was towards the far front or rear of the vehicle, or when the vehicle's crushable body parts absorbed most of the crash energy. In either case, the side airbag would not have been needed nor provided protection even if it had deployed.

Side Curtain Airbags*


The side curtain airbags help to protect the heads of the driver and passengers in outer seating positions during a moderate-to-severe side impact.

Housing Locations



The side curtain airbags are located in the ceiling above the side windows on both sides of the vehicle.

Operation



When side curtain airbags deploy in a frontal collision

One or both side curtain airbags may also inflate in a moderate-to-severe angled frontal collision.

Side Curtain Airbags*

The side curtain airbags are most effective when an occupant is wearing their seat belt properly and sitting upright, well back in their seat.

Do not attach any objects to the side windows or roof pillars as they can interfere with the proper operation of the side curtain airbags.

Models with coat hook

Do not put a coat hanger or hard objects on a coat hook. This could result in injuries if your side curtain airbag inflates.

Airbag System Indicators

Models with information display

If a problem occurs in the airbag system, the SRS indicator will come on.

Models with driver information interface

If a problem occurs in the airbag system, the SRS indicator will come on and a message appears on the driver information interface.

Supplemental Restraint System (SRS) Indicator

Models with information display



■ When the power mode is set to ON

The indicator comes on for a few seconds, then goes off. This tells you the system is working properly.



If the indicator comes on at any other time, or does not come on at all, have the system checked by a dealer as soon as possible. If you don't, your airbags and seat belt tensioners may not work properly when they are needed.

►► Supplemental Restraint System (SRS) Indicator

⚠ WARNING

Ignoring the SRS indicator can result in serious injury or death if the airbag systems or tensioners do not work properly.

Have your vehicle checked by a dealer as soon as possible if the SRS indicator alerts you to a possible problem.



*1: Mexican models

*2: Models for other countries

Airbag Care

You do not need to, and should not, perform any maintenance on or replace any airbag system components yourself. However, you should have your vehicle inspected by a dealer in the following situations:

■ When the airbags have deployed

If an airbag has inflated, the control unit and other related parts must be replaced. Similarly, once an automatic seat belt tensioner has been activated, it must be replaced.

■ When the vehicle has been in a moderate-to-severe collision

Even if the airbags did not inflate, have your dealer inspect the following: front seat belt tensioners, and each seat belt that was worn during the crash.

✕ Airbag Care

The removal of airbag components from the vehicle is prohibited.

In case of malfunction, or shutdown, or after the airbag inflation/seat belt tensioner operation, ask a qualified personnel for handling.


We recommend against the use of salvaged airbag system components, including the airbag, tensioners, sensors, and control unit.

Protecting Child Passengers

Each year, many children are injured or killed in vehicle crashes because they are either unrestrained or not properly restrained. In fact, vehicle crashes are the number one cause of death of children aged 12 and under.

To reduce the number of child deaths and injuries, infants and children should be properly restrained when they ride in a vehicle.

Children should sit properly restrained in a rear seat. This is because:



- An inflating front airbag can injure or kill a child sitting in the front seat.
- A child in the front seat is more likely to interfere with the driver's ability to safely control the vehicle.
- Statistics show that children of all sizes and ages are safer when they are properly restrained in a rear seat.

Protecting Child Passengers

⚠ WARNING

Children who are unrestrained or improperly restrained can be seriously injured or killed in a crash.

Any child too small for a seat belt should be properly restrained in an approved child restraint system. A larger child should be properly restrained with a seat belt, using a booster seat if necessary.

In many countries, the law requires all children aged 12 and under, and whose height are shorter than 150 cm be properly restrained in a rear seat.

In many countries, it is required to use an officially approved and suitable child restraint system for transporting a child on any passenger seat. Check your local legal requirement.

We recommend a child restraint system compliant with UN Regulation No. 44 or No. 129, or the regulations of the subject countries.

➡ **Selecting a Child Restraint System** P. 69

- Never hold a child on your lap because it is impossible to protect them in the event of a collision.
- Never put a seat belt over yourself and a child. During a crash, the belt would likely press deep into the child and cause serious or fatal injuries.
- Never let two children use the same seat belt. Both children could be very seriously injured in a crash.
- Any child who is too small to wear a seat belt must be properly restrained in an approved child restraint system that is properly secured to the vehicle using the seat belt or the child restraint anchorage system.

►► Protecting Child Passengers

Front Passenger's Sun Visor

⚠ WARNING



NEVER use a rearward facing child restraint on a seat protected by an **ACTIVE AIRBAG** in front of it, **DEATH** or **SERIOUS INJURY** to the **CHILD** can occur.

- Do not allow children to operate the doors, windows, or seat adjustments.
- Do not leave children in the vehicle unattended, especially in hot weather when the inside of the vehicle can get hot enough to kill them. They could also activate vehicle controls causing it to move unexpectedly.

►► Protecting Child Passengers

Front Passenger's Doorjamb*

WARNING



Extreme Hazard!

DO NOT use a rear-facing child restraint on a seat protected by an airbag in front of it!

WARNING: Use the power window lock button to prevent children from opening the windows. Using this feature will prevent children from playing with the windows, which could expose them to hazards or distract the driver.

 **Opening/Closing the Power Windows**
P. 202

WARNING: Always take the ignition key with you whenever you leave the vehicle alone or with other occupants.

► Protecting Child Passengers


To remind you of the passenger's front airbag hazard and child safety, your vehicle has the warning label on the passenger's side sun visor. Please read and follow the instructions on this label.

► **Safety Labels** P. 100

Safety of Infants and Small Children

■ Protecting Infants

An infant must be properly restrained in a rear-facing child restraint system until the infant reaches the child restraint system manufacturer's weight or height limit for the seat.



■ Positioning a rear-facing child restraint system

Child restraint system must be placed and secured in a rear seating position.

- We recommend that you install the child restraint system directly behind the front passenger's seat, move the seat as far forward as needed, and leave it unoccupied.
- Make sure that there is no contact between the child restraint system and the seat in front of it.

If there is, you may wish to get a smaller rear-facing child restraint system.

►► Protecting Infants

⚠ WARNING

Placing a rear-facing child restraint system in the front seat can result in serious injury or death if the passenger's front airbag inflates.

Always place a rear-facing child restraint system in the back seat, not the front.

When properly installed, a rear-facing child restraint system may prevent the driver or a front passenger from moving their seat all the way back, or from locking their seat-back in the desired position.

► Protecting Infants

Many experts recommend use of a rear-facing child restraint system for a child up to two years old if the child's height and weight are appropriate for a rear-facing child restraint system.

Rear-facing child restraint systems should never be installed in a front-facing position.


Always refer to the child restraint system manufacturer's instructions before installation.

If the passenger's front airbag inflates, it can hit the rear-facing child restraint system with great force, which can dislodge or strike the system, and seriously injure the child.

Continued

■ Protecting Smaller Children

If a child has exceeded the weight and height limitations of a rear-facing child restraint system, the child should be properly restrained in a firmly secured front-facing child restraint system until they exceed the weight and height limitations for the front-facing child restraint system.



■ Front-facing child restraint system placement

We strongly recommend placing a front-facing child restraint system in a rear seating position.

Placing a front-facing child restraint system in the front seat can be hazardous. A rear seat is the safest place for a child.

►► Protecting Smaller Children

⚠ WARNING

Placing a front-facing child restraint system in the front seat can result in serious injury or death if the front airbag inflates.

If you must place a front-facing child restraint system in front, move the vehicle seat as far back as possible, and properly restrain the child.

Educate yourself about the laws and regulations regarding child restraint system use where you are driving, and follow the child restraint system manufacturer's instructions.

■ Selecting a Child Restraint System

Some child restraint systems are lower anchorage compatible. Some have a rigid-type connector, while others have a flexible-type connector. Both are equally easy to use. Some existing and previously owned child restraint systems can only be installed using the seat belt. Whichever type you choose, follow the child restraint system manufacturer's use and care instructions including recommended expiration dates as well as the instructions in this manual. Proper installation is key to maximising your child's safety.

The flexible type may not be available in your country.

In seating positions and vehicles not equipped with lower anchorages, install a child restraint system using the seat belt and a top tether for added security. This is because all child restraint systems must be secured with the seat belt when the lower anchorage system is not in use. In addition, the child restraint system manufacturer may advise that a seat belt be used to attach an ISOFIX restraint system once a child reaches a specified weight. Please read the child restraint system owner's manual for proper installation instructions.

■ Important consideration when selecting a child restraint system

Make sure the child restraint system meets the following three requirements:

- The child restraint system is the correct type and size for the child.
- The child restraint system is the correct type for the seating position.
- The child restraint system is compliant with safety standards. We recommend a child restraint system compliant with UN Regulation No. 44 or No. 129, or the regulations of the subject countries. Look for the approval mark on the system and the manufacturer's statement of compliance on the box.

✎ Selecting a Child Restraint System

Installation of a lower anchorage-compatible child restraint system is simple.

Lower anchorage-compatible child restraint systems have been developed to simplify the installation process and reduce the likelihood of injuries caused by incorrect installation.

Malaysian, Thai, Mexican and Indian models


We recommend a rear-facing or a front-facing Honda genuine ISOFIX child restraint system for infants or small children, respectively. Ask your dealer.

■ Child Restraint Systems Standards


If a child restraint system (whether an i-Size/ISOFIX type or one that is fitted with a seat belt) meets the relevant UN Regulation, it will be affixed with an approval label as shown in the adjacent table. Before purchasing or using any child restraint system, make sure to check the approval label and ensure that it is compatible with your vehicle and the child, and that it complies with the relevant UN Regulation.

►► Selecting a Child Restraint System

Example of UN Regulation No. 44 approval label



Example of UN Regulation No. 129 approval label



■ **Lower Anchorage-Compatible Child Restraint Systems**

The two outer rear seats in your vehicle are equipped with lower anchorages. However, not all of the various types of child restraint systems are suitable for use in your vehicle. Before you purchase or use any lower anchorage-compatible (i-Size/ISOFIX) child restraint system, refer to the following tables to ensure that the restraint system is appropriate for the vehicle, the seating position, and the child's weight (mass group) and size.

▣ Lower Anchorage-Compatible Child Restraint Systems

Mass group is specified for some child restraint systems. Make sure to check the mass group as indicated in the manufacturer's instructions as well as on the package and labels of the child restraint system.

The particular child restraint systems listed in the table are genuine Honda products. They are available from your dealer.

For correct installation, refer to the instructions manual that came with the child restraint system.

Indian Models

■ ISOFIX Child Restraint Systems

MASS Group	Size class	Fixture	Vehicle ISOFIX positions				Recommended Child Restraint Systems* ¹
			Front seat	2nd row			
			Passenger	L-side	R-side	Centre	
Carrycot	F	ISO/L1	—	X	X	—	
	G	ISO/L2	—	X	X	—	
Group 0 up to 10 kg	E	ISO/R1	—	IL	IL	—	
Group 0+ up to 13 kg	E	ISO/R1	—	IL	IL	—	
	D	ISO/R2	—	IL	IL	—	Honda Baby & Kids i-Size (Rearward facing)
	C	ISO/R3	—	IL	IL	—	Honda Baby & Kids i-Size (Rearward facing)
Group I 9 kg to 18 kg	D	ISO/R2	—	IL	IL	—	Honda Baby & Kids i-Size (Rearward facing)
	C	ISO/R3	—	IL	IL	—	Honda Baby & Kids i-Size (Rearward facing)
	B	ISO/F2	—	IUF, IL	IUF, IL	—	
	B1	ISO/F2X	—	IUF, IL	IUF, IL	—	Honda Baby & Kids i-Size (Forward facing)
	A	ISO/F3	—	IUF, IL	IUF, IL	—	
Group II 15 kg to 25 kg			—	X	X	—	
Group III 22 kg to 36 kg			—	X	X	—	

►► ISOFIX Child Restraint Systems

When purchasing a child restraint systems, make sure to check the ISOFIX size class or the fixture to ensure that the seat is compatible with your vehicle.

ISOFIX Size Class	Fixture (CRF)	Description
G	ISO/L2	Right lateral-facing (carrycot) infant seat
F	ISO/L1	Left lateral-facing (carrycot) infant seat
E	ISO/R1	Rearward-facing infant seat
D	ISO/R2	Reduced-size rearward-facing child restraint systems
C	ISO/R3	Full-size rearward-facing child restraint systems
B1	ISO/F2X	Reduced-height forward-facing child restraint systems
B	ISO/F2	Reduced-height forward-facing child restraint systems
A	ISO/F3	Full-height, forward-facing child restraint systems

IUF:	Suitable for forward facing ISOFIX child restraints system of universal category approved for use in this mass group.
IL:	Suitable for particular ISOFIX child restraint systems (CRS), including those listed in the corresponding box in the right column of the table. These ISOFIX CRS are those of the 'specific vehicle', 'restricted' or 'semiuniversal' categories.
X:	Seat position not suitable for children in this mass group.
—:	Seat position not equipped with ISOFIX anchorage.
*1:	The named Child Restraint Systems (CRS) reflect Honda's recommendations at the date of publication. You should speak to an authorised dealer for up-to-date details relating to our recommended CRSs. Other CRS may also be suitable - please consult CRS manufacturers for recommended vehicle lists.

■ i-Size Child Restraint Systems

	Seating position				Recommended Child Restraint Systems* ¹
	Front passenger	Rear L-side	Rear R-side	Rear Centre	
i-Size Child Restraint Systems	X	i-U	i-U	X	Honda Baby & Kids i-Size

- i-U: Suitable for i-Size “universal” Child Restraint Systems forward and rearward facing.
- i-UF: Suitable for forward-facing i-Size “universal” Child Restraint Systems only.
- X: Seating position not suitable for i-Size “universal” Child Restraint Systems.
- *1: The named Child Restraint Systems (CRS) reflect Honda’s recommendations at the date of publication. You should speak to an authorised dealer for up to date details relating to our recommended CRSs. Other CRS may also be suitable - please consult CRS manufacturers for recommended vehicle lists.

■ **Child Restraint Systems to be Installed with a Lap/Shoulder Seat Belt**

Not all of the various types of child restraint systems are suitable for use in your vehicle. Before you purchase or use a child restraint system, refer to the following table to ensure that the child restraint system is appropriate for the vehicle, the seating position, and the child’s weight (mass group) and size.

☒ Child Restraint Systems to be Installed with a Lap/Shoulder Seat Belt

Mass group is specified for some child restraint systems. Make sure to check the mass group as indicated in the manufacturer’s instructions as well as on the package and labels of the child restraint system.

The particular child restraint systems listed in the table are genuine Honda products. They are available from your dealer.

For correct installation, refer to the instructions manual that came with the child restraint system.

Indian Models

■ Child Restraint Systems installed with Seat Belt

MASS Group	Seat position				Recommended Child Restraint Systems* ¹
	Front passenger seat	2nd row			
		L-side	R-side	Centre	
Group 0 Up to 10 kg	X	U	U	U	
Group 0+ Up to 13 kg	X	U	U	U	
Group I 9 kg to 18 kg	UF* ²	U	U	U	
Group II 15 kg to 25 kg	UF* ²	U	U	U	
Group III 22 kg to 36 kg	UF* ²	U	U	U	

-
- U: Suitable for 'universal' category restraints approved for use in this mass group.
 - UF: Suitable for forward facing 'universal' category restraints approved for use in this mass group.
 - L: Suitable for particular child restraint systems given in this list. These restraints may be of the "specific vehicle," "restricted," or "semi-universal" category.
 - X: Seat position not suitable for children in this mass group.
 - *1: The named Child Restraint Systems (CRS) reflect Honda's recommendations at the date of publication. You should speak to an authorised dealer for up to date details relating to our recommended CRSs. Other CRS may also be suitable - please consult CRS manufacturers for recommended vehicle lists.
 - *2: Adjust the seat slide to the rearmost position and adjust the seat back to the most front lock position.
 If the child restraint system interferes with the head restraint and cannot be installed stably, raise the head restraint.
 Remove the head restraint if it is removable. If interference can be avoided by raising the head restraint, then it is not necessary to remove it. Please note that the removed head restraint should be stored in the luggage compartment so that it will not fly during sudden braking or collision.
 Also, if you remove the child restraint system, attach the head restraint to the original seat and make sure it is locked.
 However, when using the booster cushion only, do not remove the head restraint.
-

A size class is specified for some child restraint systems. Make sure to check the size class as indicated on the manufacturer's instructions, package, and labels of the child restraint.

For a correct installation, please refer to the Child Restraint Instruction Manual.

Locations for Child Restraint System Installation

Malaysian models



	Suitable for universal restraint systems installed with vehicle safety belts.
	Suitable for forward facing universal restraint systems installed with vehicle safety belts.
	Suitable for i-Size and ISOFIX child restraints systems.
	Suitable for forward facing restraint systems only.
	Never use a rearward facing child restraint system.
	Seat position equipped with Top Tether anchorages.

*1: Adjust the seat slide to the rearmost position and adjust the seat back to the most front lock position.

*2: Forward facing only

*4: The head restraint must be removed when attaching a forward facing booster seat approved by UN R129. Store the removed head restraint in the luggage compartment so that it does not fly during sudden braking or collision. Also, when the booster seat is removed, attach the head restraint to the original seat again and make sure it is locked.

*5: If you can not fix the child restraint system stably, adjust the seat-back angle to be parallel with the back side of the child restraint system, still keeping it forward of the seat belt shoulder anchorage.

Child restraint systems with support legs can be installed on non i-Size seating positions. However, the centre seat is excluded.

Seat position number	Size groups Weight Stature		Seating position			
			①	②	③	④
			Front passenger ^{*1, *5}	2nd row		
				Left	Centre	Right
Seating position suitable for universal belted (yes/no)	Group 0	Up to 10 kg	No	Yes	No	Yes
	Group 0+	Up to 13 kg				
	Group I	9-18 kg	Yes ^{*2}	Yes	Yes ^{*2}	Yes
	Group II	15-25 kg				
	Group III	22-36 kg				
i-Size seating position (yes/no)	≤ 150 cm		No	Yes	No	Yes
Seating position suitable for recommended genuine CRS ^{*3}	Refer to genuine CRS list		No	Yes	No	Yes
Seating position suitable for lateral fixture (L1/L2)	—		No	No	No	No
Largest suitable rearward facing fixture (R1/R2X/R2/R3)	Group 0	Up to 10 kg	No	R3	No	R3
	Group 0+	Up to 13 kg				
	Group I	9-18 kg				
Largest suitable forward facing fixture (F2X/F2/F3)	Group I	9-18 kg	No	F3	No	F3
Largest suitable booster fixture (B2/B3)	≤ 150 cm		B3 ^{*4}	B3	B3	B3

- *1: Adjust the seat slide to the rearmost position and adjust the seat back to the most front lock position.
- *2: Forward facing only
- *3: The named Child Restraint Systems (CRS) reflect Honda's recommendations at the date of publication. You should speak to an authorised dealer for up to date details relating to our recommended CRSs. Other CRS may also be suitable - please consult CRS manufacturers for recommended vehicle lists.
- *4: The head restraint must be removed when attaching a forward facing booster seat approved by UN R129. Store the removed head restraint in the luggage compartment so that it does not fly during sudden braking or collision. Also, when the booster seat is removed, attach the head restraint to the original seat again and make sure it is locked.
- *5: If you can not fix the child restraint system stably, adjust the seat-back angle to be parallel with the back side of the child restraint system, still keeping it forward of the seat belt shoulder anchorage.

Child restraint systems with support legs can be installed on non i-Size seating positions. However, the centre seat is excluded.

►► Locations for Child Restraint System Installation

When purchasing a child restraint systems, make sure to check the ISOFIX size class or the fixture to ensure that the seat is compatible with your vehicle.

Fixture (CRF)	Description
ISO/L1	Left lateral-facing (carrycot) infant seat
ISO/L2	Right lateral-facing (carrycot) infant seat
ISO/R1	Rearward-facing infant seat
ISO/R2X	Reduced-size rearward-facing child restraint systems
ISO/R2	Reduced-size rearward-facing child restraint systems
ISO/R3	Full-size rearward-facing child restraint systems
ISO/F2X	Reduced-height forward-facing child restraint systems
ISO/F2	Reduced-height forward-facing child restraint systems
ISO/F3	Full-height, forward-facing child restraint systems
ISO/B2	Reduced width forward-facing booster seat
ISO/B3	Full width forward-facing booster seat

Thai models



	Suitable for universal restraint systems installed with vehicle safety belts.
	Suitable for forward facing universal restraint systems installed with vehicle safety belts.
	Suitable for i-Size and ISOFIX child restraints systems.
	Suitable for forward facing restraint systems only.
	Never use a rearward facing child restraint system.
	Seat position equipped with Top Tether anchorages.

- *1: When installing a child restraint system, adjust the seat slide to the most rear position.
- *2: Adjust the front seat-back angle to its most upright position.
- *3: When installing a prospective junior seat approved by UN R 129, adjust the front seat-back angle to its most upright position and remove the head restraint.
- *4: If the CRS and head restraint interfere, remove the head restraint. The removed head restraint should be stored in the luggage compartment so that it does not fly during sudden braking or collision.
Also, remove the CRS and if an adult is seated, attach the head restraint to the original seat and make sure it is locked.
Refer to the head restraint page for how to install P. 239

	Size groups Weight Stature		Seating position and Seat position number			
			①	②	③	④
			Front passenger* ¹	2nd row		
				Left	Centre	Right
Seating position suitable for universal belted (yes/no)	Group 0	Up to 10 kg	No	Yes	No	Yes
	Group 0+	Up to 13 kg				
	Group I	9-18 kg	Yes* ² , * ⁴ , * ⁵	Yes	Yes* ⁵	Yes
	Group II	15-25 kg				
	Group III	22-36 kg				
i-Size seating position (yes/no)	≤ 150 cm		No	Yes	No	Yes
Seating position suitable for recommended genuine CRS	Refer to genuine CRS list		No	Yes	No	Yes
Seating position suitable for lateral fixture (L1/L2)	—		No	No	No	No
Largest suitable rearward facing fixture (R1/R2X/R2/R3)	Group 0	Up to 10 kg	No	R3	No	R3
	Group 0+	Up to 13 kg				
	Group I	9-18 kg				
Largest suitable forward facing fixture (F2X/F2/F3)	Group I	9-18 kg	No	F3	No	F3
Largest suitable booster fixture (B2/B3)	≤ 150 cm		B3* ³ , * ⁴	B3	B3	B3

- *1: When installing a child restraint system, adjust the seat slide to the most rear position.
- *2: Adjust the front seat-back angle to its most upright position.
- *3: When installing a prospective junior seat approved by UN R 129, adjust the front seat-back angle to its most upright position and remove the head restraint.
- *4: If the CRS and head restraint interfere, remove the head restraint. The removed head restraint should be stored in the luggage compartment so that it does not fly during sudden braking or collision.
Also, remove the CRS and if an adult is seated, attach the head restraint to the original seat and make sure it is locked.
Refer to the head restraint page for how to install P. 239

- *5: Front facing only

The child restraint system with the support leg can also be installed in the front passenger seating position where i-Size child restraint system is not mountable. However, the central seat is excluded.

Locations for Child Restraint System Installation

When purchasing a child restraint systems, make sure to check the ISOFIX size class or the fixture to ensure that the seat is compatible with your vehicle.

Fixture (CRF)	Description
ISO/L1	Left lateral-facing (carrycot) infant seat
ISO/L2	Right lateral-facing (carrycot) infant seat
ISO/R1	Rearward-facing infant seat
ISO/R2X	Reduced-size rearward-facing child restraint systems
ISO/R2	Reduced-size rearward-facing child restraint systems
ISO/R3	Full-size rearward-facing child restraint systems
ISO/F2X	Reduced-height forward-facing child restraint systems
ISO/F2	Reduced-height forward-facing child restraint systems
ISO/F3	Full-height, forward-facing child restraint systems
ISO/B2	Reduced width forward-facing booster seat
ISO/B3	Full width forward-facing booster seat

Mexican models



	Suitable for universal restraint systems installed with vehicle safety belts.
	Suitable for forward facing universal restraint systems installed with vehicle safety belts.
	Suitable for i-Size and ISOFIX child restraints systems.
	Suitable for forward facing restraint systems only.
	Never use a rearward facing child restraint system.
	Seat position equipped with Top Tether anchorages.

- *1: When installing a child restraint system, adjust the seat slide to the most rear position.
- *2: Adjust the front seat-back angle to its most upright position.
- *3: When installing a prospective junior seat approved by UN R 129, adjust the front seat-back angle to its most upright position and remove the head restraint.
- *4: If the CRS and head restraint interfere, remove the head restraint. The removed head restraint should be stored in the luggage compartment so that it does not fly during sudden braking or collision.
Also, remove the CRS and if an adult is seated, attach the head restraint to the original seat and make sure it is locked.
Refer to the head restraint page for how to install P. 239

			Seating position and Seat position number			
	Size groups Weight Stature		①	②	③	④
			Front passenger* ¹	2nd row		
				Left	Centre	Right
Seating position suitable for universal belted (yes/no)	Group 0	Up to 10 kg	No	Yes	No	Yes
	Group 0+	Up to 13 kg				
	Group I	9-18 kg	Yes* ² , * ⁴ , * ⁵	Yes	Yes* ⁵	Yes
	Group II	15-25 kg				
	Group III	22-36 kg				
i-Size seating position (yes/no)	≤ 150 cm		No	Yes	No	Yes
Seating position suitable for recommended genuine CRS	Refer to genuine CRS list		No	Yes	No	Yes
Seating position suitable for lateral fixture (L1/L2)	—		No	No	No	No
Largest suitable rearward facing fixture (R1/R2X/R2/R3)	Group 0	Up to 10 kg	No	R3	No	R3
	Group 0+	Up to 13 kg				
	Group I	9-18 kg				
Largest suitable forward facing fixture (F2X/F2/F3)	Group I	9-18 kg	No	F3	No	F3
Largest suitable booster fixture (B2/B3)	≤ 150 cm		B3* ³ , * ⁴	B3	B3	B3

- *1: When installing a child restraint system, adjust the seat slide to the most rear position.
- *2: Adjust the front seat-back angle to its most upright position.
- *3: When installing a prospective junior seat approved by UN R 129, adjust the front seat-back angle to its most upright position and remove the head restraint.
- *4: If the CRS and head restraint interfere, remove the head restraint. The removed head restraint should be stored in the luggage compartment so that it does not fly during sudden braking or collision.
Also, remove the CRS and if an adult is seated, attach the head restraint to the original seat and make sure it is locked.
Refer to the head restraint page for how to install P. 239
- *5: Front facing only

The child restraint system with the support leg can also be installed in the front passenger seating position where i-Size child restraint system is not mountable. However, the central seat is excluded.

►► Locations for Child Restraint System Installation

When purchasing a child restraint systems, make sure to check the ISOFIX size class or the fixture to ensure that the seat is compatible with your vehicle.

Fixture (CRF)	Description
ISO/L1	Left lateral-facing (carrycot) infant seat
ISO/L2	Right lateral-facing (carrycot) infant seat
ISO/R1	Rearward-facing infant seat
ISO/R2X	Reduced-size rearward-facing child restraint systems
ISO/R2	Reduced-size rearward-facing child restraint systems
ISO/R3	Full-size rearward-facing child restraint systems
ISO/F2X	Reduced-height forward-facing child restraint systems
ISO/F2	Reduced-height forward-facing child restraint systems
ISO/F3	Full-height, forward-facing child restraint systems
ISO/B2	Reduced width forward-facing booster seat
ISO/B3	Full width forward-facing booster seat

■ ASEAN Genuine CRS List

Range of application	Child Restraint System	Category
Under 100 cm	Honda Baby & Kids i-Size	i-Size Universal ISOFIX (Rearward facing)
Over 71 cm and 15 months to 100 cm	Honda Baby & Kids i-Size	i-Size Universal ISOFIX

■ Indian Genuine CRS List


Mass Group	Child Restraint System	Category
Group 0 up to 10 kg	—	—
Group 0+ up to 13 kg	Honda Baby & Kids i-Size	Semi-universal ISOFIX (Rearward facing)
Group I 9 kg to 18 kg	Honda Baby & Kids i-Size	Semi-universal ISOFIX
Group II, III 15 kg to 36 kg	—	—

■ Latin American and Caribbean Genuine CRS List

Mass Group	Child Restraint System	Category
Group 0 up to 10 kg	—	—
Group 0+ up to 13 kg	Honda Baby & Kids	Semi-universal ISOFIX (Rearward facing)
Group I 9 kg to 18 kg	Honda Baby & Kids	Semi-universal ISOFIX
Group II, III 15 kg to 36 kg	—	—

■ Installing a Lower Anchorage-Compatible Child Restraint System

A lower anchorage-compatible child restraint system can be installed in either of the two outer rear seats. A child restraint system is attached to the lower anchorages with either the rigid or flexible type of connectors.




1. Locate the lower anchorages under the marks.

►► Installing a Lower Anchorage-Compatible Child Restraint System


⚠ WARNING

Never attach two child restraint systems to the same anchorage. In a collision, one anchorage may not be strong enough to hold two child restraint system attachments and may break, causing serious injury or death.

Some child restraint systems come with optional guide-cups, which avoid possible damage to the seat surface. Follow the manufacturer's instructions when using the guide-cups, and attach them to the lower anchorages as shown in the image.




* Not available on all models



2. Place the child restraint system on the vehicle seat, then attach the child restraint system to the lower anchorages according to the instructions that came with the child restraint system.

- When installing the child restraint system, make sure that the lower anchorages are not obstructed by the seat belt or any other object.
- Install the child restraint system so that the gap between it and the seat-back is as small as possible.



Child restraint system with tether strap


3. Open the tether anchor cover behind the head restraint.

►► Installing a Lower Anchorage-Compatible Child Restraint System

WARNING: Never use a hook that does not come with a Top Tether Anchorage Symbol when securing an installed child restraint system.

For your child's safety, when using a child restraint system installed using the lower anchorage system, make sure that the child restraint system is properly secured to the vehicle. A child restraint system that is not properly secured will not adequately protect a child in a crash and may cause injury to the child or other vehicle occupants.

The flexible type may not be available in your country.



4. Straight top tether type

Route the tether strap over the top of the head restraint. Make sure the strap is not twisted.

Other top tether type

Route the tether strap around the head restraint. Make sure the strap is not twisted.

5. Secure the tether strap hook to the anchorage.

6. Tighten the tether strap as instructed by the child restraint system manufacturer.



7. Make sure the child restraint system is firmly secured by rocking it forward and back, and side to side; little movement should be felt.



Child restraint system with support leg

- 3.** Extend the support leg until it touches the floor as instructed by the child restraint system manufacturer.
 - Confirm that the section of the floor on which the support leg rests is level. If the section is not level, the support leg will not provide adequate support.
 - Make sure that there is no contact between the child restraint system and the seat in front of it.
- 4.** Make sure the child restraint system is firmly secured by rocking it forward and back, and side to side; little movement should be felt.



■ Installing a Child Restraint System with a Lap/Shoulder Seat Belt



1. Place the child restraint system on the vehicle seat.
2. Route the seat belt through the child restraint system according to the child restraint system manufacturer's instructions, and insert the latch plate into the buckle.
► Insert the latch plate fully until it clicks.
3. Push down the tab. Route the shoulder part of the belt into the slit at the side of the restraint.
4. Grab the shoulder part of the belt near the buckle, and pull up to remove any slack from the lap part of the belt.
► When doing this, place your weight on the child restraint system and push it into the vehicle seat.
5. Position the belt properly and push up the tab. Make sure the belt is not twisted.
► When pushing up the tab, pull up the upper shoulder part of the belt to remove any slack from the belt.

▣ Installing a Child Restraint System with a Lap/Shoulder Seat Belt

A child restraint system that is not properly secured will not adequately protect a child in a crash and may cause injury to the child or other vehicle occupants.




6. Make sure the child restraint system is firmly secured by rocking it forward and back, and side to side; little movement should be felt.
7. Make sure any unused seat belt that a child can reach is buckled.

If your child restraint system does not come with a mechanism that secures the belt, install a locking clip on the seat belt.


After going through the step 1 and 2, pull up the shoulder part of the belt and make sure there is no slack in the lap portion.

3. Tightly grasp the belt near the latch plate.
Pinch both parts of the belt together so they do not slip through the latch plate.
Unbuckle the seat belt.
4. Install the locking clip as shown in the image. Position the clip as close as possible to the latch plate.
5. Insert the latch plate into the buckle. Go to step 6 and 7.

■ Adding Security with a Tether



A tether anchorage point is provided behind each rear outer seating position. If you have a child restraint system that comes with a tether but can be installed with a seat belt, the tether may be used for additional security.




1. Locate the appropriate tether anchorage point.

2. **Straight top tether type**

Route the tether strap over the top of the head restraint. Make sure the strap is not twisted.

Other top tether type

Route the tether strap around the head restraint. Make sure the strap is not twisted.



3. Secure the tether strap hook to the anchorage.
4. Tighten the tether strap as instructed by the child restraint system manufacturer.

► Adding Security with a Tether

WARNING: Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts, harnesses or for attaching other items or equipment to the vehicle.

Always use a tether for front-facing child restraint systems whether using the seat belt or lower anchorages.

Safety of Larger Children

■ Protecting Larger Children

The following pages give instructions on how to check proper seat belt fit, what kind of booster seat to use if one is needed, and important precautions for a child who must sit in front.

■ Checking Seat Belt Fit

When a child is too big for a child restraint system, secure the child in a rear seat using the lap/shoulder seat belt. Have the child sit upright and all the way back, then answer the following questions.



■ Checklist

- Do the child's knees bend comfortably over the edge of the seat?
- Does the shoulder belt cross between the child's neck and arm?
- Is the lap part of the seat belt as low as possible, touching the child's thighs?
- Will the child be able to stay seated like this for the whole trip?

If you answer yes to all these questions, the child is ready to wear the lap/shoulder seat belt correctly. If you answer no to any question, the child needs to ride on a booster seat until the seat belt fits properly without a booster seat.


►► Safety of Larger Children

⚠ WARNING

Allowing a child aged 12 or under to sit in front can result in injury or death if the passenger's front airbag inflates.

If a larger child must ride in front, move the vehicle seat as far to the rear as possible, have the child sit up properly and wear the seat belt properly, and use a booster seat if needed.

Booster Seats



If a lap/shoulder seat belt cannot be used properly, position the child in a booster seat in the rear seat. For the child's safety, check that the child meets the booster seat manufacturer's recommendations.

A backrest is available for a specific booster seat. Install the backrest to the booster seat and adjust it to the vehicle seat according to the booster seat manufacturer's instructions. Make sure the seat belt is properly routed through the guide at the shoulder of the backrest and the belt does not touch and cross the child's neck.

Booster Seats

When installing a booster seat, make sure to read the instructions that came with it, and install the seat accordingly.

There are high- and low-type booster seats. Choose a booster seat that allows the child to wear the seat belt correctly.

We recommend a booster seat with a backrest as it is easier to adjust the shoulder belt.

■ Protecting Larger Children - Final Checks

Your vehicle has a rear seat where children can be properly restrained. If you ever have to carry a group of children, and a child must ride in front:

- Make sure you read and fully understand the instructions and safety information in this manual.
- Move the front passenger seat as far back as possible.
- Have the child sit upright and well back in the seat.
- Check that the seat belt is properly positioned so that the child is secure in the seat.

■ Monitoring child passengers

We strongly recommend that you keep an eye on child passengers. Even older, more mature children sometimes need to be reminded to fasten their seat belts and sit up properly.

Carbon Monoxide Gas

The engine exhaust from this vehicle contains carbon monoxide, a colourless, odourless, and highly toxic gas. As long as you properly maintain your vehicle, carbon monoxide gas will not get into the interior.

■ Have the exhaust system inspected for leaks whenever

- The exhaust system is making an unusual noise.
- The exhaust system may have been damaged.
- The vehicle is raised for an oil change.

When you operate a vehicle with the boot open, airflow can pull exhaust gas into the interior and create a hazardous condition. If you must drive with the boot open, open all the windows and set the heating* and cooling system* or climate control system* as shown below.

1. Select the fresh air mode.
2. Select the  mode.
3. Set the fan speed to high.
4. Set the temperature control to a comfortable setting.

Adjust the heating* and cooling system* or climate control system* in the same manner if you sit in your parked vehicle with the engine running.

Carbon Monoxide Gas

⚠ WARNING

Carbon monoxide gas is toxic.

Breathing it can cause unconsciousness and even kill you.

Avoid any enclosed areas or activities that expose you to carbon monoxide.


An enclosed area such as a garage can quickly fill up with carbon monoxide gas. Do not run the engine with the garage door closed. Even when the garage door is open, drive out of the garage immediately after starting the engine.

* Not available on all models

Label Locations


These labels are in the locations shown. They warn you of potential hazards that can cause serious injury or death. Read these labels carefully.

If a label comes off or becomes hard to read, contact a dealer for a replacement.



Instrument Panel

This chapter describes the buttons, indicators, and gauges that are used while driving.



Indicators	102
Gauges and Displays	128
Gauges.....	128
Information Display*	131
Driver Information Interface (A-type meter)*	133
Driver Information Interface (B-type meter)*	157

Indicators come on/blink depending on the condition of the vehicle. Messages may display on the driver information interface* at the same time. Please take the appropriate action outlined in the message, such as contacting a dealer.

 *1	Parking Brake and Brake System Indicator (Red)	→ P. 104
 *1	Brake System Indicator (Amber)	→ P. 105
 *1	Low Oil Pressure Indicator*	→ P. 105
 *1	Malfunction Indicator Lamp	→ P. 105
 *1	Charging System Indicator	→ P. 105
 *2, *3	Transmission System Indicator*	→ P. 106
 *4		
 *2		
 *3	M (7-speed manual shift mode) Indicator*/Shift Indicator*	→ P. 106
 *4		
 *2, *3	Shift Position Indicator*	→ P. 107
 *4		
	Shift Up Indicator*	→ P. 107
	Shift Down Indicator*	→ P. 107
	Seat Belt Reminder Indicator	→ P. 108
 *1	Rear Seat Belt Reminder Indicators*	→ P. 109
	Low Fuel Indicator (Amber)	→ P. 109
 *1	Anti-lock Brake System (ABS) Indicator	→ P. 109
 *1	Supplemental Restraint System Indicator	→ P. 109
 *1	Door and Boot Open Indicator*	→ P. 110
 *1	Vehicle Stability Assist (VSA) System Indicator	→ P. 111
 *1	VSA OFF Indicator	→ P. 111
 *1	Electric Power Steering (EPS) System Indicator	→ P. 111
	Turn Signal and Hazard Warning Indicators	→ P. 112
	Lights On Indicator	→ P. 112
	High-Beam Indicator	→ P. 112
 *1	Auto High-Beam Indicator*	→ P. 112
	Rear Fog Light Indicator*	→ P. 113
 *1	Light Control Indicator*	→ P. 113

*1: When you set the power mode to ON, these indicators come on to indicate that system checks are being performed. They go off a few seconds later or after the engine has started. If an indicator does not come on or turn off, there may be a malfunction in the corresponding system. To resolve the issue, follow the instructions in the owner's manual.

*2: Models with information display

*3: Models with A-type meter

*4: Models with B-type meter

	*1 Keyless Access System Indicator* → P. 116		System Message Indicator* → P. 119		*1 Lane Keeping Assist System (LKAS) Indicator (Amber)* → P. 122
	ECON Mode Indicator* → P. 116	NO KEY	NO KEY Indicator* → P. 126		Lane Keeping Assist System (LKAS) Indicator (White/Green)* → P. 122
ECO	ECO Indicator* → P. 116		KEY BATT Indicator* → P. 126		*1 Collision Mitigation Braking System (CMBS) Indicator (Amber)* → P. 122
	CRUISE MAIN Indicator* → P. 116		*1 High Temperature Indicator (Red)* → P. 110		Collision Mitigation Braking System (CMBS) Indicator (Grey)* → P. 122
	CRUISE CONTROL Indicator* → P. 116		Low Temperature Indicator (Blue) → P. 110		*1 Road Departure Mitigation Indicator (Amber)* → P. 123
	*1 Starter System Indicator* → P. 117		Immobilizer System Indicator → P. 114		Road Departure Mitigation System Steering Assist Auto OFF Indicator* → P. 123
	Rotate Wheel Indicator* → P. 117		Security System Alarm Indicator → P. 115		Road Departure Mitigation Indicator (Grey)* → P. 123
	Shift to Park Indicator* → P. 117		*1 Auto Idle Stop System Indicator (Amber)* → P. 120		*1 Safety Support Indicator (Amber)* → P. 124
	*1 Emergency Call (eCall) Indicator* → P. 117		Auto Idle Stop Indicator (Green)* → P. 120		Safety Support Indicator (Green/Grey)* → P. 126
	*1 Low Tyre Pressure/Deflation Warning System Indicator* → P. 118		*1 Adaptive Cruise Control (ACC) Indicator (Amber)* → P. 121		
80 km/h	*1 Speed Alarm Indicator* → P. 119		Adaptive Cruise Control (ACC) Indicator (White/Green)* → P. 121		
120 km/h	*1 Speed Alarm Indicator* → P. 119				

*1: When you set the power mode to ON, these indicators come on to indicate that system checks are being performed. They go off a few seconds later or after the engine has started. If an indicator does not come on or turn off, there may be a malfunction in the corresponding system. To resolve the issue, follow the instructions in the owner's manual.

* Not available on all models

Indicator	Name	On/Blinking	Explanation
 (Red)	Parking Brake and Brake System Indicator (Red)	Comes on when the parking brake is applied, and goes off when it is released.	The beeper sounds and the indicator comes on if you drive with the parking brake not fully released.
		Comes on when the brake fluid level is low.	Comes on while driving - Make sure the parking brake is released. Stop in a safe place and check the brake fluid level.  What to do when the indicator comes on while driving P. 500
		Comes on if there is a problem with the brake system.	Thai models Comes on along with the Parking Brake and Brake System Indicator (amber) - Immediately stop in a safe place. Contact a dealer for repair. The brake pedal becomes harder to operate. Depress the pedal further than you normally do. All models Comes on along with the ABS indicator - Have your vehicle checked by a dealer.  If the Brake System Indicator (Red) Comes On P. 500

Indicator	Name	On/Blinking	Explanation
 (Amber)	Brake System Indicator (Amber)	Comes on if there is a problem with a system related to braking other than the conventional brake system.	Thai models Comes on while driving - Avoid high speeds and sudden braking. Take the vehicle to a dealer immediately. Except Thai models Comes on while driving - Have your vehicle checked by a dealer. - With this indicator on, your vehicle still has normal braking ability.
	Low Oil Pressure Indicator*	Comes on when the engine oil pressure is low.	Comes on while driving - Immediately stop in a safe place. ➤ If the Low Oil Pressure Indicator Comes On P. 497
	Malfunction Indicator Lamp	- Comes on if there is a problem with the emissions control systems. - Blinks when a misfire in the engine's cylinders is detected.	➤ If the Malfunction Indicator Lamp Comes On or Blinks P. 500
	Charging System Indicator	Comes on when there is a problem with the charging system.	- Stop in a safe place and contact a dealer immediately. ➤ Checking the Battery P. 446 ➤ If the Charging System Indicator Comes On P. 499

Indicator	Name	On/Blinking	Explanation
 *1, *2  *3	Transmission System Indicator*	Blinks if the transmission system has a problem.	- Have your vehicle checked by a dealer immediately. Thai models Do not drive displays on the driver information interface - Immediately stop in a safe place and contact a dealer.
 *1  *2  *3	M (7-speed manual shift mode) Indicator*/Shift Indicator*	Comes on when the 7-speed manual shift mode is applied.	 7-Speed Manual Shift Mode P. 284

*1:Models with information display
*2:Models with A-type meter
*3:Models with B-type meter

Indicator	Name	On/Blinking	Explanation
	Shift Position Indicator*	Indicates the current shift position.	 Shifting P. 281
	Shift Up Indicator*	Comes on when shifting up is recommended.	 Shift Up/Down Indicator* P. 287
	Shift Down Indicator*	Comes on when shifting down is recommended.	 Shift Up/Down Indicator* P. 287

*1: Models with information display or A-type meter

*2: Models with B-type meter

Indicator	Name	On/Blinking	Explanation
	Seat Belt Reminder Indicator	- Comes on if you are not wearing a seat belt when you set the power mode to ON. - If the front passenger is not wearing a seat belt, the indicator comes on a few seconds later. Latin American, Indian, Bhutanese, Nepalese and Malaysian models with driver information interface - Comes on for a while if any rear passenger unfastens their seat belt while the power mode is ON. - Blinks and beeper sounds while driving when you or the front passenger are unfastened or any rear passenger unfastens their seat belt. Except Latin American, Indian, Bhutanese, Nepalese and Malaysian models with driver information interface Models with information display - Blinks and beeper sounds while driving when you or the front passenger are unfastened.	Latin American, Indian, Bhutanese, Nepalese and Malaysian models with driver information interface - The beeper stops and the indicator goes off when you and the passengers fasten their seat belts. Stays on after you and/or the passengers have fastened the seat belt(s) - A detection error may have occurred in the sensor. Have your vehicle checked by a dealer.  Seat Belt Reminder P. 43 Except Latin American, Indian, Bhutanese, Nepalese and Malaysian models with driver information interface Models with information display - The beeper stops and the indicator goes off when you and the front passenger fasten their seat belts. Stays on after you and/or the front passenger has fastened the seat belt(s) - A detection error may have occurred in the sensor. Have your vehicle checked by a dealer.  Seat Belt Reminder P. 43

Indicator	Name	On/Blinking	Explanation
	Rear Seat Belt Reminder Indicators*	• Comes on if the rear seat belts are unfastened when you set the power mode to ON. • Blinks and the beeper sounds while driving if the rear seat belts are unfastened.	• Goes off when the rear passengers have fastened their seat belts. ➤ Seat Belt Reminder P. 43
	Low Fuel Indicator (Amber)	• Comes on when the fuel reserve is running low (approximately 6.0 Litres left). • Blinks if there is a problem with the fuel gauge.	• Refuel your vehicle as soon as possible. • Have your vehicle checked by a dealer.
	Anti-lock Brake System (ABS) Indicator	• Comes on if there is a problem with the ABS.	• Stays on constantly - Have your vehicle checked by a dealer. With this indicator on, your vehicle still has normal braking ability but no anti-lock function. ➤ Anti-lock Brake System (ABS) P. 378
	Supplemental Restraint System Indicator	• Comes on if a problem with any of the following is detected: - Supplemental Restraint System - Side airbag system* - Side curtain airbag system* - Seat belt tensioner	• Stays on constantly - Have your vehicle checked by a dealer.

* Not available on all models


Indicator	Name	On/Blinking	Explanation
	High Temperature Indicator (Red)*	Blinks when the engine coolant temperature goes up, and stays on if the temperature continues to rise.	- Comes on blue when the engine coolant temperature is low. Blinks while driving - Drive slowly to prevent overheating. Stays on while driving - Immediately stop in a safe place and allow the engine to cool.  Overheating P. 493
	Low Temperature Indicator (Blue)	Comes on when the engine coolant temperature is low.	If the indicator stays on after the engine has reached normal operating temperature, there may be a problem with the temperature sensors. Have your vehicle inspected by a dealer.
	Door and Boot Open Indicator*	- Comes on if any door or the boot is not completely closed. - The beeper sounds and the indicator comes on if the boot or any door is opened while driving.	Goes off when the boot and all doors are closed.

Indicator	Name	On/Blinking	Explanation
	Vehicle Stability Assist (VSA) System Indicator	• Blinks when VSA is active.	—
		• Comes on if there is a problem with the VSA system, brake assist system, hill start assist system, starting assist brake function*, or agile handling assist.	• Stays on constantly - Have your vehicle checked by a dealer. ➤ Vehicle Stability Assist (VSA) System P. 298 ➤ Brake Assist System P. 379 ➤ Hill Start Assist System P. 277 ➤ Starting Assist Brake Function P. 293 ➤ Agile Handling Assist P. 300
		• Comes on if the VSA system is deactivated temporarily after the battery has been disconnected, then reconnected.	• Drive a short distance at more than 20 km/h (12 mph). The indicator should go off. If it does not, have your vehicle checked by a dealer.
	Vehicle Stability Assist (VSA) OFF Indicator	• Comes on when you partially disable VSA. • Comes on if the VSA system is deactivated temporarily after the battery has been disconnected, then reconnected.	• ➤ VSA On and Off P. 299 • Drive a short distance at more than 20 km/h (12 mph). The indicator should go off. If it does not, have your vehicle checked by a dealer.
	Electric Power Steering (EPS) System Indicator	• Comes on if there is a problem with the EPS system.	• Stays on constantly - Have your vehicle checked by a dealer. • Models with driver information interface • Do Not Drive displays on the driver information interface - Immediately stop in a safe place and contact a dealer. ➤ If the Electric Power Steering (EPS) System Indicator Comes On P. 501

Indicator	Name	On/Blinking	Explanation
	Turn Signal and Hazard Warning Indicators	- Blinks when you operate the turn signal lever. - Blinks along with all turn signals when you press the hazard warning button.	Does not blink or blinks rapidly ➤ Replacing Light Bulbs P. 428, 428, 429
		Except Mexican models Blinks along with all turn signals when you depress the brake pedal while the high speed driving.	➤ Emergency Stop Signal P. 380
	Lights On Indicator	Comes on when the position, tail, and other external lights are on.	➤ Light Switches P. 213
	High-Beam Indicator	Comes on when the high beam headlights are on.	—
	Auto High-Beam Indicator*	Comes on when all the operating conditions of the auto high-beam are met.	➤ Auto High-Beam* P. 219

Indicator	Name	On/Blinking	Explanation
	Rear Fog Light Indicator*	Comes on when the rear fog light is on.	 Rear Fog Light* P. 217
	Light Control Indicator*	Comes on if there is a problem with the automatic lighting control system.	Comes on while driving - Manually turn the lights on, and have your vehicle checked by a dealer.
		Comes on if there is a problem with the headlights.	Comes on while driving - The headlights may not be on. When conditions allow you to drive safely, have your vehicle checked by a dealer as soon as possible.

*1:Models with information display
*2:Models with A-type meter
*3:Models with B-type meter

Indicator	Name	On/Blinking	Explanation
*1  Indicator *2  Indicator *3  Indicator	Security System Alarm Indicator	Blinks when the security system alarm has been set.	 Security System Alarm P. 199

*1: Models with information display

*2: Models with A-type meter

*3: Models with B-type meter

Indicator	Name	On/Blinking	Explanation
	Keyless Access System Indicator*	Comes on as soon as a problem is detected in the keyless access system* or keyless starting system.	Stays on constantly or does not come on at all - Have your vehicle checked by a dealer.
	ECON Mode Indicator*	Comes on when the ECON mode is on.	➤ ECON Mode* P. 289
ECO	ECO Indicator*	Comes on while the engine is operating in its most economical range.	—
	CRUISE MAIN Indicator*	Comes on when you press the CRUISE button.	➤ Cruise Control* P. 294
	CRUISE CONTROL Indicator*	Comes on if you have set a speed for cruise control.	➤ Cruise Control* P. 294

Indicator	Name	On/Blinking	Explanation
	Starter System Indicator*	Comes on if the starting system has a problem.	As a temporary measure, press and hold the ENGINE START/STOP button for 15 seconds while pressing the brake pedal, and manually start the engine. Have your vehicle checked by a dealer.
	Rotate Wheel Indicator*	Comes on when the steering wheel is locked.	Move the steering wheel left and right while pressing the ENGINE START/STOP button.
	Shift to Park Indicator*	Blinks if you push the ENGINE START/STOP button to turn the engine off without the shift lever in P.	Press the ENGINE START/STOP button twice after moving the shift lever to P.
	Emergency Call (eCall) Indicator*	Comes on if the emergency call system has a problem.	Stays on constantly - Have your vehicle checked by a dealer.  Emergency Call (eCall)* P. 518

Indicator	Name	On/Blinking	Explanation
	Low Tyre Pressure/Deflation Warning System Indicator*	• May come on briefly if the power mode is set to ON and the vehicle is not moved within 45 seconds, to indicate the initialise process is not yet complete. • Comes on and stays on when: - One or more tyres' pressures are determined to be significantly low. - The system has not been initialised.	• Comes on while driving - Stop in a safe place, check tyre pressures, and inflate the tyre(s) if necessary. • Stays on after the tyres are inflated to the recommended pressures - The system needs to be initialised.  Deflation Warning System Initialisation/Calibration P. 303
		• Blinks for about one minute, and then stays on if there is a problem with the deflation warning system, or when a temporary spare tyre*/compact spare tyre* is temporarily installed.	• Blinks and remains on - Have your vehicle checked by a dealer. If the vehicle is fitted with a temporary spare tyre*/compact spare tyre*, get your regular tyre repaired or replaced and put back on your vehicle as soon as you can.
		• Comes on if the deflation warning system is deactivated temporarily after the battery has been disconnected, then reconnected.	• Drive a short distance at more than 20 km/h (12 mph). The indicator should go off. If it does not, have your vehicle checked by a dealer.

Indicator	Name	On/Blinking	Explanation
80 km/h	Speed Alarm Indicator*	- Comes on when your vehicle speed exceeds 80 km/h. A reminder tone sounds about every two minutes. - Blinks when your vehicle speed exceeds 120 km/h. A reminder tone sounds continuously.	- This indicator keeps illuminating while your vehicle speed is faster than 80 km/h. - This indicator keeps blinking while your vehicle speed is faster than 120 km/h.
120 km/h	Speed Alarm Indicator*	Blinks when your vehicle speed exceeds 120 km/h. A reminder tone sounds.	This indicator keeps blinking while your vehicle speed is faster than 120 km/h.
	System Message Indicator*	Comes on along with a beep when a problem is detected. A system message on the driver information interface appears at the same time.	- While the indicator is on, press the  (home) button, and select  to see the message again. Switching the Display P. 133, 157 - Refer to the Indicators information in this chapter when a system message appears on the driver information interface. Respond to the message accordingly. - The driver information interface does not return to the normal screen unless the warning is cancelled, or the left selector wheel is pressed.

Indicator	Name	On/Blinking	Explanation
	Auto Idle Stop System Indicator (Amber)*	Comes on when the Auto Idle Stop system has been turned off by the Auto Idle Stop OFF button.	 Auto Idle Stop System ON/OFF P. 291
		Blinks if there is a problem with the Auto Idle Stop system.	Have your vehicle checked by a dealer.
	Auto Idle Stop Indicator (Green)*	Comes on when Auto Idle Stop is in operation. The engine automatically shuts off.	 Auto Idle Stop* P. 290

Indicator	Name	On/Blinking	Explanation
	Adaptive Cruise Control (ACC) Indicator (Amber)*	Comes on if there is a problem with ACC.	Comes on while driving - Have your vehicle checked by a dealer.
		- Comes on if the ACC is deactivated temporarily after the battery has been disconnected, then reconnected. - Indicator may come on temporarily when the maximum permissible weight is exceeded. - ACC has been automatically cancelled.	- Drive a short distance at more than 20 km/h (12 mph). The indicator should go off. If it does not, have your vehicle checked by a dealer. - Make sure the total load is within the maximum permissible weight.  Load Limit P. 270 Stays on constantly - Have your vehicle checked by a dealer.
	Adaptive Cruise Control (ACC) Indicator (White/Green)*	- Lights up in white when you press the  button. - Lights up in green while the system is in operation.	 Adaptive Cruise Control (ACC) P. 337

Indicator	Name	On/Blinking	Explanation
	Lane Keeping Assist System (LKAS) Indicator (Amber)*	Comes on if there is a problem with the LKAS.	Stays on constantly - Have your vehicle checked by a dealer.
		Indicator may come on temporarily when the maximum permissible weight is exceeded.	- Make sure the total load is within the maximum permissible weight. ➤ Load Limit P. 270 Stays on constantly - Have your vehicle checked by a dealer.
	Lane Keeping Assist System (LKAS) Indicator (White/Green)*	- Lights up in white when you press the LKAS button. - Lights up in green when the LKAS is in operation.	➤ Lane Keeping Assist System (LKAS) P. 355
	Collision Mitigation Braking System (CMBS) Indicator (Amber)*	Comes on if there is a problem with the CMBS or it cannot be used temporarily due to issues such as dirt on the windscreen near the camera.	- The Safety Support Indicator (Amber) comes on at the same time. ➤ Safety Support Indicator (Amber)* P. 125
		Models with A-type meter Comes on when the CMBS is off.	➤ Safety Support* P. 139
	Collision Mitigation Braking System (CMBS) Indicator (Grey)*	Comes on when the CMBS is off.	➤ Safety Support* P. 139

Indicator	Name	On/Blinking	Explanation
	Road Departure Mitigation Indicator (Amber)*	Comes on if there is a problem with the Road Departure Mitigation System or it cannot be used temporarily due to issues such as dirt on the windscreen near the camera.	- The Safety Support Indicator (Amber) comes on at the same time. ➤ Safety Support Indicator (Amber)* P. 125
		Models with A-type meter Comes on when the Road Departure Mitigation System steering assist is automatically turned off.	➤ Road Departure Mitigation System P. 325
		Models with A-type meter Comes on when the Road Departure Mitigation System is off.	➤ Safety Support* P. 139
	Road Departure Mitigation System Steering Assist Auto OFF Indicator*	Comes on when the Road Departure Mitigation System steering assist is automatically turned off.	➤ Road Departure Mitigation System P. 325
	Road Departure Mitigation Indicator (Grey)*	Comes on when the Road Departure Mitigation System is off.	➤ Safety Support* P. 139

* Not available on all models


Indicator	Name	On/Blinking	Explanation
	Safety Support Indicator (Amber)*	• Comes on if there is a problem with the Road Departure Mitigation system or CMBS.	• Stays on constantly - Have your vehicle checked by a dealer.
		• Indicator may come on temporarily when the maximum permissible weight is exceeded.	• Make sure the total load is within the maximum permissible weight. 📖 Load Limit P. 270 • Stays on constantly - Have your vehicle checked by a dealer.
		• Comes on if the Road Departure Mitigation system and CMBS are deactivated temporarily after the battery has been disconnected and then reconnected.	• Drive a short distance at more than 20 km/h (12 mph). The indicator should go off. If it does not, have your vehicle checked by a dealer.

Indicator	Name	On/Blinking	Explanation
	Safety Support Indicator (Amber)*	Comes on when the Road Departure Mitigation system and/or CMBS shuts itself off.	Stays on - The temperature inside the camera is too high. Use the climate control system to cool down the camera. The system activates when the temperature inside the camera cools down.  Front Wide View Camera P. 374
			Stays on - The area around the camera is blocked by dirt, mud, etc. Stop your vehicle in a safe place and wipe the debris off with a soft cloth. - Have your vehicle checked by a dealer if the indicator and message are still displayed even after you have cleaned the area around the camera.  Front Wide View Camera P. 374 - It may come on when the ambient conditions are dark, such as when driving in a tunnel, or at night, dawn, or dusk.

Indicator	Name	On/Blinking	Explanation
	Safety Support Indicator (Green/Grey)*	• Lights up in green when the Road Departure Mitigation system and CMBS are on. • Lights up in green and grey when one or more of the systems above are off. • Lights up in grey when all systems above are off.	➤ Road Departure Mitigation System P. 325 ➤ Collision Mitigation Braking System (CMBS) P. 311
	NO KEY Indicator*	• Comes on when you close the door with the power mode in ON without the keyless remote inside the vehicle.	• The indicator goes off when you bring the keyless remote back inside the vehicle, and close the door.
	KEY BATT Indicator*	• Comes on when the keyless remote's battery becomes weak.	• Replace the battery as soon as possible. ➤ Replacing the Remote Battery P. 450

Information Display Warning and Information Messages*

The following messages appear only on the information display.

Message	Condition	Explanation
	- Appears when there is a problem with the sensor on the battery. - Appears along with the battery charging system indicator when the battery is not charging.	Stays on constantly - Have your vehicle checked by a dealer. - Turn off the heating and cooling system*/climate control system* and rear demister to reduce electricity consumption. ► If the Charging System Indicator Comes On P. 499
	Appears when the power mode is in ACCESSORY.	—
	Appears if you push the ENGINE START/STOP button to turn the engine off without the shift to P.	Move the shift to P, then press the ENGINE START/STOP button twice.
	Appears when the steering wheel is locked.	Move the steering wheel left and right while pressing the ENGINE START/STOP button at the same time.

Gauges

Gauges include the speedometer, fuel gauge, and other related indicators. They are displayed when the power mode is in ON.

■ Speedometer

Displays your driving speed in km/h and mph*.

■ Fuel Gauge

Displays the amount of fuel left in the fuel tank.

■ Tachometer

Shows the number of engine revolutions per minute.

Models with information display

■ Instant Fuel Economy Gauge

Shows the instant fuel economy as a bar graph in km/l* or l/100 km*.

» Speedometer

Mexican models

You can change the speed/distance units.

➤ **Speed/distance units** P. 141, 159

➤ **Settings** P. 142, 167

» Fuel Gauge

NOTICE

You should refuel when the reading approaches **[E]**. Running out of fuel can cause the engine to misfire, damaging the catalytic converter.

After lightly refueling, or depending on your vehicle's condition, the actual amount of remaining fuel may differ from the fuel gauge reading.

» Tachometer

Models with B-type meter

You can turn the tachometer display on or off.

➤ **Settings** P. 167

Models with driver information interface

■ Odometer

Shows the total number of kilometres or miles* that your vehicle has accumulated.

■ Outside Temperature

Shows the outside temperature in Celsius.

Models with information display

If the outside temperature has been below 3°C at the time you set the power mode to ON, the outside temperature indicator blinks for 10 seconds.

Except Mexican models with driver information interface

If the outside temperature has been below 3°C at the time you set the power mode to ON, the **Outside Temperature Low** message appears on the driver information interface.

■ Adjusting the outside temperature display

Adjust the temperature reading by up to $\pm 3^{\circ}\text{C}$ if the temperature reading seems incorrect.

Models with information display

1. Set the power mode to ON.
2. Press and hold the **TRIP/CLOCK** button for 10 seconds or more while the outside temperature is shown on the information display.
 - The information display goes into temperature adjustment mode. The display starts showing from -3°C to $+3^{\circ}\text{C}$.
3. Release the **TRIP/CLOCK** button when the right adjustment amount is shown.
 - The adjustment is complete.

» Outside Temperature

The temperature sensor is in the front bumper. Road heat and exhaust from another vehicle can affect the temperature reading when your vehicle speed is less than 30 km/h (19 mph).

It may take several minutes for the display to be updated after the temperature reading has stabilised.

» Adjusting the outside temperature display

Models with driver information interface

You can adjust the temperature reading.

► **Settings** P. 142, 167

* Not available on all models

■ Clock

Shows the clock.

■ Current Mode for ACC and the LKAS*

Shows the current mode for ACC and LKAS.

➤ **Adaptive Cruise Control (ACC)** P. 337

➤ **Lane Keeping Assist System (LKAS)** P. 355

» Clock

You can adjust the time manually and change the clock display to show the 12 hour clock or 24 hour clock.


➤ **Clock** P. 180

Information Display*

The information display shows the odometer, trip meter, and other gauges.

Switching the Display

Press the **TRIP/CLOCK** button to change the display.



* Not available on all models

■ Odometer

Shows the total number of kilometres that your vehicle has accumulated.

■ Trip Meter

Shows the total number of kilometres driven since the last reset. Meters A and B can be used to measure two separate trips.

■ Resetting a trip meter

To reset a trip meter, display it, then press and hold the **TRIP/CLOCK** button. The trip meter is reset to **0.0**.

■ Average Fuel Economy

Shows the estimated average fuel economy of each trip meter in km/l* or l/100 km*. The display is updated at set intervals. When a trip meter is reset, the average fuel economy is also reset.

■ Range

Shows the estimated distance you can travel on the remaining fuel. This estimated distance is based on the vehicle's current fuel economy.

» Trip Meter

Switch between trip meter A and trip meter B by pressing the **TRIP/CLOCK** button.

Driver Information Interface (A-type meter)*

The driver information interface shows information such as the estimated travelable distance and fuel economy of the vehicle. It also displays messages such as warnings and other helpful information.

When a warning message displays, please check the message and contact a dealer to have the vehicle inspected if necessary. Please refer to the pages below if the

Engine oil pressure low or **Engine temperature too hot** message is displayed.

🔍 **If the Engine oil pressure low Warning Appears** P. 498

🔍 **Overheating** P. 493

Switching the Display


Press the  (home) button, then roll the left selector wheel to scroll to the content you want to see. Press the left selector wheel to see detailed information.

Switching the Display

To go back to the home screen, press the  (home) button.

You can add or remove content from the driver information interface.

🔍 **Customize Display** P. 140




*1:Except Mexican models

*2:Mexican models

Range / Fuel / Trip Meter

Roll the left selector wheel to switch between trip meter A and trip meter B.



■ Trip meter

Shows the total number of kilometres driven since the last reset. Meters A and B can be used to measure two separate trips.

Resetting a trip meter

To reset the trip meter, display it, press the left selector wheel, and then select **Reset**.

- The trip meter is reset to 0.0.

■ Average Fuel Economy

Shows the estimated average fuel economy of each trip meter in km/l, l/100 km*, or mpg*.

The display is updated at set intervals. When a trip meter is reset, the average fuel economy is also reset.

■ Instant Fuel Economy

Shows the instant fuel economy as a bar graph in km/l, l/100 km*, or mpg*.

■ Range

Shows the estimated distance you can travel on the remaining fuel. This estimated distance is based on the vehicle's current fuel economy.

» Range / Fuel / Trip Meter

Except Mexican models

You can change the unit of fuel consumption in either km/l and l/100km.

➤ **Settings** P. 142

» Average Fuel Economy

You can change when to reset the average fuel economy.


➤ **Settings** P. 142

» Range

The driving range displayed is only an estimate and may differ from the actual distance the vehicle can travel.

■ Speed / Time / Trip Meter

Roll the left selector wheel to switch between trip meter A and trip meter B.



■ Trip meter

➤ **Trip meter** P. 136

■ Elapsed time

Shows the time elapsed since Trip A or Trip B was reset.

■ Average speed

Shows the average speed in km/h since Trip A or Trip B was reset.

■ Seat Belts*

Occurs, under specified conditions, when seat belts are latched or unlatched.

➤ **Seat Belt Reminder** P. 43

■ Oil Monitor System*

Show the oil monitor system.

➤ **Oil Monitor System*** P. 397

» Elapsed time

You can change when to reset the elapsed time.

➤ **Settings** P. 142

» Average speed

You can change when to reset the average speed.


➤ **Settings** P. 142

■ Safety Support*

Indicates the status of the Road Departure Mitigation system and CMBS, such as On, Off, or Failure, by colour and letters.

The following colours indicate the status of any of the above-mentioned systems:

- Green: The system is on.
- Grey: The system is off.
- Amber: There is a problem with the system.



☒ Safety Support*

If a system is indicated by the colour amber, have your vehicle checked by a dealer immediately.

To turn each system on or off, first press the left selector wheel to switch displays. From the next display, you can select which system to turn on or off.


- ☒ **Road Departure Mitigation System** P. 325
- ☒ **Collision Mitigation Braking System (CMBS)** P. 311

You can also confirm the status of each function by the colour of the indicator.


- ☒ **Collision Mitigation Braking System (CMBS) Indicator (Amber)*** P. 122
- ☒ **Road Departure Mitigation Indicator (Amber)*** P. 123
- ☒ **Safety Support Indicator (Amber)*** P. 124
- ☒ **Safety Support Indicator (Green/Grey)*** P. 126

■ Customize Display

You can choose which icons to display on the home screen.



1. Roll the left selector wheel until  is selected, then press the left selector wheel.
2. Roll the left selector wheel.



3. Roll the left selector wheel to scroll between icons, then press the left selector wheel to check or uncheck them.

» Customize Display

Icons that are grey cannot be removed from the home screen.

Continuously variable transmission models

When you customize settings, shift to **P**.

Manual transmission models

When you customize settings, set the parking brake.

■ Speed/Distance Units*

Enables you to show another unit on the driver information interface, and set the displayed measurements to read in either km and km/h or miles and mph.

Press and hold the left selector wheel when you select the  screen on the driver information interface. Each time you do this, the unit will change from km and km/h to miles and mph or vice versa. After this, a confirmation screen will appear for a few seconds.

■ Warnings

You can check if there are any active warning messages.

» Warnings

If there are multiple warnings, you can roll the left selector wheel to see other warnings.


* Not available on all models

■ Settings

Use the driver information interface to customize certain features.

■ How to customize

Press the  (home) button, then select the  screen by rolling the left selector wheel while the power mode is in ON, the vehicle is at a complete stop. Then, press the left selector wheel.



» Settings

To customize other features, roll the left selector wheel.

- **List of customizable options** P. 143
- **Example of customization settings** P. 153

Continuously variable transmission models

When you customize settings, shift to **[P]**.

Manual transmission models

When you customize settings, set the parking brake.

■ List of customizable options

Setup Group	Customizable Features	Description	Selectable Settings
Mexican models TPMS calibration	—	Initialises the deflation warning system.	Mexican models Calibrate/Cancel
Models for other countries Deflation warning system*	—		Models for other countries Initialise/Cancel
Clock setup	Adjust clock	Adjusts the time. ➡ Adjusting the Clock P. 180	—
	Clock display	Sets time display 24 hour, 12 hour or off.	24h/12h*¹/OFF

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Driver assist system setup*	Forward collision warning distance	Changes the distance at which Collision Mitigation Braking System (CMBS) alerts.	Long/Normal* ¹ /Short
	Preceding vehicle proximity warning distance		Far/Normal* ¹ /Near
	ACC forward vehicle detect beep	Causes the system to beep when a vehicle is detected or when the vehicle is out of ACC range.	ON/OFF* ¹
	ACC vehicle ahead detected beep		
	Lead car departure notification system	Changes the setting for the lead car departure notification system.	Normal* ¹ /Early/OFF

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Driver assist system setup*			Indian, Bhutanese and Nepalese models Early/Normal/Delayed*1
	Road departure mitigation setting	Changes the setting for the Road Departure Mitigation system.	Except Indian, Bhutanese and Nepalese models Narrow/Normal*1/Wide/Warning only Early/Normal*1/Delayed/Warning only
	Lane keeping assist suspend beep Lane keep assist beep	Causes the system to beep when the LKAS is suspended.	ON/OFF*1

*1:Default Setting

* Not available on all models

Setup Group	Customizable Features	Description	Selectable Settings
Meter setup	Language selection*	Changes the displayed language.	English/Français/Español* ¹
	Adjust outside temp. display	Adjusts the temperature reading by a few degrees.	-3°C ~ ±0°C* ¹ ~ +3°C
	"Trip A" reset timing	Changes the setting of how to reset trip meter A, average fuel economy A, average speed A, and elapsed time A.	When fully refueled/IGN OFF/ Manually reset* ¹ When fully refueled/When ignition is turned OFF/ Manual reset* ¹
	"Trip B" reset timing	Changes the setting of how to reset trip meter B, average fuel economy B, average speed B, and elapsed time B.	When fully refueled/IGN OFF/ Manually reset* ¹ When fully refueled/When ignition is turned OFF/ Manual reset* ¹

*1:Default Setting

* Not available on all models

Setup Group	Customizable Features	Description	Selectable Settings
Meter setup	Adjust alarm volume	Changes the alarm volume, such as buzzers, warnings, turn signal sound, and so on.	High/Mid^{*1}/Low
	Alarm volume control		Max/Mid^{*1}/Min
	Fuel efficiency backlight*	Turns the ambient meter feature on and off.	ON^{*1}/OFF
	Rear seat reminder	Turns the Rear Seat Reminder feature on and off.	ON^{*1}/OFF
	Speed/distance units*	Selects the speed/distance units.	mph·miles/km/h·km^{*1}
	Fuel economy unit*	Selects the fuel economy unit.	km/l, l/100km (The default setting varies depending on the model.)

*1:Default Setting

* Not available on all models

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Lighting setup	Auto high-beam* Auto High-Beam*	Turns the auto high-beam on and off.	ON*¹/OFF
	Interior light dimming time Interior light dimmer duration	Changes the length of time the interior lights stay on after you close the doors.	60sec/30sec*¹/15sec
	Headlight auto off timer Headlight auto OFF timer	Changes the length of time the exterior lights stay on after you close the driver's door.	60sec/30sec/15sec*¹/0sec
	Auto light sensitivity*	Changes the timing for the headlights to come on.	Max/High/Mid*¹/Low/Min

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Lighting setup	Auto interior illumination sensitivity	Changes the sensitivity of the brightness of the instrument panel when the headlight switch is in the AUTO position.	Max/High/Mid*1/Low/Min
	Instrument illumination sensitivity		
	Auto headlight ON with wiper ON	Changes the settings for the wiper operation when the headlights automatically come on while the headlight switch is in the AUTO position.	ON*1/OFF
	Headlight integration with wipers		

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Door setup	Auto door lock*	Changes the setting for when the doors automatically lock.	With vehicle speed*¹/Shift from P*²/OFF
	Auto door unlock*	Changes the setting for when the doors automatically unlock.	Shift to P*², *³/IGN OFF*⁴/OFF
	Key and remote unlock mode*	Sets up either the driver's door or all doors to unlock on the first operation of the keyless remote or built-in key.	Driver door*¹/All doors
	Walk away auto lock*	Changes the settings for the auto lock function when you walk away from the vehicle while carrying the keyless remote.	ON/OFF*¹
	Walk away lock*		

*1:Default Setting

*2:Continuously variable transmission models

*3:Default Setting for continuously variable transmission models

*4:Default Setting for manual transmission models

Setup Group	Customizable Features	Description	Selectable Settings
Door setup	Keyless lock answer back	LOCK/UNLOCK - The exterior lights flash.	ON*1/OFF
	Keyless lock notification	LOCK (2nd push) - The beeper sounds.	
	Security relock timer	Changes the time it takes for the doors to relock and the security system to set after you unlock the vehicle without opening any door.	90sec/60sec/30sec*1
	Auto folding door mirror*	Changes how you can fold the door mirrors.	Auto fold with keyless*1/ Manual only
Maintenance reset*	—	Resets the oil monitor system information*2/ maintenance reminder display*3 when you have performed the maintenance service.	Cancel/Reset
Default all	—	Cancels customized changes you have made or restores them to their default setting.	Cancel/Set Cancel/OK


*1:Default Setting

*2:Thai models


*3:Mexican models

■ Example of customization settings

The steps for changing the **"Trip A" reset timing** setting to **When fully refueled** are shown below. The default setting for **"Trip A" reset timing** is **Manually reset/Manual reset**.




1. Press the  (home) button and roll the left selector wheel to select , then press the left selector wheel.
2. Roll the left selector wheel until **Meter setup** appears on the display.
3. Press the left selector wheel.




4. Roll the left selector wheel until **"Trip A" reset timing** appears on the display, then press the left selector wheel.

- The display switches to the customization setup screen, where you can select **When fully refueled, IGN OFF/When ignition is turned OFF, Manually reset/Manual reset**, or **Back**.



5. Roll the left selector wheel and select **When Fully Refueled**, then press the left selector wheel.
 - The display will return to the customization menu screen.



6. Roll the left selector wheel until **Back** appears on the display, then press the left selector wheel.
7. Repeat Step 6 until you return to the normal screen.

Driver Information Interface (B-type meter) *

The driver information interface shows information such as the estimated travelable distance and fuel economy of the vehicle. It also displays messages such as warnings and other helpful information.

When a warning message displays, please check the message and contact a dealer to have the vehicle inspected if necessary. Please refer to the pages below if the

Engine Oil Pressure Low or **Engine Temperature Too Hot** message is displayed.

❏ **If the Engine oil pressure low Warning Appears** P. 498

❏ **Overheating** P. 493

Switching the Display


Press the  (home) button, then roll the left selector wheel to scroll to the content you want to see. Press the left selector wheel to see detailed information.

Switching the Display

To go back to the home screen, press the  (home) button.

You can add or remove content from the driver information interface.

❏ **Customize Display** P. 166



*1:Except Mexican models

*2:Mexican models

Tachometer

Shows the number of engine revolutions per minute and other contents will hide.

Mexican models

■ Speed/distance units

Enables you to show another unit on the driver information interface and set the displayed measurements to read in either kilometres and miles, km/h and mph.

Press and hold the left selector wheel when you select the **Tachometer** on the driver information interface. Each time you do this, the unit will change from kilometres, km/h to miles, mph or vice versa. After this, a confirmation screen will appear for a few seconds.

Tachometer

The tachometer can be turned on and off using **Settings**.



➤ **Settings** P. 167

Even if you have turned off the tachometer using **Settings**, if **Tachometer** is selected on the driver information interface, it will change to a tachometer-only display.

➤ **Switching the Display** P. 157


Range/Fuel/Trip Meter

Roll the left selector wheel to switch between trip meter A and trip meter B.



Left Selector Wheel

➔ Roll the left selector wheel.



■ Trip meter

Shows the total number of kilometres or miles* driven since the last reset. Meters A and B can be used to measure two separate trips.

Resetting a trip meter

To reset the trip meter, display it, press the left selector wheel, and then select **Reset**.

- The trip meter is reset to **0.0**.

■ Average fuel economy

Shows the estimated average fuel economy of each trip meter in km/l*, l/100 km* or mpg*.

The display is updated at set intervals. When a trip meter is reset, the average fuel economy is also reset.

■ Instant fuel economy

Shows the instant fuel economy as a bar graph in km/l*, l/100 km* or mpg*.

■ Range

Shows the estimated distance you can travel on the remaining fuel. This estimated distance is based on the vehicle's current fuel economy.

⌘ Average fuel economy

You can change when to reset the average fuel economy.

⌘ **Settings** P. 167


⌘ Range

The driving range displayed is only an estimate and may differ from the actual distance the vehicle can travel.

* Not available on all models


■ Speed/Time/Trip Meter

Roll the left selector wheel to switch between trip meter A and trip meter B.



Left Selector Wheel

➡ Roll the left selector wheel.



■ Trip meter

🔍 Trip meter P. 161

■ Elapsed Time

Shows the time elapsed since the last time Trip A or Trip B was reset.

■ Average Speed

Shows the average speed in km/h or mph* since the last time Trip A or Trip B was reset.

⌘ Elapsed Time

You can change when to reset the elapsed time.

🔍 Settings P. 167

⌘ Average Speed


You can change when to reset the average speed.

🔍 Settings P. 167

* Not available on all models

G-meter*

Displays the strength (G) and direction of the load that is applied to the vehicle during driving.



Seat Belts*

Occurs, under specified conditions, when seat belts are latched or unlatched.


➤ **Seat Belt Reminder** P. 43

Safety Support

Indicates the state of the Road Departure Mitigation system and CMBS, such as On, Off, or Failure, by colour and letters.

The following colours indicate the state of any of the above-mentioned systems:

- Green: The system is on.
- Grey: The system is off.
- Amber: There is a problem with the system.



Safety Support

If a system is indicated by the colour amber, have your vehicle checked by a dealer immediately.

To turn each system on or off, first rotate the left selector wheel to switch displays. From the next display, you can select which system to turn on or off.

➤ **Road Departure Mitigation System** P. 325

➤ **Collision Mitigation Braking System (CMBS)** P. 311

You can also confirm the state of each function by the colour of the indicator.

➤ **Collision Mitigation Braking System (CMBS) Indicator (Amber)*** P. 122

➤ **Collision Mitigation Braking System (CMBS) Indicator (Grey)*** P. 122

➤ **Road Departure Mitigation Indicator (Amber)*** P. 123

➤ **Road Departure Mitigation Indicator (Grey)*** P. 123



➤ **Road Departure Mitigation System Steering Assist Auto OFF Indicator*** P. 123

➤ **Safety Support Indicator (Amber)*** P. 124

➤ **Safety Support Indicator (Green/Grey)*** P. 126

■ Customize Display

You can choose which icons to display on the home screen.



1. Roll the left selector wheel until **Customize Display** is selected, then press the left selector wheel.
2. Roll the left selector wheel.
3. Roll the left selector wheel to scroll between icons, then press the left selector wheel to check or uncheck them.

■ Information*1/Warnings*2

You can check if there are any active warning messages.

*1: Except Mexican models

*2: Mexican models

» Customize Display

Icons that are grey cannot be removed from the home screen.

Continuously variable transmission models

When you customize settings, shift to **P**.

Manual transmission models

When you customize settings, set the parking brake.

» Information*1/Warnings*2


If there are multiple warnings or informations, you can roll the left selector wheel to see other warnings.

■ Settings

Use the driver information interface to customize certain features.

■ How to customize

Press the  (home) button, then select the  screen by rolling the left selector wheel while the power mode is in ON, the vehicle is at a complete stop. Then, press the left selector wheel.



⌘ Settings

To customize other features, roll the left selector wheel.

➤ **List of customizable options** P. 168

➤ **Example of customization settings** P. 177

Continuously variable transmission models

When you customize settings, shift to **P**.

Manual transmission models

When you customize settings, set the parking brake.

■ List of customizable options

Setup Group	Customizable Features	Description	Selectable Settings
Instrument Panel	Except Mexican models Deflation Warning System* Mexican models TPMS Calibration	— Initialises the deflation warning system.	Except Mexican models Initialise/Cancel Mexican models Calibrate/Cancel
	Clock Adjustment	Adjusts the time. ⚙ Adjusting the Clock P. 180	—
	Clock Setup Except Mexican models Clock Display Mexican models Clock Format	Sets time display 24 hour, 12 hour or off.	24h/12h*¹/OFF
	Driver Assist System Setup Except Mexican models Preceding Vehicle Proximity Warning Distance Mexican models Forward Collision Warning Distance	Changes the distance at which Collision Mitigation Braking System (CMBS) alerts.	Except Mexican models Far/Normal*¹/Near Mexican models Long/Normal*¹/Short

*1:Default Setting

* Not available on all models

Setup Group	Customizable Features	Description	Selectable Settings
Driver Assist System Setup	Except Mexican models ACC Vehicle Ahead Detected Beep Mexican models ACC Forward Vehicle Detect Beep	Causes the system to beep when a vehicle is detected or when the vehicle is out of ACC range.	ON/OFF * ¹
	Road Departure Mitigation Setting	Changes the setting for the Road Departure Mitigation system.	Indian, Bhutanese and Nepalese models Early/Normal/Delayed * ¹ Mexican models Narrow/Normal * ¹ / Wide/Warning Only Models for other countries Early/Normal * ¹ / Delayed/Warning Only * ²
	Except Mexican models Lane Keep Assist Beep Mexican models Lane Keeping Assist Suspend Beep	Causes the system to beep when the LKAS is suspended.	ON/OFF * ¹
	Lead Car Departure Notification System*	Changes the setting for the lead car departure notification system.	Normal * ¹ / Early/OFF

*1:Default Setting

*2:Indian, Bhutanese and Nepalese models

* Not available on all models

Setup Group	Customizable Features	Description	Selectable Settings
Meter Setup	Mexican models Language Selection	Changes the displayed language.	Mexican models English/Français/Español * ¹
	Middle Eastern models Language		Middle Eastern models ENGLISH/Arabic * ¹
	Adjust Outside Temp. Display	Adjusts the temperature reading by a few degrees.	-3°C ~ ±0°C*¹ ~ +3°C
	"Trip A" Reset Timing	Changes the setting of how to reset trip meter A, average fuel economy A, average speed A, and elapsed time A.	Except Mexican models When Fully Refueled/When Ignition Is Turned OFF/Manual Reset * ¹
	"Trip B" Reset Timing	Changes the setting of how to reset trip meter B, average fuel economy B, average speed B, and elapsed time B.	Mexican models When Fully Refueled/IGN OFF/Manually Reset * ¹
			Except Mexican models When Fully Refueled/When Ignition Is Turned OFF/Manual Reset * ¹
			Mexican models When Fully Refueled/IGN OFF/Manually Reset * ¹

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Meter Setup	Except Mexican models Alarm Volume Control	Changes the alarm volume, such as buzzers, warnings, turn signal sound, and so on.	Except Mexican models Max/Mid^{*1}/Min
	Mexican models Adjust Alarm Volume		Mexican models High/Mid^{*1}/Low
	Fuel Efficiency Backlight*	Turns the ambient meter feature on and off.	ON^{*1}/OFF
	Rear Seat Reminder	Turns the Rear Seat Reminder feature on and off.	ON^{*1}/OFF
	Speed/Distance Units*	Selects the speed/distance units.	km/h·km^{*1}/mph·miles
	Tachometer	Selects whether the tachometer is displayed on the driver information interface.	ON^{*1}/OFF

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Keyless Access Setup	Door Unlock Mode*	Changes which doors unlock when you grab the driver's door handle.	Driver Door Only* ¹ /All Doors
	Keyless Access Beep Volume	Changes the beep tone that sounds when you have a keyless remote and grab a front door handle.	High* ¹ /Low
	Keyless Access Light Flash*	Causes some exterior lights to flash when you unlock/lock the doors.	ON* ¹ /OFF
	Keyless Access Beep	Causes the beeper to sound when you unlock/lock the doors.	ON* ¹ /OFF
	Remote Start System ON/OFF*	Turns the remote engine start feature on and off.	ON* ¹ /OFF

*1:Default Setting

* Not available on all models

Setup Group	Customizable Features	Description	Selectable Settings
Lighting Setup	Auto High-Beam	Turns the auto high-beam on and off.	ON^{*1}/OFF
	Except Mexican models Interior Light Dimmer Duration	Changes the length of time the interior lights stay on after you close the doors.	60sec/30sec^{*1}/15sec
	Mexican models Interior Light Dimming Time		
	Headlight Auto OFF Timer	Changes the length of time the exterior lights stay on after you close the driver's door.	60sec/30sec/15sec^{*1}/0sec
	Auto Light Sensitivity*	Changes the timing for the headlights to come on.	Max/High/Mid^{*1}/Low/Min
	Except Mexican models Instrument Illumination Sensitivity	Changes the sensitivity of the brightness of the instrument panel when the headlight switch is in the AUTO position.	Max/High/Mid^{*1}/Low/Min
	Mexican models Auto Interior Illumination Sensitivity		

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Lighting Setup	Except Mexican models Headlight Integration With Wipers	Changes the settings for the wiper operation when the headlights automatically come on while the headlight switch is in the AUTO position.	ON *1/ OFF
	Mexican models Auto Headlight ON With Wiper ON		

*1:Default Setting

Setup Group	Customizable Features	Description	Selectable Settings
Door Setup	Auto Door Lock *	Changes the setting for when the doors automatically lock.	With Vehicle Speed * ¹ / Shift From P * ² / OFF
	Auto Door Unlock *	Changes the setting for when the doors automatically unlock.	Shift To P * ² , * ³ / IGN OFF * ⁴ / OFF
	Key And Remote Unlock Mode *	Sets up either the driver's door or all doors to unlock on the first operation of the keyless remote.	Driver Door Only * ¹ / All Doors
	Except Mexican models Walk Away Lock Mexican models Walk Away Auto Lock	Changes the settings for the auto lock function when you walk away from the vehicle while carrying the keyless remote.	ON/OFF * ¹

*1:Default Setting

*2:Continuously variable transmission models

*3:Default Setting for continuously variable transmission



*4:Default Setting for manual transmission

Setup Group	Customizable Features	Description	Selectable Settings
Door Setup	Except Mexican models Keyless Lock Notification Mexican models Keyless Lock Answer Back	LOCK/UNLOCK - The exterior lights flash. LOCK (2nd push) - The beeper sounds.	ON ^{*1} /OFF
	Security Relock Timer	Changes the time it takes for the doors to relock and the security system to set after you unlock the vehicle without opening any door.	90sec/60sec/30sec ^{*1}
	Auto Folding Door Mirror*	Changes how you can fold the door mirrors.	Auto Fold With Keyless ^{*1} / Manual Only
Maintenance Reset*		Resets the maintenance reminder display when you have performed the maintenance service.	Cancel/Reset
Default All	—	Cancels customized changes you have made or restores them to their default setting.	Except Mexican models Cancel/OK Mexican models Cancel/Set

*1:Default Setting

■ Example of customization settings



The steps for changing the **"Trip A" Reset Timing** setting to **When Fully Refueled** are shown below. The default setting for **"Trip A" Reset Timing** is **Manual Reset***¹/**Manually Reset***².



1. Press the  (home) button and roll the left selector wheel to select , then press the left selector wheel.
2. Roll the left selector wheel until **Meter Setup** appears on the display.
3. Press the left selector wheel.

*1: Except Mexican models

*2: Mexican models



4. Roll the left selector wheel until **"Trip A" Reset Timing** appears on the display, then press the left selector wheel.

► The display switches to the customization setup screen, where you can select **When Fully Refueled**, **When Ignition Is Turned OFF^{*1}/IGN OFF^{*2}**, **Manual Reset^{*1}/Manually Reset^{*2}**, or **Back**.

5. Roll the left selector wheel and select **When Fully Refueled**, then press the left selector wheel.

► The display will return to the customization menu screen.

6. Roll the left selector wheel until **Back** appears on the display, then press the left selector wheel.

7. Repeat Step 6 until you return to the normal screen.

*1: Except Mexican models

*2: Mexican models

Controls

This chapter explains how to operate the various controls necessary for driving.

Clock	180
Locking and Unlocking the Doors	
Key	183
Locking/Unlocking the Doors from the Outside	185
Locking/Unlocking the Doors from the Inside	192
Childproof Door Locks	193
Auto Door Locking/Unlocking*	194
Opening and Closing the Boot	195
Security System	
Immobilizer System	198
Security System Alarm	199
Windows	202

Sunroof*	207
Operating the Switches Around the Steering Wheel	
ENGINE START/STOP Button	209
Turn Signals	212
Light Switches	213
Rear Fog Light*	217
Headlight Adjuster*	218
Auto High-Beam*	219
Daytime Running Lights	222
Wipers and Washers	223
Brightness Control	226
Rear Demister Button	228
Adjusting the Steering Wheel	229


Mirrors	
Interior Rearview Mirror	230
Power Door Mirrors	231
Seats	
Front Seats	233
Armrest*	241
Interior Convenience Items	242
Heating* and Cooling System*	
Using Vents, Heating* and A/C	254
Climate Control System*	
Using Automatic Climate Control	259
Automatic Climate Control Sensors ...	263

* Not available on all models

Adjusting the Clock




You can adjust the time in the clock display when the power mode is in ON.

■ Adjusting the Time



Models with information display

1. Press the **TRIP/CLOCK** button repeatedly until the displayed time begins flashing.
2. Press and hold the **TRIP/CLOCK** button to change the setting between 12h and 24h, or to turn off the clock.
3. Press the **+** or **-** button to adjust the minutes.
As you increase or decrease the minutes, the hour moves forward or backward.
4. Press the **TRIP/CLOCK** button to complete clock adjustment.



Models with driver information interface (A-type meter)

1. Select the **Settings** screen.
 ➤ **Settings** P. 142
2. Roll the left selector wheel to select **Clock setup**, then push the left selector wheel.

3. Roll the left selector wheel until **Adjust clock** appears on the display.
4. Push the left selector wheel.




5. Roll the left selector wheel to change hour, then push the left selector wheel.
6. Roll the left selector wheel to change minute, then push the left selector wheel.
7. Press the  button to return to the normal screen.

Adjusting the Time

Models with driver information interface

You can customize the clock display to show the 12 hour clock or 24 hour clock.

➤ **Settings** P. 142, 167




Models with driver information interface (B-type meter)

1. Select the **Settings** screen.
 ■ **Settings** P. 167
2. Roll the left selector wheel to select **Clock Setup**, then push the left selector wheel.
3. Roll the left selector wheel until **Clock Adjustment** appears on the display.
4. Push the left selector wheel.
5. Roll the left selector wheel to change hour, then push the left selector wheel.
6. Roll the left selector wheel to change minute, then push the left selector wheel.
7. Press the  button to return to the normal screen.

Locking and Unlocking the Doors


Key

This vehicle comes with the following keys:



Use the key to start and stop the engine, lock and unlock all the doors, and open the boot.

Built-in Key



The built-in key can be used to lock/unlock the doors when the keyless remote battery becomes weak and the power door lock/unlock operation is disabled.

To remove the built-in key, slide the release knob and then pull out the key. To reinstall the built-in key, push the built-in key into the keyless remote until it clicks.

Key

All the keys have an immobilizer system. The immobilizer system helps to protect against vehicle theft.

➤ **Immobilizer System** P. 198

Follow the advice below to prevent damage to the keys:

- Do not leave the keys in direct sunlight, or in locations with high temperature or high humidity.
- Do not drop the keys or set heavy objects on them.
- Keep the keys away from liquids, dust, and sand.
- Do not take the keys apart except to replace the battery.

If the circuits in the keys are damaged, the engine may not start, and the remote transmitter may not work.

If the keys do not work properly, have them inspected by a dealer.


Models with remote engine start

You can remotely start the engine using the remote engine start.

➤ **Remote Engine Start*** P. 274

* Not available on all models

■ Key Number Tag



Contains a number that you will need if you purchase a replacement key.

Low Keyless Remote Signal Strength

The vehicle transmits radio waves to locate the keyless remote to start the engine; lock and unlock* the doors; and open* the boot.

In the following cases, starting the engine and locking/unlocking* the doors, or opening* the boot may be inhibited, or operation may be unstable:

- Strong radio waves are being transmitted by nearby equipment.
- You are carrying the keyless remote together with telecommunications equipment, laptop computers, mobile phones, or wireless devices.
- A metallic object is touching or covering the keyless remote.

►► Key Number Tag

Keep the key number tag separate from the key in a safe place outside of your vehicle.

If you wish to purchase an additional key, contact a dealer.

If you lose your key and you cannot start the engine, contact a dealer.

►► Low Keyless Remote Signal Strength

Communication between the keyless remote and the vehicle consumes the keyless remote's battery. Battery life is about two years, but this varies depending on regularity of use.

The battery is consumed whenever the keyless remote is receiving strong radio waves. Avoid placing it near electrical appliances such as televisions and personal computers.


Except Mexican models

It is possible to reduce battery consumption by turning off radio wave reception. When you hold down the lock and unlock buttons at the same time for approximately three seconds, the LED will blink twice and radio wave reception will turn off.

If you press any button on the keyless remote once, it will begin receiving radio waves again.


Locking/Unlocking the Doors from the Outside

■ Using the Keyless Access System *



When you carry the keyless remote, you can lock/unlock the doors and open the boot.

You can lock/unlock the doors or open the boot within a radius of about 80 cm from the outside door handle or boot release button.



■ Locking the doors and boot

Press the door lock button on the front door.

- Some exterior lights flash; the beeper sounds; all the doors and the boot lock; and the security system sets.

► Locking/Unlocking the Doors from the Outside

If the interior light switch is in the door activated position, the interior light comes on when you unlock the doors.

No doors opened: The light fades out after 30 seconds.

Doors relocked with the remote: The light goes off immediately.

► Interior Lights P. 242


► Using the Keyless Access System *

If you do not open a door within 30 seconds of unlocking the vehicle with the keyless access system, the doors will automatically relock.

You can lock or unlock doors using the keyless access system only when the power mode is in VEHICLE OFF.

The keyless access system will not lock the vehicle when a door is open.

* Not available on all models



■ Unlocking the doors and boot

Mexican models

Grab the driver's door handle:

- The driver's door unlocks.
- Some exterior lights flash twice and the beeper sounds twice.

Grab the front passenger's door handle:

- All doors unlock.
- Some exterior lights flash twice and the beeper sounds twice.

Except Mexican models


Grab the front door handle:

- All the doors and the boot unlock.
- Some exterior lights flash twice and the beeper sounds twice.

Press the boot release button:

- The boot unlocks and opens.
- Some exterior lights flash twice and the beeper sounds.

➤ **Using the Boot Release Button*** P. 196




►► Using the Keyless Access System*

- Do not leave the keyless remote in the vehicle when you get out. Carry it with you.
- Even if you are not carrying the keyless remote, you can lock/unlock the doors while someone else with the remote is within range.
- The door may be unlocked if the door handle is covered with water in heavy rain or in a carwash if the keyless remote is within range.
- If you grip a front door handle wearing gloves, the door sensor may be slow to respond or may not respond by unlocking the doors.
- After locking the door, you have up to 2 seconds during which you can pull the door handle to confirm whether the door is locked. If you need to unlock the door immediately after locking it, wait at least 2 seconds before gripping the handle, otherwise the door will not unlock.
- The door may not open if you pull it immediately after gripping the door handle. Grip the handle again and confirm that the door is unlocked before pulling the handle.
- Even within the 80 cm radius, you may not be able to lock/unlock the doors with the keyless remote if it is above or below the outside handle.
- The keyless remote may not operate if it is too close to the door and door glass.

Models with driver information interface

The light flash*, beep, and door unlock mode* settings can be customized using the driver information interface.

➤ **Settings** P. 142, 167



■ Locking the doors and boot (Walk away auto lock*)

When you walk away from the vehicle with all doors closed while carrying the keyless remote, the doors will automatically lock. The auto lock function activates when all doors are closed, and the keyless remote is within about 1.5 m radius of the outside door handle or boot release button.

Exit the vehicle while carrying the keyless remote and close the door(s).

1. While within about 1.5 m radius of the vehicle.
 - The beeper sounds; the auto lock function will be activated.
2. Carry the keyless remote beyond about 1.5 m from the vehicle and remain outside this range for 2 or more seconds.
 - Some exterior lights flash; the beeper sounds; all doors will then lock.

▣ Locking the doors and boot (Walk away auto lock*)

The auto lock function is set to OFF as the factory default setting. The auto lock function can be set to ON using the driver information interface. If you set the auto lock function to ON using the driver information interface, only the remote transmitter that was used to unlock the driver's door prior to the setting change can activate auto lock.

► Settings P. 142, 167

After the auto lock function has been activated, when you stay within the locking/unlocking operation range, the indicator on the keyless remote will continue to flash until the doors are locked.

When you stay beside the vehicle within the operation range, the doors will automatically lock approximately 30 seconds after the auto lock function activating beeper sounds.

When you open a door after the auto lock function activating beeper sounds, the auto lock function will be cancelled.

Under the following circumstances, the auto lock function will not activate:

- The keyless remote is inside the vehicle.
 - The beeper will not sound.
- The keyless remote is taken out of its operational range before all the doors are closed.
 - The beeper will sound.

To temporarily deactivate the function:

1. Set the power mode to OFF.
2. Open the driver's door.
3. Using the master door lock switch, operate the lock as follows:
Lock→Unlock→Lock→Unlock.
► The beeper sounds, and the function is deactivated.

To restore the function (any step below):

- Set the power mode to ON.
- Lock the vehicle without using the auto lock function.
- With the keyless remote on you, move out of the auto lock function operation range.
- Open any door.

►► Locking the doors and boot (Walk away auto lock*)

The auto lock function does not operate when any of the following conditions are met.

- The keyless remote is inside the vehicle.
- A door or the bonnet is not closed.
- The power mode is set to any mode other than OFF.
- The keyless remote is not located within a radius of about 1.5 m from the vehicle when you get out of the vehicle and close the doors.


Auto lock function operation stop beeper

After the auto lock function has been activated, the auto lock operation stop beeper sounds for approximately two seconds in the following cases.

- The keyless remote is put inside the vehicle through a window.
- You are located too close to the vehicle.
- The keyless remote is put inside the boot.

If the warning beeper sounds, check that you are carrying the keyless remote. Then, open/close a door and confirm the auto lock activation beeper sounds once.

■ Using the Remote Transmitter



■ Locking the doors

Press the lock button.

Once:

- Some exterior lights flash, all the doors lock, and the security system sets.

Twice (within five seconds after the first push):

- The beeper sounds and verifies the security system is set.

■ Unlocking the doors

Mexican models

Press the unlock button.

Once:

- Some exterior lights flash twice, and the driver's door unlocks.

Twice:

- The remaining doors unlock.

Except Mexican models

Press the unlock button.

- Some exterior lights flash twice, and all doors unlock.

► Using the Remote Transmitter

If you do not open a door within 30 seconds of unlocking the vehicle with the remote transmitter, the doors will automatically relock.

Models with driver information interface

You can change the relock timer setting.

► **Settings** P. 142, 167

You can lock or unlock doors using the remote transmitter only when the power mode is in VEHICLE OFF.

The remote transmitter uses low-power signals, so the operating range may vary depending on the surroundings.


The remote will not lock the vehicle when a door is open.

If the distance at which the remote transmitter works varies, the battery is probably low. Replace the button battery as soon as possible when this occurs. If the LED does not come on when you press a button, the battery is dead.

► **Replacing the Remote Battery** P. 450

■ Locking/Unlocking the Doors Using a Key

If the lock or unlock button of the keyless remote does not work, use the key instead.



Fully insert the key and turn it.

►► Locking/Unlocking the Doors Using a Key

Except Mexican models

When you lock/unlock the driver's door with the key, all the other doors lock/unlock at the same time.

Mexican models

When you lock the driver's door with the key, all the other doors lock at the same time.

When unlocking, the driver's door unlocks first.

Turning the key a second time within a few seconds does not unlock the remaining doors.

All models

If you unlock a door with the built-in key while the security system is activated, the alarm will sound.


Mexican models with driver information interface

You can customize the door unlock mode setting.

➤ **Settings** P. 142, 167

■ Locking a Door Without Using a Key

If you do not have the key on you, or if for some reason you cannot lock a door using the key, you can lock the door without it.



■ Locking the driver's door

Push the lock tab forward ① or push the master door lock switch in the lock direction ②, then pull and hold the outside door handle ③. Close the door, then release the handle.

■ Locking the passenger's doors

Push the lock tab forward and close the door.

■ Lockout prevention system

The doors cannot be locked when the keyless remote is inside the vehicle.


► Locking a Door Without Using a Key

When you lock the driver's door, all the other doors lock at the same time.

Before locking a door, make sure that the key is not inside the vehicle.

Locking/Unlocking the Doors from the Inside

■ Using the Lock Tab




■ Locking a door

Push the lock tab forward.

■ Unlocking a door

Pull the lock tab rearward.

■ Unlocking Using the Front Door Inner Handle



■ Except Latin American models

Pull the driver's door inner handle.

- The door unlocks and opens in one motion.

■ Latin American models

Pull the front door inner handle.

- The door unlocks and opens in one motion.

►► Using the Lock Tab

■ Except Mexican models

When you lock/unlock the door using the lock tab on the driver's door, all the other doors lock/unlock at the same time.

■ Mexican models

When you lock the door using the lock tab on the driver's door, all the other doors lock at the same time.

When you unlock the door using the lock tab on the driver's door, only the driver's door will unlock.

►► Unlocking Using the Front Door Inner Handle

■ Except Latin American models

The driver's door inner handle are designed to allow the driver to open the door in one motion. However, this feature requires that the driver never pull the door inner handle while the vehicle is in motion.


■ Latin American models

The front door inner handles are designed to allow front seat occupants to open the door in one motion. However, this feature requires that front seat occupants never pull a front door inner handle while the vehicle is in motion.

Children should always ride in a rear seat where childproof door locks are provided.

► **Childproof Door Locks** P. 193

■ Using the Master Door Lock Switch




Press the master door lock switch in as shown to lock or unlock all the doors.

Childproof Door Locks

The childproof door locks prevent the rear doors from being opened from the inside regardless of the position of the lock tab.

■ Setting the Childproof Door Locks



Slide the lever in the rear door to the lock position, and close the door.

■ When opening the door

Open the door using the outside door handle.

☒ Using the Master Door Lock Switch

When you lock/unlock the driver's door using the master door lock switch, all the other doors lock/unlock at the same time.

☒ Childproof Door Locks

To open the door from the inside when the childproof door lock is on, put the lock tab in the unlock position, lower the rear window, put your hand out of the window, and pull the outside door handle.

Auto Door Locking/Unlocking *

Your vehicle locks or unlocks all doors automatically when a certain condition is met.

■ Auto Door Locking

■ Drive lock mode

All doors lock when the vehicle's speed reaches about 15 km/h.

■ Auto Door Unlocking

Continuously variable transmission models

■ Park unlock mode

All doors unlock when the transmission is put into **P** with the brake pedal depressed.

Manual transmission models

■ Power mode unlock mode

All door unlock when the power mode is out of ON.

►► Auto Door Locking/Unlocking *

You can turn off or change to another auto door locking/unlocking setting using the driver information interface.

► **Settings** P. 142, 167

Precautions for Opening/Closing the Boot

■ Opening the boot

Open the boot all the way.

- ▶ If it is not fully opened, the boot lid may begin to close under its own weight.


■ Closing the boot

Keep the boot lid closed while driving to:

- ▶ Avoid possible damage.
- ▶ Prevent exhaust gas from leaking into the vehicle.


☒ **Exhaust Gas Hazard** P. 99

Using the Boot Opener



Pulling the boot opener on the outside of the driver's seat unlocks and opens the boot.

Using the Boot Release Button *



Push up the release button on the boot lid after the doors are unlocked.

Models with keyless access system

Even if the boot is locked, you can open the boot if you carry the keyless remote.


- Some exterior lights flash twice and the beeper sounds once.

►► Using the Boot Release Button *

Models with keyless access system

- If you forget the keyless remote inside, the beeper will sound and the boot will not close.
- A person who is not carrying the keyless remote can unlock the boot if a person who is carrying it is within range.
- If the beeper sounds after you close the boot, move the keyless remote away from the boot and close again.
- The keyless remote may not operate if it is too close to the boot.

Using the Remote Transmitter



Press the boot release button for approximately one second to unlock and open the boot.

►► Using the Remote Transmitter

If the driver's door is locked, the boot will automatically lock when you close it. Otherwise, you will have to lock it manually.

Immobilizer System

This system prevents a key that has not been pre-registered from starting the engine.

Pay attention to the following when pressing the **ENGINE START/STOP** button:

- Do not allow objects that emit strong radio waves near the **ENGINE START/STOP** button.
- Make sure the key is not covered by or touching a metal object.
- Do not bring a key from another vehicle's immobilizer system near the **ENGINE START/STOP** button.
- Do not put the key near magnetic items. Electronic devices, such as televisions and audio systems, emit strong magnetic fields. Note that even a key chain can become magnetic.

» Immobilizer System

NOTICE

Leaving the key in the vehicle can result in theft or accidental movement of the vehicle. Always take the key with you whenever you leave the vehicle unattended.

Do not alter the system or add other devices to it. Doing so may damage the system and make your vehicle inoperable.

If the system repeatedly does not recognise the coding of your key, contact a dealer. If you have lost your key and cannot start your vehicle, contact a dealer.

Security System Alarm

The security system alarm activates when the boot, bonnet, or doors are forcibly opened. The alarm does not activate if the boot or doors are opened with the remote transmitter or keyless access system*.

■ When the security system alarm activates

The horn sounds intermittently, and some exterior lights flash.

» Security System Alarm

Do not alter the system or add other devices to it. Doing so may damage the system and make your vehicle inoperable.

Mexican models

The security system alarm continues for a maximum of two minutes until the security system alarm deactivates.

Except Mexican models

The security system alarm will continue for approximately 5 minutes before the security system deactivates.

The system will go through ten 30-second cycles, during which the horn will sound and an emergency indicator will flash.

Depending on circumstances, the security system may continue operating for more than 5 minutes.

* Not available on all models

■ To deactivate the security system alarm

Unlock the vehicle using the remote transmitter or keyless access system*, or set the power mode to ON. The system, along with the horn and flashing lights, is deactivated.

■ Setting the security system alarm

The security system alarm automatically sets when the following conditions have been met:

- The power mode is set to VEHICLE OFF.
- The bonnet is closed.
- All doors are locked from outside with the key, remote transmitter, or keyless access system*.

■ When the security system alarm sets

The security system alarm indicator in the instrument panel blinks and the blinking interval changes after about 15 seconds.

■ To cancel the security system alarm

The security system alarm is cancelled when the vehicle is unlocked using the remote transmitter or keyless access system*, or when the power mode is set to ON. The security system alarm indicator goes off at the same time.

►► Security System Alarm

Do not set the security system alarm when someone is in the vehicle or a window is open. The system can accidentally activate when:

- Unlocking the door with the lock tab.
- Opening the boot with the boot opener.
- Opening the bonnet with the bonnet release.

Mexican models


- Taking the transmission out of **P**.

If the battery goes dead after you have set the security system alarm, the security alarm may sound once the battery is recharged or replaced.

If this occurs, deactivate the security system alarm by unlocking a door using the remote transmitter or keyless access system*.

If you unlock a door with the built-in key while the security system is activated, the alarm will sound.

■ Panic Mode*



■ The panic button on the remote transmitter

If you press the panic button for approximately one second, the following will occur for about 30 seconds:

- The horn sounds.
- Some exterior lights flash.

■ Cancelling panic mode

- Press any button on the remote transmitter.
- Set the power mode to ON.

* Not available on all models

Opening/Closing the Power Windows

The power windows can be opened and closed when the power mode is in ON, using the switches on the doors.

The driver's side switches can be used to open and close all of the windows. The power window lock button on the driver's side must be switched off to open and close the windows from anywhere other than the driver's seat.

When the power window lock button is pushed in, the indicator comes on and you can only operate the driver's window. Turn the power window lock button on if a child is in the vehicle.

» Opening/Closing the Power Windows

WARNING

Closing a power window on someone's hands or fingers can cause serious injury.


Make sure your passengers are away from the windows before closing them.

WARNING: Always take the ignition key with you whenever you leave the vehicle alone or with other occupants.

Models with power window auto-open/close function on all windows

The power windows can be operated for up to 10 minutes after you set the power mode to VEHICLE OFF. Closing driver's door cancels this function.

■ Opening/Closing the Windows with Auto-Open/Close Function



■ Manual operation

To open: Push the switch down lightly, and hold it until the desired position is reached.

To close: Pull the switch up lightly, and hold it until the desired position is reached.

■ Automatic operation

To open: Push the switch down firmly.

To close: Pull the switch up firmly.

The window opens or closes completely. To stop the window at any time, push or pull the switch briefly.

☒ Opening/Closing the Power Windows

Auto Reverse


If a power window senses resistance when closing automatically, it will stop closing and reverse direction.

The driver's window auto reverse function is disabled when you continuously pull up the switch.

The auto reverse function stops sensing when the window is almost closed to ensure that it fully closes.

* Not available on all models

■ Opening/Closing Windows without Auto-Open/Close Function*




To open: Push the switch down.

To close: Pull the switch up.

Release the switch when the window reaches the desired position.

■ Opening/Closing the Windows with the Remote*



To open: Press the unlock button, and then within 10 seconds, press it again and hold it.

To close: Press the lock button, and then within 10 seconds, press it again and hold it.


If the windows stop midway, repeat the procedure.

☒ Opening/Closing the Windows with the Remote*

If you open/close the windows with the remote, the sunroof will open/close automatically along with them.

* Not available on all models

■ Closing the Windows with the Key*



Lock the driver's door with the key. Within 10 seconds of returning the key to the central position, turn the key in the lock direction and hold it there.

Release the key to stop the windows at the desired position. If you want further adjustment, repeat the same operation.


» Closing the Windows with the Key*

If you close the windows with the key, the sunroof will close automatically along with them.

Opening/Closing the Sunroof

You can operate the sunroof when the power mode is in ON. Use the switch in the front of the ceiling to open and close the sunroof.

■ Using the Sunroof Switch



■ Automatic operation

To open: Pull the switch back firmly.

To close: Push the switch forward firmly.

The sunroof will automatically open or close all the way. To stop the sunroof midway, touch the switch briefly.

■ Manual operation

To open: Pull the switch back lightly, and hold it until the desired position is reached.

To close: Push the switch forward lightly, and hold it until the desired position is reached.

■ Tilting the sunroof up

To tilt: Push on the centre of the sunroof switch.

To close: Push the switch forward firmly, then release.

☒ Sunroof*

⚠ WARNING

Opening or closing the sunroof on someone's hands or fingers can cause serious injury.

Make sure all hands and fingers are clear of the sunroof before opening or closing it.

WARNING: Always take the ignition key with you whenever you leave the vehicle alone or with other occupants.

NOTICE

Opening the sunroof in below freezing temperature or when it is covered with snow or ice can damage the sunroof panel or motor.

Models with power window auto-open/close function on all windows

The sunroof can be operated for up to 10 minutes after you set the power mode to VEHICLE OFF. Closing driver's door cancels this function.

When resistance is detected, the auto reverse function causes the sunroof to change directions, then stop. Auto reverse stops sensing when the sunroof is almost closed to ensure that it fully closes. Make sure that all objects, including fingers, are clear of the sunroof.

» Sunroof*


You can use the remote transmitter or the key to operate the sunroof*.

▣ **Opening/Closing the Windows with the Remote*** P. 205

▣ **Closing the Windows with the Key*** P. 206

ENGINE START/STOP Button


Changing the Power Mode



ENGINE START/STOP Button

ENGINE START/STOP Button Operating Range

You can start the engine when the keyless remote is inside the vehicle.



If the battery of the keyless remote is getting low, the engine may not start when you push the **ENGINE START/STOP** button. If the engine does not start, refer to the following link.

➡ **If the Keyless Remote Battery is Weak**
P. 485

The engine may also run if the keyless remote is close to the door or window, even if it is outside the vehicle.

ON mode:
The **ENGINE START/STOP** button is on (in red), if the engine is running.

■ Automatic Power Off

If you leave the vehicle for 30 to 60 minutes with the transmission in **P** (continuously variable transmission) and the power mode in ACCESSORY, the vehicle automatically goes into the mode similar to VEHICLE OFF (LOCK) to avoid draining the battery.

When in this mode:

The steering wheel does not lock. You cannot lock or unlock doors with the remote transmitter or the keyless access system*.

Press the **ENGINE START/STOP** button twice to switch the mode to VEHICLE OFF (LOCK).

■ Power Mode Reminder

If you open the driver's door when the power mode is set to ACCESSORY, a warning beep sounds.


» ENGINE START/STOP Button

If the power mode does not change from VEHICLE OFF to ACCESSORY, press the **ENGINE START/STOP** button while moving the steering wheel left and right. The steering wheel will unlock, allowing the mode to change.

Do not leave the power mode in ACCESSORY or ON when you get out.

■ Keyless Remote Reminder

Models with information display



Models with driver information interface (A-type meter)



Keyless remote not detected

Models with driver information interface (B-type meter)



Keyless Remote Not Detected

When the power mode is set to any mode other than OFF and you remove the keyless remote from the vehicle and shut the door, an alarm will sound. If the alarm continues to sound, place the keyless remote in another location.

■ When the power mode is in **ACCESSORY**

The alarm will sound from outside the vehicle.

■ When the power mode is in **ON**

An alarm will sound both inside and outside the vehicle. In addition, a warning indicator will appear on the instrument panel.

⌘ Keyless Remote Reminder


When the keyless remote is within the system's operational range, and the driver's door is closed, the warning function cancels.

If the keyless remote is taken out of the vehicle after the engine has been started, you can no longer change the power mode or restart the engine. Always make sure that the remote is in your vehicle when you operate the **ENGINE START/STOP** button.

Removing the keyless remote from the vehicle through a window does not activate the warning buzzer.

Do not put the keyless remote on the dashboard or in the glove box. It may cause the warning buzzer to sound. Under some other conditions that can prevent the vehicle from locating the remote, the warning buzzer may also sound even if the remote is within the system's operational range.

Turn Signals



The turn signals can be used when the power mode is in ON.

■ (A): Turn signal

Push the lever up or down based on the direction you want to turn, and the turn signal will blink.

■ (B): One-touch turn signal

When you lightly push the lever up or down and release it, the turn signal will blink 3 times.

- If you lightly push the lever in the opposite direction while it is blinking, the blinking will stop.


►► Turn Signals

The turn signal indicator on the instrument panel will blink when the external turn signal blinks.

► Indicators P. 102

Light Switches

Manual Operation



Rotating the light switch turns the lights on and off, regardless of the power mode setting.

■ High beams

Push the lever forward until you hear a click.

■ Low beams

When in high beams, pull the lever back to return to low beams.

■ Flashing the high beams

Pull the lever back, and release it.

■ Lights off*

Turn the lever to **OFF** either when:

- The transmission is in **P** (Continuously Variable Transmission models).
- The parking brake is applied.

To turn the lights on again, turn the lever to OFF to cancel the lights off mode. Even if you do not cancel the lights off mode, the lights come on automatically when:

- The transmission is taken out of **P** (Continuously Variable Transmission models) and the parking brake is released.
- The vehicle starts to move.

Light Switches

If you leave the power mode in VEHICLE OFF while the lights are on, a chime sounds when the driver's door is opened.

When the lights are on, the lights on indicator in the instrument panel will be on.

► **Indicators** P. 102


Do not leave the lights on when the engine is off because it will cause the battery to discharge.

Models without headlight adjuster


If you suspect that the headlights are not positioned properly, have the vehicle inspected by a dealer.

■ Automatic Operation (automatic lighting control)

Except Mexican models



Mexican models



Automatic lighting control can be used when the power mode is in ON.

Except Mexican models

When the light switch is in **AUTO**, the headlights and other exterior lights will switch on and off automatically depending on the ambient brightness.

Mexican models

When you turn the light switch to **AUTO**, the headlights and other exterior lights will switch on and off automatically depending on the ambient brightness.

All models

The headlights come on when you unlock a door in dark areas with the headlight switch in **AUTO**.

- Once you lock the door, the headlights will go off.


►► Automatic Operation (automatic lighting control)

We recommend that you turn on the lights manually when driving at night, in a dense fog, or in dark areas such as long tunnels or parking facilities.


The light sensor is in the location shown below. Do not cover this light sensor with anything; otherwise, the automatic lighting system may not work properly.

Models with automatic intermittent wipers

Light Sensor



Models without automatic intermittent wipers



►► Automatic Operation (automatic lighting control)

Mexican models with driver information interface

Setting	The exterior lights come on when the ambient light is at
Max	 Bright Dark
High	
Mid	
Low	
Min	

Continued

■ Headlight Integration with Wipers

The headlights automatically come on when the wipers are used several times within a certain number of intervals with the headlight switch in **AUTO**.

The headlights automatically go off a few minutes later if the wipers are stopped.

■ Automatic Lighting Off Feature

The headlights, all other exterior lights, and the instrument panel lights turn off 15 seconds after you set the power mode to VEHICLE OFF, take the remote with you, and close the driver's door.

If you set the power mode to VEHICLE OFF with the headlight switch on, but do not open the door, the lights turn off after 10 minutes (3 minutes, if the switch is in the **AUTO** position).

The lights turn on again when you unlock or open the driver's door. If you unlock the door, but do not open it within 15 seconds, the lights go off. If you open the driver's door, you will hear a reminder chime alerting you that the lights are on.

» Headlight Integration with Wipers

This feature activates while the headlights are off in **AUTO**.

The instrument panel brightness does not change when the headlights come on.

At dark ambient light levels, the automatic lighting control feature turns on the headlights, regardless of the number of wiper sweeps.

Models with driver information interface

You can turn the headlight integration with wipers function on and off.

➤ **Settings** P. 142, 167

» Automatic Lighting Off Feature

Models with driver information interface

You can change the headlight auto off timer setting.

➤ **Settings** P. 142, 167

Rear Fog Light*

Can be used when the position lights or the headlights are on.




■ To turn the rear fog light on

Rotate the switch to . The indicator comes on.

* Not available on all models

Headlight Adjuster*



You can adjust the vertical angle of the low beam headlights when the position lights or headlights are on.

Turn the adjustment dial to select an appropriate angle for the headlights.

The larger dial number indicates the lower angle.

■ To select the adjustment dial position

Refer to the below table for the appropriate dial position for your vehicle's riding and loading conditions.

Condition	Dial position
A driver	0
A driver and a front passenger	1
Five persons in the front and rear seats	2
Five persons in the front and rear seats and luggage in the boot, within the limits of maximum permissible axle weight and maximum permissible vehicle weight	3
A driver and luggage in the boot, within the limits of maximum permissible axle weight and maximum permissible vehicle weight	


Auto High-Beam*

The front wide view camera detects the light sources ahead of the vehicle such as the lights of a preceding or oncoming vehicle, or street lights. When you are driving at night, the system automatically switches the headlights between low beam and high beam depending on the situation.

■ How to Use the Auto High-Beam

■ Activating the system

When all of the following conditions have been met, the auto high-beam indicator comes on and automatically switches between the high beam and low beam, depending on the situation.



- The power mode is in ON.
- The light switch is in **AUTO**.
- The lever is in the low beam position.
- The headlights have been automatically activated.
- It is dark outside the vehicle.

If the auto high-beam indicator does not come on even when all the conditions have been met, carry out either of the procedures below and the indicator will come on.

- Pull the lever towards you and release it.
- Turn the light switch to  then turn the light switch to **AUTO**.

Indian, Bhutanese and Nepalese models

- Drive the vehicle for a while.

► Auto High-Beam*

The auto high-beam system does not always operate in every situation. This system is just for assisting the driver. Always observe your surroundings and manually switch the headlights between high beam and low beam if necessary.

The range and the distance at which the camera can recognise light sources varies depending on conditions surrounding your vehicle.

Regarding the handling of the camera mounted to the inside of the windscreen, refer to the following.

► Front Wide View Camera P. 374

For the auto high-beam to work properly:

- Do not place an object that reflects light on the dashboard.
- Keep the windscreen around the camera clean. When cleaning the windscreen, be careful not to apply the windscreen cleanser to the camera lens.
- Do not attach an object, sticker, or film to the area around the camera.
- Do not touch the camera lens.

If the camera receives a strong impact, or repairing of the area near the camera is required, consult a dealer.

Indian, Bhutanese and Nepalese models

If you move the lever from the low beam position, the auto high-beam indicator will turn off.

■ Automatic switching between high-beam and low-beam

When the auto-high beam indicator comes on, the headlights switch between high beam and low beam based on the following conditions.

High beam

All of the following conditions must be met before the high beams turn on.

- Your vehicle speed is 30 km/h (19 mph)*¹/40 km/h (25 mph)*² or more.
- There are no preceding or oncoming vehicles with headlights or taillights turned on.
- There are few street lights on the road ahead.



Low beam

One of the following conditions must be met before the low beams turn on.

- Your vehicle speed is 24 km/h (15 mph) or less.
- There is a preceding or oncoming vehicle with headlights or taillights turned on.
- There are many street lights on the road ahead.

►► How to Use the Auto High-Beam

In the following cases, the auto high-beam system may not switch the headlights properly or the switching timing may be changed. If the automatic switching operation does not fit your driving habits, please switch the headlights manually.

- The brightness of the lights from a preceding or oncoming vehicle is intense or poor.
- Visibility is poor due to the weather (rain, snow, fog, windscreen frost, etc.).
- Surrounding light sources like street lights, electric billboards, and traffic lights are illuminating the road ahead.
- The brightness level of the road ahead constantly changes.
- The road is bumpy or has many curves.
- A vehicle suddenly appears in front of you, or a vehicle in front of you is not in the preceding or oncoming direction.
- Your vehicle is tilted with a heavy load in the rear.
- A traffic sign, mirror, or other reflective object ahead is reflecting strong light towards the vehicle.
- The oncoming vehicle frequently disappears under roadside trees or behind median barriers.
- The preceding or oncoming vehicle is a motorcycle, bicycle, mobility scooter, or other small vehicle.

The auto high-beam system keeps the headlight low beam on when:

- Windscreen wipers are operating at a high speed.
- The camera has detected a dense fog.

*1: Indian, Bhutanese and Nepalese models

*2: Except Indian, Bhutanese and Nepalese models

■ Manual switching between high-beam and low-beam

Except Indian, Bhutanese and Nepalese models

If you want to manually switch the headlights between high beam and low beam, follow either of the procedures below. Note that when you do this, the auto high-beam indicator will turn off and the auto high-beam will be deactivated.

Using the lever:

Pull the lever towards you for flashing the high beams and then release it.

- To reactivate the auto high-beam, follow either of the procedures below and the auto high-beam indicator will come on.
- Pull the lever towards you and release it.
- Turn the light switch to  and then to **AUTO** when the lever is in the low beam position.

Using the light switch:

Turn the light switch to .

- To reactivate the auto high-beam, turn the light switch to **AUTO** when the lever is in the low beam position, and the auto high-beam indicator will come on.

Indian, Bhutanese and Nepalese models

If you want to manually switch the headlights between high beam and low beam, follow the procedure below. Note that when you do this, the auto high-beam indicator will turn off and the auto high-beam will be deactivated.

Using the light switch:

Turn the light switch to .

- To reactivate the auto high-beam, turn the light switch to **AUTO** when the lever is in the low beam position, and the auto high-beam indicator will come on.

►► How to Use the Auto High-Beam

How to turn off the Auto High-beam System

You can turn the auto high-beam system on the off.

► **Settings** P. 142, 167

Daytime Running Lights

The position/daytime running lights come on when the following conditions have been met:

- The power mode is in ON.

Except Mexican models

- The headlight switch is in **AUTO**.

Mexican models

- The headlight switch is in **AUTO** or .


All models

Setting the power mode to VEHICLE OFF will turn off the daytime running lights.

The daytime running lights are off once the headlight switch is turned on, or when the head light switch is in **AUTO** and it is getting darker outside.

Wipers and Washers

■ Windscreen Wipers/Washers



The windscreen wipers and washers can be used when the power mode is in ON.

■ MIST


The wipers run at high speed until you release the lever.

■ Wiper switch (OFF, INT*/1/AUTO*2, LO, HI)

Move the lever up or down to change the wiper settings.

■ Adjusting wiper operation*

Turn the adjustment ring to adjust the wiper operation.



■ Washer

Sprays while you pull the lever towards you. When you release the lever for more than one second, the spray stops, the wipers sweep two or three more times to clear the windscreen, and then stop.

*1: Models with manual intermittent operation

*2: Models with automatic intermittent operation

* Not available on all models

► Wipers and Washers

NOTICE

Do not use the wipers when the windscreen is dry. The windscreen will get scratched, or the rubber blades will get damaged.

NOTICE

Turn the washers off if no washer fluid comes out. The pump may get damaged.

The wiper motor may stop motor operation temporarily to prevent an overload. Wiper operation will return to normal within a few minutes.

Models with intermittent time adjustment ring

If the vehicle speeds up while the wipers are operating intermittently, the length of the wipe interval shortens.

When the vehicle speeds up, the wiper operation's shortest delay setting (👉) and the LO setting become the same.

» Wipers and Washers

NOTICE


In cold weather, the blades may freeze to the windscreen.

Operating the wipers in this condition may damage the wipers. Use the demister to warm the windscreen, then turn the wipers on.

If the wipers stop operating due to any obstacle such as the buildup of snow, park the vehicle in a safe place.

Rotate the wiper switch to **OFF**, set the power mode to ACCESSORY or VEHICLE OFF, then remove the obstacle.

■ Automatic Intermittent Wipers*



When you push the lever down to **AUTO**, the windscreen wipers sweep once and go into the automatic mode.

The wipers operate intermittently, at low speed, or at high speed and stop in accordance with the amount of rainfall the rainfall sensor detects.

■ AUTO sensitivity adjustment


When the wiper function is set to **AUTO**, you can adjust the sensitivity of the rainfall sensor (using the adjustment ring) so that wipers will operate in accordance with your preference.

Sensor sensitivity



⊠ Automatic Intermittent Wipers*

The rainfall sensor is in the location shown below.




NOTICE

AUTO should always be turned **OFF** before the following situations in order to prevent severe damage to the wiper system:

- Cleaning the windscreen
- Driving through a car wash
- No rain present

* Not available on all models

Brightness Control



Models with information display

When the brightness of the meter will be reduced, you can use the **+** or **-** button to adjust instrument panel brightness.

Brighten: Press the **+** button.

Dim: Press the **-** button.

Models with driver information interface

When the power mode is in ON, you can use the **+** or **-** button to adjust instrument panel brightness.

Brighten: Press the **+** button.

Dim: Press the **-** button.

You will hear a beep when the brightness reaches minimum or maximum. Several seconds after adjusting the brightness, you will be returned to the previous screen.

►► Brightness Control

The brightness of the instrument panel will be reduced when the following conditions:

- The power mode is in ON.
- The light switch is in any position other than off and it is dark outside.

The brightness can be set differently for when the exterior lights are on, and when they are off.

Models with information display



Models with driver information interface




■ Brightness level indicator


The brightness level is shown on the display while you are adjusting it.

Rear Demister Button

Right-hand drive type



Left-hand drive type



Press the rear demister button to demist the rear window when the power mode is in ON.

The rear demister automatically switches off after 10-30 minutes depending on the outside temperature.


However, if the outside temperature is 0°C or below, it does not automatically switch off.

» Rear Demister Button

This system consumes a lot of power, so turn it off when the window has been demisted. Also, do not use the system for a long time while the engine is idling. This may weaken the battery, making it difficult to start the engine.

Adjusting the Steering Wheel

The steering wheel height and distance from your body can be adjusted so that you can comfortably grip the steering wheel in an appropriate driving posture.



1. While the vehicle is stopped, push the steering wheel adjustment lever down.
 - The steering wheel adjustment lever is under the steering column.
2. Move the steering wheel up or down, and in or out.
 - Make sure you can see the instrument panel gauges and indicators.
3. Pull the steering wheel adjustment lever up to lock the steering wheel in position.
 - After adjusting the position, make sure you have securely locked the steering wheel in place by trying to move it up, down, in, and out.

Adjusting the Steering Wheel

⚠ WARNING


Adjusting the steering wheel position while driving may cause you to lose control of the vehicle and be seriously injured in a crash.

Adjust the steering wheel only when the vehicle is stopped.

Interior Rearview Mirror


Adjust the angle of the rearview mirror when you are sitting in the correct driving position.

Rearview Mirror with Day and Night Positions*



Flip the tab to switch the position. The night position will help to reduce the glare from headlights behind you when driving after dark.

Automatic Dimming Rearview Mirror*



When you are driving after dark, the automatic dimming rearview mirror reduces the glare from headlights behind you, based on inputs from the mirror sensor. This feature is always active.

» Mirrors

Keep the inside and outside mirrors clean and adjusted for best visibility.


Adjust the mirrors before you start driving.

» **Front Seats** P. 233

» Automatic Dimming Rearview Mirror*

The auto dimming function cancels when the transmission is in **R**.

Power Door Mirrors



You can adjust the door mirrors when the power mode is in ON.

■ Mirror position adjustment

L/R selector switch: Select the left or right mirror. After adjusting the mirror, return the switch to the centre position.

Mirror position adjustment switch: Press the switch left, right, up, or down to move the mirror.

■ Folding door mirrors*

Press the folding button to fold in and out the door mirrors.

* Not available on all models

■ Automatic Folding Door Mirror Function *

■ Folding in the door mirrors

Press the lock button on the remote transmitter, or press the door lock button on the front door.

- The mirrors start folding in automatically.

■ Folding out the door mirrors

Unlock the driver's door using the remote transmitter or keyless access system.

- The mirrors start folding out automatically.

» Automatic Folding Door Mirror Function *


You cannot turn the automatic folding out automatically if they have been folded in using the folding button.

You can turn the automatic folding door mirror function on and off.

🔧 **Settings** P. 142, 167

Door mirrors will not fold automatically when locking from inside the vehicle using lock tab or master door lock switch.

Front Seats



Adjust the driver's seat as far back as possible while allowing you to maintain full control of the vehicle. You should be able to sit upright, well back in the seat and be able to adequately press the pedals without leaning forward, and grip the steering wheel comfortably. The passenger's seat should be adjusted in a similar manner so that it is as far back from the front airbag in the dashboard as possible.

Seats

Always make seat adjustments before driving.

Front Seats


⚠ WARNING

Sitting too close to a front airbag can result in serious injury or death if the front airbags inflate.

Always sit as far back from the front airbags as possible while maintaining control of the vehicle.

In addition to the seat adjustment, you can adjust the steering wheel up and down, in and out. Allow at least 25 cm between the centre of the steering wheel and the chest.


■ Adjusting the Seat Positions



►► Adjusting the Seat Positions

Once a seat is adjusted correctly, rock it back and forth to make sure it is locked in position.

■ Adjusting the Seat-Backs



Adjust the driver's seat-back to a comfortable, upright position, leaving ample space between your chest and the airbag cover in the centre of the steering wheel.

The front seat passenger should also adjust their seat-back to a comfortable, upright position.

Reclining a seat-back so that the shoulder part of the belt no longer rests against the occupant's chest reduces the protective capability of the belt. It also increases the chance of sliding under the belt in a crash and being seriously injured. The farther a seat-back is reclined, the greater the risk of injury.

► Adjusting the Seat-Backs

⚠ WARNING

Reclining the seat-back too far can result in serious injury or death in a crash.

Adjust the seat-back to an upright position, and sit well back in the seat.



Do not put a cushion, or other object, between the seat-back and your back.

Doing so may interfere with proper seat belt or airbag operation.

If you cannot get far enough away from the steering wheel and still reach the controls, we recommend that you investigate whether some type of adaptive equipment may help.

Rear Seats

Folding Down the Rear Seats*



1. Put the armrest back into the seat-back.
2. Remove the centre shoulder belt from the guide.

3. Pull the release lever in the boot to release the lock.

4. Fold the seat-back down.

Folding Down the Rear Seats*

WARNING

Make sure the seat-backs are latched securely before driving.

The rear seat-backs can be folded down to accommodate bulkier items in the boot.

Never drive with the seat-back folded down and the boot lid open.

Exhaust Gas Hazard P. 99

To lock the seat-back upright, push it backwards until it locks.

When returning the seat-back to its original position, push it firmly back. Also, make sure all rear shoulder belts are positioned in front of the seat-back, and the centre shoulder belt is re-positioned in the guide.


Make sure all items in the boot or items extending through the opening into the rear seats are properly secured. Loose items can fly forward if you have to brake hard.

Remove any items from the rear seat cushion and floor before you fold down the rear seat.


Rear Seat Reminder*

This feature alerts you to the possible presence of passengers or items in the rear seats before you exit the vehicle. It activates when the vehicle is set to VEHICLE OFF if the rear doors were opened shortly before or after the vehicle was set to ON.

Models with A-type meter



Models with B-type meter



A reminder appears on the driver information interface and an alert will sound when the power mode is set to VEHICLE OFF.

⌘ Rear Seat Reminder*

When the power mode is set to VEHICLE OFF, the reminder comes on briefly, then the function is deactivated.

The reminder will not work if the power mode has not been set to ON within 10 minutes of operating the rear doors.

The system does not detect passengers in the rear seats. Instead, it can detect when a rear door is opened and closed, indicating that there may be something in the rear seats.

You can turn off the notification setting.

⌘ **Settings** P. 142, 167

* Not available on all models

Maintain a Proper Sitting Position

After all occupants have adjusted their seats and head restraints and put on their seat belts, it is very important that they continue to sit upright well back in their seats with their feet on the floor until the vehicle is safely parked and the engine is off.

Sitting improperly can increase the chance of injury during a crash. For example, if an occupant slouches, lies down, turns sideways, sits forward, leans forward or sideways, or puts one or both feet up, the chance of injury during a crash is greatly increased.

In addition, an occupant who is out of position in the front seat can be seriously or fatally injured in a crash by striking interior parts of the vehicle or being struck by an inflating front airbag.

►► Maintain a Proper Sitting Position

WARNING


Sitting improperly or out of position can result in serious injury or death in a crash.

Always sit upright, well back in the seat, with your feet on the floor.


Head Restraints

Your vehicle is equipped with head restraints in all seating positions.

■ Adjusting the Front Head Restraints Positions



Head restraints are most effective for protection against whiplash and other rear-impact crash injuries when the centre of the back of the occupant's head rests against the centre of the restraint. The tops of the occupant's ears should be level with the centre height of the restraint.



To raise the head restraint:

Pull it upward.

To lower the head restraint:

Push it down while pressing the release button.

▶▶ Adjusting the Front Head Restraints Positions

⚠ WARNING

Improperly positioning head restraints reduces their effectiveness and increases the likelihood of serious injury in a crash.

Make sure head restraints are in place and positioned properly before driving.

In order for the head restraint system to work properly:

- Do not hang any items on the head restraints, or from the restraint legs.
- Do not place any objects between an occupant and the seat-back.
- Install each restraint in its proper location.

■ Removing and Reinstalling the Front Head Restraints

Head restraints can be removed for cleaning or repair.

To remove the head restraint:

Pull the restraint up as far as it will go. Then, push the release button and pull the restraint up and out.

To reinstall the head restraint:

Insert the legs back in place, then adjust the head restraint to an appropriate height while pressing the release button. Pull up on the restraint to make sure it is locked in position.

►► Removing and Reinstalling the Front Head Restraints


WARNING

Failure to reinstall or correctly reinstall the head restraints can result in severe injury during a crash.

Always replace the head restraints before driving.


Armrest*

■ Using the Front Seat Armrest*



The console lid can be used as an armrest.

■ Using the Rear Seat Armrest*






Pull down the armrest in the centre backrest.

* Not available on all models

Interior Lights

Interior Light Switches



■ ON

The interior light comes on regardless of whether the doors are open or closed.

■ Door activated

The interior light comes on in the following situations:

- When any doors are opened.
- When the driver's door is unlocked.
- When the power mode is set to VEHICLE OFF.

■ OFF

The interior light remains off regardless of whether the doors are open or closed.

» Interior Light Switches

In the door activated position, the interior light fades out and turns off about 30 seconds after the doors are closed.

The light turns off after 30 seconds in the following situations:

- When you unlock the driver's door but do not open it.
- When you set the power mode to VEHICLE OFF but do not open a door.

Models with driver information interface

You can change the interior lights dimming time.

➤ **Settings** P. 142, 167

The interior light turns off immediately in the following situations:

- When you lock the driver's door.
- When you close the driver's door in ACCESSORY mode.
- When you set the power mode to ON.

If you leave any of the doors open in VEHICLE OFF mode, the interior light turns off after about 15 minutes.

To avoid draining the battery, do not leave the interior light on for an extended length of time when the engine is off.

Map Light Switches



The map lights can be turned on and off by pressing the lenses.

Map Light Switches

When the front interior light switch is in the door activated position and any door is open, the map light will not go off when you press the lens.




The map lights can be turned on and off by pressing the  button.

►► Map Light Switches

When the front interior light switch is in the door activated position and any door is open, the map light will not go off when you press the  button.


Storage Items

■ Glove Box



Pull the handle to open the glove box.

■ Console Compartment*



Pull the handle to open the console compartment.

☒ Glove Box

⚠ WARNING

An open glove box can cause serious injury to your passenger in a crash, even if the passenger is wearing the seat belt.


Always keep the glove box closed while driving.

* Not available on all models

■ Beverage Holders



■ Front seat beverage holders




■ Front seat beverage holders (four beverage holders type)*

» Beverage Holders

NOTICE


Spilled liquids can damage the upholstery, carpeting, and electrical components in the interior.

Be careful when you are using the beverage holders. Hot liquid can scald you.




■ **Front door side beverage holders**

Located on both front door side pockets.



■ **Rear door side beverage holders**

Located on both rear door side pockets.




■ **Rear seat beverage holders***

Fold the armrest down to use the rear seat beverage holders.

* Not available on all models

■ Driver's Side Pocket



Pull the lid to open the pocket.

■ Coat Hook*




There is a coat hook on the rear right grab handle of right side. Pull it down to use it.

»» Coat Hook*

The coat hook is not designed for large or heavy items.

■ Under-Floor Storage Area*



Pull up the boot floor lid.

* Not available on all models

Other Interior Convenience Items


■ Accessory Power Sockets

The accessory power sockets can be used when the power mode is in ACCESSORY or ON.



■ Accessory power socket on the console panel

Open the cover to use it.



■ Accessory power sockets on the back of the console compartment*

Open the cover to use it.

►► Accessory Power Sockets

NOTICE


Do not insert an automotive type cigarette lighter element. This can overheat the accessory power socket.

The accessory power sockets are designed to supply power for 12-volt DC accessories that are rated 180 watts (15 amps) or less.

To prevent battery drain, only use the accessory power socket when the engine is running.

When the accessory power socket is not in use, close the cover to prevent any small foreign objects from getting into the accessory power socket.

Rear Sunshade*



Pull the tab and roll up the sunshade all the way. Use the hooks to hang it.

Rear Sunshade*

NOTICE

Be careful not to scratch the heating elements on the rear windscreen when using the rear sunshade.

Indian Models

Do not use the sunshade while driving as it could obstruct the driver's view.


The sunshade can be used to protect the interior when parking the car in direct sunlight for a long period of time.

Check and follow your local legal requirements before using the sunshade.


* Not available on all models

■ USB Ports for Charging*

Install the USB connector to the USB port (3.0A) for charging the device.
The USB port with  symbol is for battery charge only.



■ On the front panel*



■ Rear of the console compartment*

» USB Ports for Charging*

- Do not leave the device to charge in the vehicle. Direct sunlight and high temperatures may damage it.
- We recommend using an extension cable with the USB port.
- Do not connect the device to charge using a hub.
- Do not use a device such as a card reader or hard disk drive, as the device or your files may be damaged.
- We recommend backing up your data before using the device in your vehicle.

The USB port can supply up to 3.0A of power. It does not output 3.0A unless the device requests.

For amperage details, read the operating manual of the device that needs to be charged.

Set the power mode to ACCESSORY or ON first.


Under certain conditions, a device connected to the port may generate noise in the radio you are listening to.

If the USB charger becomes too hot, charging may be suspended.

Do not insert foreign object into charging device.


Do not spill liquid (i.e. water, drinks, etc) on the device.

■ Front Seat Ventilation *



The seat ventilators can be used when the power mode is in ON.

The seat ventilators: Use them when you want to ventilate the surface of the seats. When used with the air conditioning, the surface of the seats will become easier to cool.



Press the seat ventilation button:

- Once - The HI setting (three indicators on)
- Twice - The MID setting (two indicators on)
- Three times - The LO setting (one indicator on)
- Four times - The OFF setting (no indicators on)

When the power mode is turned on after it is turned off, the previously selected setting is maintained.

▣ Front Seat Ventilation *

Do not use the seat ventilation even in LO when the engine is OFF. Under such conditions, the battery may be weakened, making the engine difficult to start.

* Not available on all models

Using Vents, Heating* and A/C



Dashboard vents and back of the console compartment*



Dashboard and floor vents, and back of the console compartment*



Floor vents



Floor and demister vents

Mode Control Dial

Change airflow.

Temperature Control Dial*³


Adjusts the interior temperature.

MAX COOL Button*^{1, 3}

Press to cool down the interior rapidly.

A/C (Air Conditioning) Button*³

Press to cool the interior or dehumidify.



(ON/OFF) Button*³

Press to switch the system between on and off.

MAX A/C Button*²

Turns on the A/C, selects airflow from the dashboard vents, and switches the mode to recirculation.



(Recirculation) Button*³

Press the  button and switch the mode depending on environmental conditions.

Recirculation mode (indicator on):

Recirculates air from the vehicle's interior through the system.

Fresh air mode (indicator off):

Maintains outside ventilation. Keep the system in fresh air mode in normal situations.

*1: Models with **MAX COOL** button

*2: Models with **MAX A/C** button

*3: Right-hand drive models shown. For the left-hand drive models, these buttons are located at the symmetrically opposite to the right-hand drive model.

* Not available on all models

■ Heating*

The heater uses engine coolant to warm the air.

1. Adjust the fan speed using the fan control dial.
2. Select .
3. Adjust the temperature using the temperature control dial.
4. Press the  button (the indicator off).

■ To rapidly warm up the interior

1. Set the fan to the maximum speed.
2. Select .
3. Set the temperature to maximum warm.
4. Press the  button (the indicator on).

■ To dehumidify the interior

When used in combination with the heater, the air conditioning system makes the interior warm and dry and can prevent the windows from fogging up.

1. Turn the fan on.
2. Press the **A/C** button (**A/C ON** is appeared) to turn on the air conditioning.
3. Select  and press the  button (the indicator off).
4. Adjust the temperature to your preference.

►► Using Vents, Heating* and A/C

Thai models

During idle-stops, air-conditioning is suspended, and only the blower remains active.

If you do not want air-conditioning suspended, press the Auto Idle Stop **OFF** button to cancel idle-stop.

►► To rapidly warm up the interior

Change to fresh air mode as soon as the interior gets warm enough. The windows may fog up if kept in recirculation mode.

Cooling

1. Adjust the fan speed using the fan control dial.
2. Select .
3. Adjust the temperature using the temperature control dial.
4. Press the **A/C** button (**A/C ON** is appeared).
5. Press the  button (the indicator off).

■ To rapidly cool down the interior

Models with MAX A/C button

1. Set the fan to the maximum speed.
2. Press the **MAX A/C** button (**MAX A/C** is appeared).

Models with MAX COOL button

Press the **MAX COOL** button (**MAX COOL** is appeared).

►► Cooling

Continuously variable transmission models


While **ECON** mode is active, the system may have reduced cooling performance.

►► To rapidly cool down the interior


If the interior is very warm, you can cool it down more rapidly by partially opening the windows.

Defrosting the Windscreen and Windows

Right-hand drive type



Left-hand drive type



1. Set the fan to a high speed.
2. Press the  button.
3. Press the  button (indicator off).
4. Adjust the temperature until the airflow feels warm.
 - If you want to rapidly defrost the window:
Set the fan to the maximum speed and higher temperature, then press the  button (indicator on).

Defrosting the Windscreen and Windows

For your safety, make sure you have a clear view through all the windows before driving.

Do not set the temperature near the lower limit. When cold air hits the windscreen, the outside of the windscreen may fog up.


Thai models

If the side windows fog up, adjust the vents so that the air hits the side windows.


If you press  button during Auto Idle Stop, the engine restarts automatically.

■ To rapidly defrost the windows

Right-hand drive type



Left-hand drive type




►► To rapidly defrost the windows

After defrosting the windows, switch over to fresh air mode. If you keep the system in recirculation mode, the windows may fog up from humidity. This impedes visibility.

Using Automatic Climate Control

The automatic climate control system maintains the interior temperature you select. The system also selects the proper mix of heated* or cooled air that raises* or lowers the interior temperature to your preference as quickly as possible.



Use the system when the engine is running.

1. Press the **AUTO** button.
2. Adjust the interior temperature using the temperature control dial.
3. Press the **ON/OFF** (ON/OFF) button to cancel.

Using Automatic Climate Control

If any buttons are pressed while using the climate control system in auto, the function of the button that was pressed will take priority.

The **AUTO** indicator will go off, but functions unrelated to the button that was pressed will be controlled automatically.

Continuously variable transmission models

While ECON mode is active, the climate control system may have reduced cooling performance.

Models without MAX COOL button

If the interior is very warm, you can cool it down more rapidly by partially opening the windows, turning the system on auto, and setting the temperature to low. Change the fresh air mode to recirculation mode until the temperature cools down.

Models with MAX COOL button

If the interior is very warm, you can cool it down more rapidly by partially opening the windows, press the **MAX COOL** button.

When you set the temperature to the lower or upper* limit, **Lo** or **Hi*** is displayed.

Pressing the **ON/OFF** (ON/OFF) button switches the climate control system between on and off. When turned on, the system returns to your last selection.

* Not available on all models

■ Switching between the recirculation and fresh air modes

Press the  (Recirculation) button and switch the mode depending on environmental conditions.

Recirculation mode (indicator on): Recirculates air from the vehicle's interior through the system.

Fresh air mode (indicator off): Maintains outside ventilation. Keep the system in fresh air mode in normal situations.

►► Using Automatic Climate Control

Some models

To prevent cold air from blowing in from outside, the fan may not start immediately when the **AUTO** button is pressed.


Defrosting the Windscreen and Windows

Defrosting the Windscreen and Windows


For your safety, make sure you have a clear view through all the windows before driving.

Do not set the temperature near the lower limit. When cold air hits the windscreen, the outside of the windscreen may fog up.

Right-hand drive type



Left-hand drive type



Press the  button to turn the air conditioning system on and the system automatically switches to the fresh air mode.

Some models

Press the  button (indicator off) to switch to the fresh air mode.


► If you want to rapidly defrost the window:

Press the  button (indicator on).


Press the  button again to turn it off and the system will return to the previous settings.

■ To rapidly defrost the windows

Right-hand drive type




Left-hand drive type



►► To rapidly defrost the windows

After defrosting the windows, switch over to fresh air mode. If you keep the system in recirculation mode, the windows may fog up from humidity. This impedes visibility.

Automatic Climate Control Sensors



The automatic climate control system is equipped with sensors. Do not cover or spill any liquid on them.

Features

If this vehicle is equipped with an audio system, please refer to the audio system manual.
Consult a dealer for details.



Driving

This chapter discusses driving and refueling.

Before Driving

Driving Preparation	268
Load Limit	270

Towing a Trailer..... 271

When Driving

Starting the Engine	272
Precautions While Driving.....	279
Continuously Variable Transmission* ..	280
Shifting	281, 286
ECON Mode*	289
Auto Idle Stop*	290
Cruise Control*	294
Vehicle Stability Assist (VSA) System ..	298

Agile Handling Assist	300
Deflation Warning System*	301
Honda SENSING*	308
Collision Mitigation Braking System (CMBS)	311
Road Departure Mitigation System....	325
Adaptive Cruise Control (ACC).....	337
Lane Keeping Assist System (LKAS) ..	355
Lead Car Departure Notification System* ..	368
Front Wide View Camera	374

Braking

Brake System	376
Anti-lock Brake System (ABS)	378

Brake Assist System	379
---------------------------	-----

Except Mexican models

Emergency Stop Signal	380
-----------------------------	-----

Parking Your Vehicle

When Stopped	381
Parking Sensor System*	383

Refueling

Fuel Information	387
How to Refuel	389

Fuel Economy and CO₂ Emissions.... 390

Turbo Engine Vehicle*

Driving Preparation

Check the following items before you start driving.

Exterior Checks

- Make sure there are no obstructions on the windows, door mirrors, exterior lights, or other parts of the vehicle.
 - ▶ Remove any frost, snow, or ice.
 - ▶ Remove any snow on the roof, as this can slip down and obstruct your field of vision while driving or fall off and impact other road users. If frozen solid, remove ice once it has softened.
 - ▶ When removing ice from around the wheels, be sure not to damage the wheel or wheel components.
- Make sure the bonnet is securely closed.
 - ▶ If the bonnet opens while driving, your front view will be blocked.
- Make sure the tyres are in good condition.
 - ▶ Check air pressures, and check for damage and excessive wear.
-  **Checking and Maintaining Tyres** P. 439
- Make sure there are no people or objects behind or around the vehicle.
 - ▶ There are blind spots from the inside.

Exterior Checks

NOTICE

When doors are frozen shut, use warm water around the door edges to melt any ice. Do not try to force them open, as this can damage the rubber trim around the doors. When done, wipe dry to avoid further freezing.

Do not pour warm water into the key cylinder. You will be unable to insert the key if the water freezes in the hole.

Heat from the engine and exhaust can ignite flammable materials left under the bonnet, causing a fire. If you've parked your vehicle for an extended period, inspect and remove any debris that may have collected, such as dried grass and leaves that have fallen or have been carried in for use as a nest by a small animal. Also, check under the bonnet for leftover flammable materials after you or someone else has performed maintenance on your vehicle.

Interior Checks

- Store or secure all items on board properly.
 - Carrying too much luggage, or improperly storing it, can affect your vehicle's handling, stability, stopping distance, and tyres, and make it unsafe.
 - ✎ **Load Limit** P. 270
- Do not pile items higher than the seatback height.
 - They can block your view and may be thrown forward in the event of sudden braking.
- Do not place anything in the front seat footwells. Make sure to secure the floor mat.
 - An object or unsecured floor mat can interfere with your brake and accelerator pedal operation while driving.
- If you have any animals on board, do not let them move around in the vehicle.
 - They may interfere with driving and a crash could occur.
- Securely close all doors and the boot.
 - ✎ **Locking/Unlocking the Doors from the Inside** P. 192
- Adjust your seating position properly.
 - Adjust the head restraint, too.
 - ✎ **Seats** P. 233
 - ✎ **Adjusting the Front Head Restraints Positions** P. 239
- Adjust the mirrors and steering wheel properly.
 - Adjust them while sitting in the proper driving position.
 - ✎ **Mirrors** P. 230
 - ✎ **Adjusting the Steering Wheel** P. 229

Interior Checks

The headlight aim is set by the factory, and does not need to be adjusted. However, if you regularly carry heavy items in the boot, have the aiming readjusted at a dealer or by a qualified technician.

Models with headlight adjuster

You can adjust the low beam headlight angle by yourself.

✎ **Headlight Adjuster*** P. 218

* Not available on all models

- Be sure items placed on the floor behind the front seats cannot roll under the seats.
 - They can interfere with the driver's ability to operate the pedals, the operation of the seats.
- Everyone in the vehicle must fasten their seat belt.
 - 📖 **Fastening a Seat Belt** P. 46
- Make sure that the indicators in the instrument panel come on when you start the vehicle, and go off soon after.
 - Always have a dealer check the vehicle if a problem is indicated.
 - 📖 **Indicators** P. 102

Load Limit

When you load luggage, the total weight of the vehicle, all passengers, and luggage must not exceed the maximum permissible weight.

📖 **Specifications** P. 524

►► Load Limit

WARNING




Overloading or improper loading can affect handling and stability and cause a crash in which you can be hurt or killed.

Follow all load limits and other loading guidelines in this manual.

Towing a Trailer

Your vehicle is not designed to, and cannot safely, tow a trailer nor have a tow hitch installed. Do not install a tow hitch on, or tow with, your vehicle.

Starting the Engine



1. Make sure the parking brake is applied.

Continuously variable transmission models

2. Check that the transmission is in **P**, then depress the brake pedal.

► Although it is possible to start the vehicle in **N**, it is safer to start it in **P**.

Manual transmission models

2. Check that the shift lever is in **N**. Then, depress the brake pedal with your right foot, and the clutch pedal with your left foot.

► The clutch pedal must be fully depressed to start the engine.

Starting the Engine

Keep your foot firmly on the brake pedal when starting the engine.


The engine is harder to start in cold weather and in thinner air found at altitudes above 2,400 metres.

When starting the engine in cold weather, turn off all electrical accessories such as the lights, Heating* and cooling system*/climate control system*, and rear demister in order to reduce battery drain.

If the exhaust system sounds abnormal or you can smell exhaust gas inside the vehicle, have your vehicle checked by a dealer. There may be a problem with the engine or exhaust system.

Bring the keyless remote close to the **ENGINE START/STOP** button if the battery in the keyless remote is weak.

➡ **If the Keyless Remote Battery is Weak** P. 485



All models

3. Press the **ENGINE START/STOP** button without depressing the accelerator pedal.

▶▶ Starting the Engine

The engine may not start if the keyless remote is subjected to strong radio waves.

Do not hold the **ENGINE START/STOP** button to start the engine.

If the engine does not start, wait at least 30 seconds before starting the engine again.

The immobilizer system protects your vehicle from theft. If an improperly coded key (or other device) is used, the engine's fuel system is disabled.

🔑 **Immobilizer System** P. 198

Thai models

When you start the engine, you may feel the brake pedal slightly sink down. This is normal.

■ Remote Engine Start*

You can remotely start the engine using the keyless remote.

■ To start the engine


LED: Blinks when any button is pressed.



Press the  button, then press and hold the  button.

▶ Some exterior lights flash once.

If the engine starts successfully, some exterior lights flash six times.



▶▶ Remote Engine Start*

⚠ WARNING

Engine exhaust contains toxic carbon monoxide.

Breathing carbon monoxide can kill you or cause unconsciousness.

Never use the remote engine starter when the vehicle is parked in a garage or other area with limited ventilation.

The remote engine start may violate local laws. Before using the remote engine start, check your local laws.

If there are buildings and obstacles between your vehicle and the keyless remote, the range will be reduced. This distance may vary by external electrical interference.



If the engine does not start, exterior lights will not flash.

- ▶ Go within the range, and try again.

When started remotely, the engine automatically shuts off after 10 minutes of idling and/or the brake pedal and **ENGINE START/STOP** button have not been pressed simultaneously.

To extend the run time for another 10 minutes during the first run, press the  button, then press and hold the  button.

- ▶ Some exterior lights flash six times if a 10-minute extension request was transmitted successfully.

⌘ Remote Engine Start*

The engine may not start by the remote engine start if:


- You have disabled a remote engine start setting*.
 ➤ **Settings** P. 142, 167
- The power mode is not in VEHICLE OFF.
- The transmission is in a position other than **P**.
- The bonnet is open, or any door or the boot is unlocked.
- You have already used the keyless remote twice to start the engine.
- Another registered keyless remote is in the vehicle.
- There is any antenna failure.
- The door is unlocked with the built-in key.
- The engine oil pressure is low.
- The engine coolant temperature is extremely high.
- The telematics unit malfunctions*.
- The security system alarm is not set.

* Not available on all models

■ To stop the engine



Press and hold the  button for one second.



If the engine stops successfully, the exterior lights flash once.



When the keyless remote is out of the keyless access system range, the exterior lights will not flash. The engine will not stop.

► Go within the range, and try again.

►► Remote Engine Start*

The engine may stop while it is running if:

- You do not start the vehicle within 10 minutes of starting the engine with the keyless remote.
- The engine is stopped by using the keyless remote.
- The security system alarm is not set.
- The door is unlocked with the built-in key.
- The bonnet is open, or any door, or the boot is unlocked.
- You press the shift lever release button.
- The engine coolant temperature is extremely high.
- The battery is low.
- The engine oil pressure is low.
- The malfunction indicator lamp comes on if there is a problem with the emissions control systems.

While the engine is running, the vehicle will automatically precondition inside the vehicle.

When it is warm outside:

- The heating* and cooling system*/climate control system* is activated in recirculation mode.

When it is cold outside:

- The demister is activated at a moderately warm temperature.
- The rear demister is activated.

Starting to Drive

Continuously variable transmission models

When the engine was started using the keyless remote*

1. Depress and hold the brake pedal, then press the **ENGINE START/STOP** button.

When the engine was started in any case

2. Keeping your right foot on the brake pedal, release the parking brake. Check that the parking brake and brake system indicator (red) has gone off.

🔧 **Parking Brake** P. 376

3. Put the shift lever in **[D]**. Select **[R]** when reversing.

4. Gradually release the brake pedal and gently depress the accelerator pedal to pull away.

Hill Start Assist System

Hill start assist keeps the brake engaged briefly to help to prevent the vehicle from rolling on inclines as you move your foot from the brake pedal to the accelerator.

Manual transmission models

Depress the clutch pedal, and shift to one of the forward gears when facing uphill, or **[R]** when facing downhill, then release the brake pedal.

Continuously variable transmission models

Put the transmission into **[D]** or **[S]** when facing uphill, or **[R]** when facing downhill, then release the brake pedal.

Starting to Drive

When the engine was started using the keyless remote*

The engine stops when the transmission is taken out of **[P]** before the **ENGINE START/STOP** button is pressed. Follow step 1 when starting to drive.

Hill Start Assist System

Hill start assist may not prevent the vehicle from rolling downhill on a very steep or slippery slope, and will not operate on small inclines.

Hill start assist will operate even when VSA is switched off.

Hill start assist is not a replacement for the parking brake.

■ Stopping the Engine

You can turn the engine off when the vehicle is completely stopped.

Continuously variable transmission models

1. Depress the brake pedal and change the shift position to **[P]**.
2. Press the **ENGINE START/STOP** button.

Manual transmission models

- If the shift lever is in **[N]**, press the **ENGINE START/STOP** button.
- If the shift lever is in any gear other than **[N]**, depress the clutch pedal, then press the **ENGINE START/STOP** button.

Precautions While Driving

In a Fog

Visibility becomes low when it is foggy. When you drive, turn on the low beam headlights even during the daytime. Slow down, using the road line in the centre, guard rails, and the taillights of the vehicle ahead of you as your driving guide.

In a Strong Wind

If a strong side wind drifts your vehicle while driving, hold the steering wheel tight. Slowly decelerate your vehicle and keep your vehicle in the middle of the road. Be careful with wind gusts especially when your vehicle is exiting a tunnel, driving on a bridge or river bank, and driving through an open area like a quarry, and when a large lorry is passing by.

In Rain

The road is slippery when raining. Avoid hard braking, rapid acceleration, and abrupt steering and be more cautious when driving. It is likely to experience hydroplaning phenomenon if you are driving on a rutted road with puddles. Do not drive in deep water and on flooded roads. This can damage the engine or driveline, or cause electrical component failure.

Precautions While Driving

CAUTION: Do not drive on the road where water is deep. Driving through deep water will cause damage to the engine and electrical equipment and the vehicle will break down.

Continuously variable transmission models

NOTICE

Do not operate the shift lever while pressing the accelerator pedal. You could damage the transmission.

All models

NOTICE

If you repeatedly turn the steering wheel at an extremely low speed, or hold the steering wheel in the full left or right position for a while, the electric power steering (EPS) system heats up. The system goes into a protective mode and limits its performance. The steering wheel becomes harder and harder to operate. Once the system cools down, the EPS system is restored. Repeated operation under these conditions can eventually damage the system.

If the power mode is set to ACCESSORY while driving, the engine will shut down and all steering and brake power assist functions will stop, making it difficult to control the vehicle.

Do not select **N** while driving as you will lose engine braking (and acceleration) performance.

■ Other Precautions

If there is a strong impact with something under the vehicle, stop in a safe location. Check the underside of the vehicle for damage or any fluid leaks.

Continuously Variable Transmission *

■ Creeping

When the engine runs at higher idle speeds, the creeping force increases. Keep the brake pedal firmly depressed when stopped or ensure that brake-hold is engaged.

■ Kickdown

Quickly depressing the accelerator pedal while driving uphill may cause the transmission to drop to a lower ratio, unexpectedly increasing vehicle speed. Depress the accelerator pedal carefully, especially on slippery roads and curves.

►► Precautions While Driving

During the first 1,000 km of operation, avoid sudden acceleration or full throttle operation so as not to damage the engine or powertrain.

Avoid hard braking for the first 300 km after purchasing your new vehicle or replacing the brake pads or rotors to allow for proper break-in.

►► In Rain

Be careful when hydroplaning phenomenon occurs. When you drive on a road covered with water at excessive speed, a layer of water builds between the tyres and the road surface. If this occurs, the vehicle cannot respond to control inputs such as steering, and braking.


Slowly decelerate when you shift down. If the road is slippery, sudden engine braking can cause the tyres to skid.

Continuously variable transmission models

Shifting

Change the shift position in accordance with your driving needs.

■ Shift lever positions




▣ Shift lever positions

You cannot change the power mode from ON to VEHICLE OFF unless the shift lever is in **P**.


The vehicle may move very slightly even in **N** while the engine is cold.
Depress the brake pedal firmly and, when necessary, apply the parking brake.

Shift Lever Operation

Models with A-type meter



Models with B-type meter



Shift Lever Operation

NOTICE

When you change the shift lever from **[D]** to **[R]** and vice versa, come to a complete stop and keep the brake pedal depressed.

Operating the shift lever before the vehicle has come to a complete standstill can damage the transmission.

Use the shift position indicator to check the lever position before pulling away.

If the transmission system indicator blinks when driving, in any shift position, there is a problem with the transmission.

Avoid sudden acceleration and have the transmission checked by a dealer as soon as possible.


The fuel supply may be cut off if you drive at engine speeds in or over the tachometer red zone (engine speed limit). If this happens, you may experience a slight jolt.

It may not be possible to operate the shift lever if the brake pedal is applied while the shift lever release button is held down.


Depress the brake pedal first.

When shifting positions in extremely low temperatures (-30°C), there may be a short delay before the shift position is displayed. Always confirm you are in the correct shift position before driving.

Models with information display



All models



Models with paddle shifters

■ 7-Speed Manual Shift Mode

Use the paddle shifters to change between 1st and 7th speeds without releasing your hands from the steering wheel. The transmission switches to the 7-speed manual shift mode when you pull a paddle shifter while driving. This mode is useful when engine braking is needed.

■ When the shift lever is in **[D]**:

The shift mode goes into the 7-speed manual shift mode temporarily, and the number is displayed in the shift indicator.

The 7-speed manual shift mode is cancelled automatically if you drive at constant speed or accelerate, and the number in the shift indicator goes off.

Pulling the **[+]** paddle shifter for a few seconds will cancel this mode.

The 7-speed manual shift mode is especially useful when reducing the vehicle speed temporarily before making a turn.

■ When the shift lever is in **[S]**:

The shift mode goes into the 7-speed manual shift mode. The **M** indicator and the speed number are displayed in the shift indicator. As the vehicle speed slows down, the transmission automatically shifts down accordingly. When the vehicle comes to a stop, it automatically shifts down into 1st.


If the vehicle speed increases and the engine speed reaches near the tachometer's red zone, the transmission automatically shifts up.

When cancelling the 7-speed manual shift mode, move the shift lever from **[S]** to **[D]**. When the 7-speed manual shift mode is cancelled, the **M** indicator and shift indicator will turn off.

You can only pull away in 1st speed.

Models with paddle shifters

7-Speed Manual Shift Mode Operation



7-Speed Manual Shift Mode Operation

In the 7-speed manual shift mode, the transmission shifts up or down by operating either paddle shifter under the following conditions:

Shift Up: The engine speed reaches the lowest threshold of the higher speed position.

Shift Down: The engine speed reaches the highest threshold of the lower speed position.

When the engine speed reaches near the tachometer's red zone, the transmission shifts up automatically.

When the engine speed reaches the lowest threshold of the selected speed position, the transmission shifts down automatically.

Operating the paddle shifters on slippery surfaces may cause the tyres to lock up. In this case, the 7-speed manual shift mode is cancelled and goes back to the normal driving mode.

Each paddle shift operation makes a single speed change.

To change continuously, release the paddle shifter before pulling it again for the next speed.

The shift indicator blinks when you cannot shift up or down. It indicates that your vehicle speed is not in its allowable shifting range.

Slightly accelerate to shift up and decelerate to shift down while the indicator is blinking.


Manual transmission models

Shifting

Shift Lever Operation

Fully depress the clutch pedal to operate the shift lever and change gears, then slowly release the pedal.

Depress the clutch pedal, and pause for a few seconds before shifting into **R**, or shift into one of the forward gears for a moment. This stops the gears so they do not “grind.”



When you are not shifting, do not rest your foot on the clutch pedal. This can cause your clutch to wear out faster.

Shifting

NOTICE

Do not shift to **R** before the vehicle comes to a complete stop.

Shifting to **R** before stopping can damage the transmission.

NOTICE

Before downshifting, make sure the engine will not go into the tachometer's red zone. Should this occur, it can severely damage your engine.

If you exceed the maximum speed for the gear you are in, the engine speed will enter into the tachometer's red zone. When this happens, you may experience a slight jolt.

■ Shift Up/Down Indicator*



Come on to inform you that upshifting or downshifting is necessary to prevent the engine from over revving or stalling.

The shift up indicator: Comes on when upshifting is recommended.

The shift down indicator: Comes on when downshifting is recommended.

▣ Shift Up/Down Indicator*

This indicator will not prompt you to downshift to increase engine braking. It is up to you to downshift to increase engine braking when driving downhill.

Always shift down at the appropriate vehicle speed.

The shift down indicator does not come on when downshifting from **2** to **1**.


Road and traffic conditions may require you to shift at times other than those indicated.

* Not available on all models

Reverse Lockout

The manual transmission has a lockout mechanism that stops you from accidentally shifting into **R** from a forward gear while the vehicle is moving above a certain speed.

If you cannot shift to **R** when the vehicle is stopped, do the following:



1. Depress the clutch pedal, move the shift lever all the way to the left, and shift to **R**.
2. If you still cannot shift into **R**, apply the parking brake, and set the power mode to ACCESSORY or VEHICLE OFF.
3. Depress the clutch pedal and shift into **R**.
4. Keep depressing the clutch pedal and start the engine.


Reverse Lockout

Have your vehicle checked by a dealer if you have to go through this procedure repeatedly.

ECON Mode*

The ECON mode limits output to facilitate fuel-efficient driving.

▶ To turn the ECON mode ON and OFF, press the **ECON** button.



⌘ ECON Mode*

While in ECON mode, the Heating* and cooling system*/climate control system* will be less effective and the vehicle slower to accelerate.

The mode may not be able to be changed under some driving conditions.

Models with driver information interface


If there is a vehicle system failure, a message will also appear on the driver information interface, and you cannot change the mode.

*1: Models with driver information interface

* Not available on all models

Auto Idle Stop *

To help to maximise fuel economy, the engine automatically stops when the vehicle comes to a stop, depending on environmental and vehicle operating conditions. The indicator (green) comes on at this time.



The environmental and vehicle conditions that impact Auto Idle Stop system operation are varied.

► **Auto Idle Stop Activates When:** P. 292

The engine then restarts once the vehicle is about to move again, and the indicator (green) goes off.

► **The Engine Automatically Restarts When:** P. 293

If the driver's door is opened while the indicator (green) comes on, a buzzer sounds to notify you that the Auto Idle Stop function is in operation.

A message associated with Auto Idle Stop appears on the driver information interface.

►► Auto Idle Stop *

The 12-volt battery installed in this vehicle is specifically designed for a model with Auto Idle Stop. Using a 12-volt battery other than this specified type may shorten the 12-volt battery life, and prevent Auto Idle Stop from activating. If you need to replace the 12-volt battery, make sure to select the specified type. Ask a dealer for more details.

► **Specifications** P. 524

The duration of the Auto Idle Stop operation:

- Increases in the ECON mode, compared to when the ECON mode is off, with cooling system in use.


► **ECON Mode*** P. 289



A message appears on the driver information interface when the Auto Idle Stop system cannot be activated.

❏ **Auto Idle Stop System ON/OFF** P. 291

■ Auto Idle Stop System ON/OFF



To turn the Auto Idle Stop system off, press this button. The Auto Idle Stop system stops.

- ▶ Auto Idle Stop system will stop, the indicator will come on and a message appears on the driver information interface.

The Auto Idle Stop system is turned on every time you start the engine, even if you turned it off the last time you drove the vehicle.

❏ Auto Idle Stop System ON/OFF

If you turn off the Auto Idle Stop system while it is activated, the engine will restart.

❏ **Auto Idle Stop Activates When:** P. 292

If you press and hold the Auto Idle Stop **OFF** button, you can select whether to display the status messages or not.

■ Auto Idle Stop Activates When:

The vehicle stops with the shift lever in **[D]** and the brake pedal depressed. When you shift into **[P]** quickly with depressing the brake pedal, the Auto Idle Stop continues to operate, even if the brake pedal is released.

► If you depress the brake pedal, the engine may automatically restarts.

■ Auto Idle Stop does not activate when:

- The Auto Idle Stop **OFF** button is pressed.
- The driver's seat belt is not fastened.
- The engine is not adequately warmed up or coolant temperature is high.
- The transmission fluid temperature is low or high.
- The vehicle comes to a stop again before the vehicle speed reaches 5 km/h after the engine starts.
- The vehicle is stopped on a steep incline.
- The transmission is in a position other than **[D]**.
- The engine is started with the bonnet open.
 - Turn off the engine. Close the bonnet before you restart the engine to activate Auto Idle Stop.
- The battery charge is low.
- The internal temperature of the battery is 5°C or less.
- The **MAX COOL** button is ON.
-  is on with the fan operating.

■ Auto Idle Stop may not activate when:

- The vehicle is stopped by braking suddenly.
- The steering wheel is operated.
- The vehicle is repeatedly accelerated and decelerated at a low speed.

►► Auto Idle Stop Activates When:

Do not open the bonnet while the Auto Idle Stop function is activated. If the bonnet is opened, the engine will not restart automatically. In this case, restart the engine with the **ENGINE START/STOP** button.

► **Starting the Engine** P. 272

Pressing the **ENGINE START/STOP** button causes the engine to no longer restart automatically. Follow the standard procedure to start the engine.

► **Starting the Engine** P. 272

■ The Engine Automatically Restarts When:

- The brake pedal is released.
- When the transmission is put into **[P]** from **[D]** or **[N]** on a slope.

■ The engine restarts even if the brake pedal is depressed when:

- The Auto Idle Stop **OFF** button is pressed.
- The steering wheel is operated.
- The transmission is put into **[R]** or **[S]**, or when it is set from **[N]** to **[D]**.
 - ▶ If you put the transmission into **[P]** after the Auto Idle Stop activates, the Auto Idle Stop continues to operate. In this case, the engine restarts when you depress the brake pedal.
- The pressure on the brake pedal is reduced and the vehicle starts moving while stopped on an incline.
- The brake pedal is released slightly during a stop.
- The battery charge becomes low.
- The accelerator pedal is depressed.
- The driver's seat belt is unlatched.
- The **MAX COOL** button is ON.
-  is on with the fan operating.

■ Starting Assist Brake Function

Briefly keeps the brake applied after releasing the brake pedal to restart the engine. This can keep your vehicle from unexpectedly moving while on an incline.

⌘ The Engine Automatically Restarts When:

If you are using an electronic device during Auto Idle Stop, the device may temporarily be turned off when the engine restarts.

Cruise Control*

Maintains a constant vehicle speed without having to keep your foot on the accelerator. Use cruise control on motorways or open roads where you can travel at a constant speed with little acceleration or deceleration.

When to use

- Vehicle speed for cruise control:
Desired speed in a range above roughly 40 km/h
- Shift positions for cruise control:
In **D** or **S**


Always keep sufficient distance between you and the vehicle in front of you.



How to use

CRUISE MAIN is on in the instrument panel.
Cruise control is ready to use.

- Press the **CRUISE** button on the steering wheel.



» Cruise Control*

⚠ WARNING

Improper use of the cruise control can lead to a crash.


Use the cruise control only when travelling on open motorways in good weather.

It may not be possible to maintain a constant speed when driving uphill or downhill.

When not using cruise control:
Turn off cruise control by pressing the **CRUISE** button.

While in **ECON** mode, it may take relatively more time to accelerate to maintain the set speed.

■ To Set the Vehicle Speed




Take your foot off the pedal and press the **SET/-** button when you reach the desired speed.

The moment you release the **SET/-** button, the set speed is fixed, and cruise control begins. The **CRUISE CONTROL** indicator comes on.

■ To Adjust the Vehicle Speed

Increase or decrease the vehicle speed using the **RES/+** or **SET/-** buttons on the steering wheel.




- Each time you press the **RES/+** or **SET/-** button, the vehicle speed is increased or decreased by about 1.6 km/h.
- If you keep the **RES/+** or **SET/-** button pressed, the vehicle speed increases or decreases until you release it. This speed is then set.

►► To Adjust the Vehicle Speed

You can set the vehicle speed using the **SET/-** button on the steering wheel when adjusting the speed with the accelerator and brake pedals.

■ To Cancel



To cancel cruise control, do any of the following:

- Press the **CANCEL** button.
- Press the **CRUISE** button.
- Depress the brake pedal.

The **CRUISE CONTROL** indicator goes off.

☒ To Cancel

Resuming the prior set speed:

After cruise control has been cancelled, you can still resume the prior set speed by pressing the **RES/+** button while driving at a speed of at least 40 km/h or more.

You cannot set or resume in the following situations:


- When vehicle speed is less than 40 km/h
- When the **CRUISE** button is turned off

At vehicle speeds of 35 km/h or less, cruise control is cancelled automatically.

Vehicle Stability Assist (VSA) System

VSA helps to stabilise the vehicle during cornering if the vehicle turns more or less than what was intended. It also assists in maintaining traction on slippery surfaces. It does so by regulating engine output and selectively applying the brakes.

VSA Operation



When VSA activates, you may notice that the engine does not respond to the accelerator. You may also notice some noise from the hydraulic brake system. You will also see the indicator blink.

►► Vehicle Stability Assist (VSA) System

The VSA may not function properly if tyre type and size are mixed. Make sure to use the same size and type of tyre, and the air pressures as specified.


When the VSA system indicator comes on and stays on while driving, there may be a problem with the system. While this may not interfere with normal driving, have your vehicle checked by a dealer immediately.

VSA cannot enhance stability in all driving situations and does not control the entire braking system. You still need to drive and corner at speeds appropriate for the conditions and always leave a sufficient margin of safety.

The main function of the VSA system is generally known as Electronic Stability Control (ESC). The system also includes a traction control function.

The Adaptive Cruise Control (ACC)*, vehicle stability assist (VSA) system, vehicle stability assist (VSA) **OFF**, safety support*, low tyre pressure/deflation warning system*, Collision Mitigation Braking System (CMBS)*, and Road Departure Mitigation* indicator may come on in amber along with a message in the driver information interface when you set the power mode to ON after reconnecting the battery. Drive a short distance at more than 20 km/h (12 mph). Each indicator should go off. If any do not, have your vehicle checked by a dealer.

■ VSA On and Off



This button is on the driver side control panel. To partially disable VSA functionality/features, press and hold it until you hear a beep.

Your vehicle will have normal braking and cornering ability, but traction control function will be less effective.

To restore VSA functionality/features, press the  (VSA **OFF**) button until you hear a beep.

VSA is turned on every time you start the engine, even if you turned it off the last time you drove the vehicle.

▣ Vehicle Stability Assist (VSA) System

In certain unusual conditions when your vehicle gets stuck in shallow mud or fresh snow, it may be easier to free it with the VSA temporarily switched off.

When the  (VSA **OFF**) button is pressed, the traction control function becomes less effective. This allows for the wheels to spin more freely at low speed. You should only attempt to free your vehicle with the VSA off if you are not able to free it when the VSA is on.

Immediately after freeing your vehicle, be sure to switch VSA on again. We do not recommend driving your vehicle with the VSA system switched off.

You may hear a motor sound coming from the engine compartment while system checks are being performed immediately after starting the engine or while driving. This is normal.

Agile Handling Assist

Lightly brakes the front wheels, as needed, when you turn the steering wheel, and helps support the vehicle's stability and performance during cornering.

» Agile Handling Assist

The agile handling assist cannot enhance stability in all driving situations. You still need to drive and corner at speeds appropriate for the conditions and always leave a sufficient margin of safety.


When the VSA system indicator comes on and stays on while driving, the agile handling assist does not activate.

You may hear a sound coming from the engine compartment while the agile handling assist is activated. This is normal.

Deflation Warning System *

Instead of directly measuring the pressure in each tyre, the deflation warning system on this vehicle monitors and compares the rolling radius and rotational characteristics of each wheel and tyre while you are driving to determine if one or more tyres are significantly under-inflated.

Models with information display



This will cause the low tyre pressure/deflation warning system indicator to come on.

Deflation Warning System *

The system does not monitor the tyres when driving at low speed.

Conditions such as low ambient temperature and altitude change directly affect tyre pressure and can trigger the low tyre pressure/deflation warning system indicator to come on.

Tyre pressure checked and inflated in:

- Warm weather can become under-inflated in colder weather.
- Cold weather can become overinflated in warmer weather.

The low tyre pressure/deflation warning system indicator will not come on as a result of overinflation.

The deflation warning system may not function properly if tyre type and size are mixed.


Make sure to use the same size and type of tyre.

➤ **Checking and Maintaining Tyres** P. 439

The low tyre pressure/deflation warning system indicator may come on with a delay or may not come on at all when:

- You rapidly accelerate, decelerate, or turn the steering wheel.
- You drive on snowy or slippery roads.
- Tyre chains* are used.
- The tyre loses air pressure rapidly.

* Not available on all models



*1: Except Mexican models

*2: Mexican models

* Not available on all models

This will cause the low tyre pressure/deflation warning system indicator to come on and a message to appear on the driver information interface.

►► Deflation Warning System*

The low tyre pressure/deflation warning system indicator may come on under the following conditions:

- A temporary spare tyre*/compact spare tyre* is used.
- Tyre chains* are used.

The Adaptive Cruise Control (ACC)*, vehicle stability assist (VSA) system, vehicle stability assist (VSA) **OFF**, safety support*, low tyre pressure/deflation warning system, Collision Mitigation Braking System (CMBS)*, and Road Departure Mitigation* indicator may come on in amber along with a message in the driver information interface when you set the power mode to ON after reconnecting the battery.

Drive a short distance at more than 20 km/h (12 mph). Each indicator should go off. If any do not, have your vehicle checked by a dealer.

Deflation Warning System Initialisation/Calibration

You must start deflation warning system initialisation/calibration every time you:

- Adjust the pressure in one or more tyres.
- Rotate the tyres.
- Replace one or more tyres.

Before initialising/calibrating the deflation warning system:

- Set the cold tyre pressure in all four tyres.

🔧 **Checking Tyres** P. 439

Make sure:

- The vehicle is at a complete stop.

Continuously variable transmission models

- The shift lever is in **P**.

Manual transmission models

- The shift lever is in **N**.

All models

- The power mode is in ON.

Deflation Warning System Initialisation/Calibration

Deflation warning system cannot be initialised/calibrated if a temporary spare tyre*/compact spare tyre* is installed.

The initialisation/calibration process requires approximately 30 minutes of cumulative driving at speeds between 40–100 km/h (25–62 mph).


During this period, if the engine is turned on and the vehicle is not moved within 45 seconds, you may notice the low tyre pressure/deflation warning system indicator comes on briefly. This is normal and indicates that the initialisation/calibration process is not yet complete.

If the tyre chains* are installed, remove them before initialising/calibrating the deflation warning system.

If the low tyre pressure/deflation warning system indicator comes on even when the properly inflated specified regular tyres are installed, have your vehicle checked by a dealer.

We recommend that the tyres be replaced with the same brand, model, and size as the originals. Ask a dealer for details.


* Not available on all models



Models with information display

Press and hold the deflation warning system button until the low tyre pressure/deflation warning system indicator blinks twice, indicating the calibration process has begun.

- If the low tyre pressure/deflation warning system indicator does not blink, confirm the above conditions then press and hold the deflation warning system button again.
- The calibration process finishes automatically.




A-type meter

You can initialise the system from the customized features on the driver information interface.

1. Press (home) button.
2. Roll the left selector wheel controls to select , then push the left selector wheel.
▶ appears on the display.
3. Roll the left selector wheel controls to select **Deflation warning system/TPMS calibration**, then push the left selector wheel.
▶ The display switches to the customization setup screen, where you can select **Cancel** or **Initialise/Calibrate**.
4. Roll the left selector wheel controls to select **Initialise/Calibrate**, then push the left selector wheel.
▶ **Completed/Calibration started** screen appears, then the display returns to the customization setup screen.

- If the **Failed/Calibration failed to start** message appears, repeat steps 3 – 4.
- The initialisation process finishes automatically.

Continued




Except Mexican models with B-type meter

You can initialise the system from the customized features on the driver information interface.

1. Press (home) button.
2. Roll the left selector wheel controls to select , then push the left selector wheel.
► appears on the display.
3. Roll the left selector wheel controls to select **Deflation Warning System**, then push the left selector wheel.
► The display switches to the customization setup screen, where you can select **Cancel** or **Initialise**.
4. Roll the left selector wheel controls to select **Initialise**, then push the left selector wheel.
► **Completed** screen appears, then the display returns to the customization setup screen.

- If the **Failed** message appears, repeat steps 3 – 4.
- The initialisation process finishes automatically.



Mexican models with B-type meter

You can calibrate the system from the customized features on the driver information interface.

1. Press  (home) button.
2. Roll the left selector wheel controls to select , then push the left selector wheel.
▶  appears on the display.
3. Roll the left selector wheel controls to select **TPMS Calibration**, then push the left selector wheel.
▶ The display switches to the customization setup screen, where you can select **Cancel** or **Calibrate**.
4. Roll the left selector wheel controls to select **Calibrate**, then push the left selector wheel.
▶ **Calibration Started** screen appears, then the display returns to the customization setup screen.

- If the **Calibration Failed To Start** message appears, repeat steps 3 – 4.
- The calibration process finishes automatically.

Assists with functions such as acceleration, braking, and steering in order to reduce the burden on the driver, as well as help to avoid or reduce the severity of collisions.

Honda SENSING has the following functions:

■ The functions that do not require switch operations to activate

- Collision Mitigation Braking System (CMBS) ➡ P. 311
- Road Departure Mitigation System ➡ P. 325
- Lead Car Departure Notification System* ➡ P. 368
- Auto High-Beam ➡ P. 219
- Parking Sensor System* ➡ P. 383

■ The functions that require switch operations to activate

- Adaptive Cruise Control (ACC) ➡ P. 337
- Lane Keeping Assist System (LKAS) ➡ P. 355

➡ Honda SENSING*


Make sure that all the tyres are of the same specified size, type, and brand, and that they are evenly worn. If you use tyres of different sizes, types, brands, or degree of wear, the system may not work properly.

Do not modify the suspension. Altering the height of the vehicle may prevent the system from working properly.

Thai models

CAUTION: This equipment should be operated keeping the radiator at least 20 cm or more away from person's body (excluding extremities: hands, wrists, feet and ankles).
This telecommunication equipment conforms to NTC technical requirement.
This telecommunication equipment has EMF radiation conforms to NTC EMF exposure standard.

■ Operation Switches for the Adaptive Cruise Control (ACC)/ Lane Keeping Assist System (LKAS)



■ Button

Press to activate standby mode for ACC.
Or press to cancel the system.

■ **LKAS Button**

Press to activate standby mode for LKAS.
Or press to cancel the system.

■ **RES/+ and SET/- Buttons**

Press **RES/+** button to set or resume the ACC or increase the vehicle speed.
Press **SET/-** button to set the ACC or decrease the vehicle speed.

■ **Interval Button**


Press to change the ACC following-interval.

■ **CANCEL Button**

Press to cancel ACC.

Gauge Content

You can see the current state of ACC and LKAS.



- ① Indicates that ACC is ready to be activated.
 - Green: The system is on.
 - White: The system is standby.
 - Amber: There is a problem with the system.
- ② Indicates that LKAS is ready to be activated.
 - Green: The system is operating.
 - White: The system is standby.
 - Amber: There is a problem with the system.
- ③ Indicates that LKAS is activated and whether or not traffic lane lines are detected.
 - Green lines: The system is operating.
 - White lines: Traffic lane lines are detected.
 - Amber line: Lane departure is detected.
- ④ Indicates whether or not ACC detected the vehicle ahead.
- ⑤ Indicates that ACC shows the set vehicle speed.
 - White: Set Vehicle Speed
 - Grey: Prior Set Speed
- ⑥ Indicates that ACC shows the set vehicle interval.

Collision Mitigation Braking System (CMBS)

The system can assist you when it determines there is a possibility of your vehicle colliding with a vehicle (including motorcycles) ahead from behind, an oncoming vehicle in front, a vehicle approaching from the side, a pedestrian, or someone riding a bicycle (moving bicycle). The CMBS is designed to alert you when the potential for a collision is determined, as well as assist in reducing speed, avoiding collisions, and reducing collision severity.

⌘ Collision Mitigation Braking System (CMBS)

Important Safety Reminder

The CMBS is designed to reduce the severity of an unavoidable collision. It does not prevent collisions nor stop the vehicle automatically. It is still your responsibility to operate the brake pedal and steering wheel appropriately according to the driving conditions.

The CMBS may not activate or may not detect a vehicle in front of your vehicle under certain conditions:

➤ **CMBS Conditions and Limitations** P. 316

You can read about handling information for the front wide view camera equipped with this system.


➤ **Front Wide View Camera** P. 374

Manual transmission models

When the CMBS activates, the engine may stop automatically. Start the engine by normal operation if the engine stops.

■ How the system works

When to use



The system starts monitoring the roadway ahead when your vehicle speed is about 5 km/h (3 mph) or above and will search for a vehicle (including motorcycles), pedestrian, or moving bicycle in front of you.

The CMBS activates when:

- The speed difference between your vehicle and a vehicle (including motorcycles), pedestrian, or moving bicycle detected in front of you becomes about 5 km/h (3 mph) and over with a chance of a collision.
- Your vehicle drives at about 30 km/h (18 mph) or less and there is a chance of a frontal collision with a detected oncoming vehicle (including motorcycles), pedestrian, or moving bicycle when you turn right*1/left*2 at an intersection.
- Your vehicle speed is about 100 km/h (62 mph) or less and the system determines there is a chance of a collision with:
 - An oncoming or stationary vehicle detected in front of you.
 - A pedestrian or moving bicycle detected in front of you.
 - A vehicle approaching from the side in front of you.

The CMBS will be cancelled when your vehicle stops or the system determines there no longer is the potential for a collision.

The CMBS may also be cancelled when a driver operates the steering wheel and the brake or accelerator pedal to avoid a collision.

*1: Right-hand Drive Type

*2: Left-hand Drive Type

▶▶ How the system works


The front wide view camera in the CMBS is also designed to detect pedestrians. However, this pedestrian detection feature may not activate or may not detect a pedestrian in front of your vehicle under certain conditions. Refer to the ones indicating the pedestrian detection limitations from the list.

▶ **CMBS Conditions and Limitations** P. 316

■ When the system activates

The system provides visual and audible alerts of a possible collision, and stops if the collision is avoided.

- ▶ Take appropriate action to prevent a collision (apply the brakes, change lanes, etc.)





You can change the distance (**Long/Normal/Short**, **Far/Normal/Near**) between vehicles at which the system's earliest collision alert will come on.

📖 **Settings** P. 142, 167

When in **Long/Far**, visual and audible alerts come on at a longer distance from a vehicle ahead than in **Normal** setting, and in **Short/Near**, at a shorter distance than in **Normal**.

■ Collision Alert Stages

The system has three alert stages for a possible collision. However, depending on circumstances, the CMBS may not go through all of the stages before initiating the last stage.

Distance between vehicles		CMBS		
		The sensors detect a vehicle	Audible & Visual WARNINGS	Braking
Stage one		There is a risk of a collision with the vehicle ahead of you.	The visual alert flashes. If the distance between your vehicle and the vehicle in front of you continues to decrease, the audible alert sounds in addition to the visual alert flashing. ▶ The collision warning distance can be changed. ➤ Settings P. 142, 167	—
Stage two		The risk of a collision has increased, time to respond is reduced.	Visual and audible alerts.	Lightly applied
Stage three		The CMBS determines that a collision is unavoidable.		Forcefully applied

■ CMBS On and Off

You can turn the system on and off using the driver information interface.

➤ **Switching the Display** P. 131

➤ **Safety Support*** P. 139

The CMBS is turned on every time you start the engine, even if you turned it off the last time you drove the vehicle.

☒ Collision Mitigation Braking System (CMBS)

You cannot turn the CMBS off while driving.

The CMBS may automatically shut off, and the safety support indicator (amber) and Collision Mitigation Braking System (CMBS) indicator (amber) will come and stay on under certain conditions.

➤ **CMBS Conditions and Limitations** P. 316

The CMBS is not activated for about 15 seconds after the engine starts.

When the CMBS is activated, it will continue to operate even if the accelerator pedal is partially depressed. However, it will be cancelled if the accelerator pedal is fully depressed.

The Adaptive Cruise Control (ACC), vehicle stability assist (VSA) system, vehicle stability assist (VSA) **OFF**, safety support, low tyre pressure/deflation warning system*, Collision Mitigation Braking System (CMBS), and Road Departure Mitigation indicator may come on in amber along with a message in the driver information interface when you set the power mode to ON after reconnecting the battery. Drive a short distance at more than 20 km/h (12 mph). Each indicator should go off. If any do not, have your vehicle checked by a dealer.

* Not available on all models

■ CMBS Conditions and Limitations

In the following situations, the front wide view camera may be unable to correctly detect vehicles, pedestrians, moving bicycles, or road conditions, potentially causing the CMBS to operate improperly.

📷 **Front Wide View Camera** P. 374

■ Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes between light and dark, such as the entrance or exit of a tunnel or the shadows of trees, buildings, etc.
- There is little contrast between objects and the background.
- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the vehicles (including motorcycles), pedestrians, moving bicycles, or road surfaces.
- Roadway objects or structures are misinterpreted as vehicles and pedestrians.
- Water is sprayed by or snow blown from a vehicle ahead.
- Driving at night or in a dark place such as a tunnel (due to low-light conditions, vehicles [including motorcycles], pedestrians, or moving bicycles may not be illuminated).

■ Roadway conditions

- Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).
- Driving on curvy, winding, or undulating roads.
- The road is hilly or the vehicle is approaching the crest of a hill.
- Your vehicle is strongly shaken on uneven road surfaces.

» CMBS Conditions and Limitations

Have your vehicle checked by a dealer if you find any unusual behaviour of the system (e.g., the warning message appears too frequently).

■ Vehicle conditions

- Tyre chains* are installed.
- Driving at night or in a dark place (e.g., a tunnel) with the headlights off.
- The front wide view camera is obstructed by dirt, fog, rain, mud, wet snow, accessories, decals, stickers, film, etc.
- There is residue on the windscreen from the windscreen wipers.
- When lighting is weak due to dirt covering the headlight lenses, or there is poor visibility in a dark place due to the headlights being improperly adjusted.
- An abnormal tyre or wheel condition (incorrect sizes, varied sizes or construction, improperly inflated, compact spare tyre*/temporary spare tyre*, etc.).
- The vehicle is tilted due to heavy luggage in the boot or rear seats.
- The suspension has been modified.
- Driving with the parking brake applied.
- Camera vision is blocked by drops of water from the window washer, or by the wiper blades.
- Operation of the vehicle is unstable due to a slippery road, etc.

* Not available on all models

■ **Examples of limitations on the correct detection of the front wide view camera due to the condition of the vehicle ahead of you, oncoming vehicles, vehicles approaching from the side, pedestrians, or moving bicycles**

- The distance between your vehicle and the vehicle (including motorcycles) ahead of you, oncoming vehicle, vehicle approaching from the side, pedestrian, or moving bicycle ahead of you is too short.
- The vehicle (including motorcycles) ahead of you, oncoming vehicle, vehicle approaching from the side, pedestrian, or moving bicycle suddenly cuts in front of or jumps out in front of you.
- A bicycle or sideways-facing vehicle is stopped.
- The oncoming vehicle or vehicle (including motorcycles) ahead of you is sideways or facing diagonally.
- When the vehicle (including motorcycles) ahead of you, oncoming vehicle, vehicle approaching from the side, pedestrian, or moving bicycle blends in with the background, preventing the system from recognising them.
- When several pedestrians are moving ahead of you in a group.
- When several bicycles are moving ahead of you in a group.
- When a pedestrian or moving bicycle crosses the road too quickly.
- A pedestrian or moving bicycle approaches from the opposite direction.
- The headlights of the vehicle ahead of you or oncoming vehicle are lit on one side or not lit on either side in a dark place.
- When part of a pedestrian (heads, limbs, etc.) is hidden by a carried object.
- When a pedestrian is bent over or squatting, when their hands are raised, or they are running.

- When the pedestrian is shorter than about 1 metre or taller than about 2 metres in height.
- When the pedestrian is pushing a stroller or bicycle.
- A vehicle is approaching diagonally from the side.
- A specially-shaped vehicle (such as a tank lorry or a lorry without a load) is approaching from the side.
- A vehicle approaching from the side is driving on a curve or hill.

■ Examples of other limitations on detection or system operation

- When the vehicle (including motorcycles) ahead of you is a small motorcycle, motorcycle with a sidecar, wheelchair, three-wheeled vehicle*, or other specially shaped vehicle.
- When a vehicle is lower in the rear than the front such as lorries that are not carrying a load, or a narrow vehicle.
- When the vehicle (including motorcycles) ahead of you, oncoming vehicle, pedestrian, or moving bicycle is not in front of the vehicle.
- The speed difference between your vehicle and the vehicle (including motorcycles) ahead of you, oncoming vehicle, pedestrian, or moving bicycle is significantly large.
- The speed difference between your vehicle and a vehicle (including motorcycles), pedestrian, or moving bicycle approaching from the side is significantly large.
- When the vehicle (including motorcycles) or moving bicycle in front of you slows suddenly.
- When the driver operates the brake pedal and steering wheel to avoid a collision.

* Not available on all models

- When you approach the vehicle (including motorcycles) ahead of you, oncoming vehicle, pedestrians, or moving bicycles while accelerating rapidly or operating the steering wheel (except when turning right*¹/left*² at an intersection etc.)*³.
- When the moving bicycle is a child-sized bicycle, folding bicycle, three-wheeler or other bicycle with small tyres, or a long bicycle like a tandem bicycle.
- When the front wide view camera cannot correctly identify the shape of the vehicle (including motorcycles) ahead of you, oncoming vehicle, vehicle approaching from the side, pedestrian, or moving bicycle.
- When a vehicle (including motorcycles) that has an extremely high minimum ground clearance is ahead of you or approaching from the side.

*1: Right-hand Drive Type

*2: Left-hand Drive Type

*3: When there is a possibility of a frontal collision with the oncoming vehicle while turning right*¹/left*², the CMBS is activated. However, it may not be activated if you suddenly turn the steering wheel.

■ Automatic shutoff

The CMBS may automatically shut itself off and the safety support indicator (amber) and Collision Mitigation Braking System (CMBS) indicator (amber) come and stay on when:

- You drive off-road or on a mountain road, or curved and winding road for an extended period.
- Driving in bad weather (rain, fog, snow, etc.).
- Driving with the parking brake applied.
- The front wide view camera temperature gets too high.
- The front wide view camera is obstructed by dirt, fog, rain, mud, wet snow, accessories, decals, stickers, film, etc.
- An abnormal tyre condition is detected (incorrect tyre size, flat tyre, etc.).


Once the conditions that caused the CMBS to shut off improve or are addressed (e.g., cleaning), the system comes back on.

■ With Little Chance of a Collision


Even if there is little chance of a collision, the CMBS may activate under the following conditions.

Also, the system may activate if it detects a possibility of collision with pedestrians, moving bicycles, or vehicles.


- Your vehicle approaches or passes another vehicle that is making a left or right turn.
- Your vehicle approaches another vehicle ahead of you and you change lanes to pass.



- When your vehicle approaches vehicles, pedestrians, or moving bicycles.
- When vehicles, pedestrians, or moving bicycles are passing in front of you.
- When you drive under a low structure or through a narrow gate at high speed.
- When there are traffic signs or structures such as guard rails beside the road along a curve.



- When driving through curves, your vehicle comes to a point where the oncoming vehicle is right in front of you.



- When approaching stationary vehicles or walls, such as when parking.

- A vehicle approaches from the side as it is driving through a curve.
- You pass by a vehicle (including motorcycles), pedestrian, or bicycle that is turning left or right.
- You pass in front of a vehicle (including motorcycles), pedestrian, or bicycle that is approaching from the side.
- A vehicle (including motorcycles), pedestrian, or bicycle turns left or right while approaching your vehicle from the side.
- You attempt to pass in front of a vehicle (including motorcycles) or bicycle while you are turning left or right.
- A vehicle (including motorcycles) or bicycle is attempting to pass in front of your vehicle while you are turning left or right.
- A vehicle (including motorcycles), pedestrian, or bicycle enters the path of your vehicle and stops in front of you.
- When you are turning left or right, a crossing pedestrian enters the path of your vehicle and stops in front of you.
- You pass close by the side of a vehicle parked on the street.

Road Departure Mitigation System

Except Mexican models

Alerts and helps to assist you when the system detects a possibility of your vehicle unintentionally crossing over detected lane markings and/or leaving the roadway altogether.

Mexican models

Alerts and helps to assist you when the system detects a possibility of your vehicle crossing over detected lane markings, or approaching the outer edge of the pavement (into grass or gravel border) or a detected oncoming vehicle.

⌘ Road Departure Mitigation System

Important Safety Reminder

Like all assistance systems, the Road Departure Mitigation system has limitations.

Overreliance on the Road Departure Mitigation system may result in a collision. It is always your responsibility to keep the vehicle within your driving lane.

Except Mexican models

The Road Departure Mitigation system only alerts you when lane drift is detected without a turn signal in use. The Road Departure Mitigation system may not detect all lane markings or lane or roadway departures; accuracy will vary based on weather, speed and lane marker condition. It is always your responsibility to safely operate the vehicle and avoid collisions.

Mexican models

The Road Departure Mitigation system alerts you when the system detects that you are approaching the outer edge of the pavement (into grass or gravel border), an oncoming vehicle, or drifting into another lane without using a turn signal.


The Road Departure Mitigation system may not detect all lane markings or every instance of lane drift.

The Road Departure Mitigation system may not detect that you are approaching the outer edge of the pavement (bordered by grass or gravel) or an oncoming vehicle.

The Road Departure Mitigation system may not be able to assist you depending on weather, speed or road conditions.

■ How the System Works

Except Mexican models



The front camera located behind the rearview mirror monitors left and right lane markings (in white or yellow). If your vehicle is getting too close to detected lane markings without a turn signal activated, the system, in addition to a visual alert, applies steering torque and alerts you with rapid vibrations on the steering wheel, to help you remain within the detected lane.

▶ **Settings** P. 142, 167

As a visual alert, the **Lane departure***¹/**Lane Departure***² message appears on the driver information interface.

The system cancels assisting operations when you turn the steering wheel to avoid crossing over detected lane markings.

*1: Models with A-type meter

*2: Models with B-type meter


▶▶ Road Departure Mitigation System

The Road Departure Mitigation system is not activated for about 15 seconds after the engine has been started.

You can read about handling information for the camera equipped with this system.

▶ **Front Wide View Camera** P. 374

Mexican models



The front camera behind the rearview mirror monitors left and right lane markings in white or yellow, the outer edge of the pavement (bordered by grass or gravel) or a detected oncoming vehicles.

If your vehicle approaches any detected lane markings, the outer edge of the pavement (bordered by grass or gravel) or a detected oncoming vehicles when the turn signals have not been engaged, the system activates.

- ▶ If the system cannot detect lane markings (in white or yellow), no assistance will be provided to avoid approaching oncoming vehicles. In addition to a visual alert, the system assists with steering and alerts you with rapid steering wheel vibrations to help you remain within the detected lane.

📖 **Settings** P. 167

As a visual alert, the **Lane departure***1/**Lane Departure***2 message appears on the driver information interface.

*1: Models with A-type meter

*2: Models with B-type meter

⌘ Road Departure Mitigation System

The Road Departure Mitigation system may not work properly or may work improperly under the certain conditions:

📖 **Road Departure Mitigation System Conditions and Limitations** P. 333

There are times when you may not notice the Road Departure Mitigation system functions due to your operation of the vehicle, or road surface conditions.

Mexican models

The system cancels assisting operations when you turn the steering wheel to avoid crossing over detected lane markings or approaching the outer edge of the pavement (into grass or gravel border) or an oncoming vehicle.

»» Road Departure Mitigation System

Except Mexican models

You can change the settings for the Road Departure Mitigation system.

If LKAS is off, the message below may appear if the system has determined that there is a possibility of your vehicle crossing over detected lane markings.

➡ **Settings** P. 142, 167


Mexican models

You can change the settings for the Road Departure Mitigation system.

If LKAS is off, the message below may appear if the system has determined that there is a possibility of your vehicle crossing over detected lane markings, the outer edge of the pavement (into a grass or gravel border) or oncoming vehicle.

➡ **Settings** P. 167

Models with A-type meter



Except Mexican models with A-type meter




If the system operates several times without detecting driver response, the system beeps to alert you. After that, the Road Departure Mitigation steering assist is temporarily stopped, and the system will only alert you with the warning sound.

After a few minutes, the message to the left is displayed and the Road Departure Mitigation system is fully restored.

*1: Mexican models

*2: Except Mexican models

▶▶ Road Departure Mitigation System



Except Mexican models with B-type meter



If the system operates several times without detecting driver response, the system beeps to alert you. After that, the Road Departure Mitigation System Steering Assist Auto OFF indicator comes on, the Road Departure Mitigation steering assist is temporarily stopped, and the system will only alert you with the warning sound.

After a few minutes, the Road Departure Mitigation System Steering Assist Auto OFF indicator goes off and the Road Departure Mitigation system is fully restored.

Mexican models with B-type meter

If the system operates several times without detecting driver response, the system beeps to alert you.

How the System Activates

The system activates when all of the following conditions are met:

- The vehicle is on a straight or slightly curved road.
- The turn signals are off.
- The system makes a determination that the driver is not actively accelerating, braking, or steering.
- The lane markings are white (yellow).

Except Mexican models

The vehicle is travelling between about 72 and 180 km/h.

Mexican models

The vehicle is travelling between about 72 and 145 km/h (45 and 90 mph).

▶ When oncoming vehicles are running

The vehicle is travelling between about 72 and 145 km/h (45 and 90 mph).

Mexican models

- The outer edge of the pavement is grass or gravel border.
The vehicle is travelling between about 72 and 145 km/h (45 and 90 mph).

How the System Activates

The Road Departure Mitigation system may automatically shut off and the safety support indicator (amber) and Road Departure Mitigation indicator (amber)* come and stay on.

➤ **Indicators** P. 102

The Road Departure Mitigation system function can be impacted when the vehicle is:

- Driven on the inside edge of a curve, or outside of a lane.
- Driven in a narrow lane.

■ Road Departure Mitigation System On and Off

You can turn the system on and off using the driver information interface.

➡ **Switching the Display** P. 133

➡ **Safety Support*** P. 139

Except Indian, Bhutanese, Nepalese models

The Road Departure Mitigation system is in the previously selected on or off setting each time you start the engine.

Indian, Bhutanese, Nepalese models

The Road Departure Mitigation system is turned on every time you start the engine, even if you turned it off the last time you drove the vehicle.

» Road Departure Mitigation System On and Off

Except Indian, Bhutanese, Nepalese models

When you have selected **Warning only***¹/**Warning Only***², the system does not operate the steering wheel.

➡ **Settings** P. 142, 167

All models

The Adaptive Cruise Control (ACC), vehicle stability assist (VSA) system, vehicle stability assist (VSA) **OFF**, safety support, low tyre pressure/deflation warning system*, Collision Mitigation Braking System (CMBS), Road Departure Mitigation indicator may come on in amber along with a message in the driver information interface when you set the power mode to ON after reconnecting the battery.

Drive a short distance at more than 20 km/h (12 mph). Each indicator should go off. If any do not, have your vehicle checked by a dealer.

*1: Models with A-type meter

*2: Models with B-type meter

* Not available on all models

Road Departure Mitigation System Conditions and Limitations

Except Mexican models

The system may not properly detect lane markings and the position of your vehicle under certain conditions. Some examples of these conditions are listed below.

Mexican models

The system may not properly detect lane markings (in white or yellow), the outer edge of the pavement (into grass or gravel border) or an oncoming vehicle under certain conditions. Some examples of these conditions are listed below.

■ Environmental conditions

- There is little contrast between lane lines and the roadway surface.
- Driving in bad weather (rain, fog, snow, etc.).
- Driving on a snowy or wet roadway.
- Driving into low sunlight (e.g., at dawn or dusk).
- Shadows of adjacent objects (trees, buildings, guard rails, vehicles, etc.) are parallel to white (or yellow) lines.
- Sudden changes between light and dark, such as the entrance or exit of a tunnel or the shadows of trees, buildings, etc.
- Strong light is reflected onto the roadway.
- Driving at night or in a dark place such as a tunnel (due to low-light conditions, lane lines, the road surface, or oncoming vehicles may not be illuminated).
- The distance between your vehicle and the vehicle ahead of you is too short, and lane lines and the road surface are not visible.

Mexican models

- The outer edge of the road is bordered by objects, materials, etc. other than grass or gravel.

Continued

■ Roadway conditions

- Driving on a road with temporary lane markings.
- Faint, multiple, or varied lane markings are visible on the roadway due to road repairs or deteriorated lane markings.
- The roadway has merging, split, or crossing lines, such as at an intersection or crosswalk.
- The lane markings are extremely narrow, wide, or changing.
- Part of the lane markings are hidden by an object, such as a vehicle.
- The road is hilly or the vehicle is approaching the crest of a hill.
- Your vehicle is strongly shaken on uneven road surfaces.
- When objects on the road (curb, guard rail, pylons, etc.) are recognised as white (or yellow) lines.
- Driving on rough or unpaved roads, or over bumpy surfaces.
- Driving on roads with double lane lines.
- Driving on snowy or slippery roads.
- Passing through a junction.
- The pavement is only partially visible due to snow or puddles on the road.
- Driving on unpaved or rutted roads.
- White (or yellow) lines are not recognised correctly due to road conditions such as curves, twists, or hills.

■ Vehicle conditions

- When lighting is weak due to dirt covering the headlight lenses, or there is poor visibility in a dark place due to the headlights being improperly adjusted.
- The front of the camera is obstructed by dirt, fog, rain, mud, wet snow, accessories, decals, stickers, film, etc.
- Driving at night or in a dark place (e.g., a tunnel) with the headlights off.
- When the driver operates the brake pedal and steering wheel.
- There is residue on the windscreen from the windscreen wipers.
- An abnormal tyre or wheel condition (incorrect sizes, varied sizes or construction, improperly inflated, compact spare tyre*/temporary spare tyre*, etc.).
- The vehicle is tilted due to heavy luggage in the boot or rear seats.
- Tyre chains* are installed.
- The suspension has been modified.

Mexican models

■ Examples of limitations on detection due to the condition of oncoming vehicles

- The oncoming vehicle or vehicle ahead of you is sideways.
- The oncoming vehicle jumps out in front of you.
- When the oncoming vehicle blends in with the background, preventing the system from recognising it.
- The headlights of an oncoming vehicle are lit on one side or not lit on either side in a dark place.
- The distance between your vehicle and the oncoming vehicle is too short.
- Part of the oncoming vehicle is not visible due to the vehicle ahead of you.
- There are multiple oncoming lanes or turning lanes.
- The vehicle in the adjacent lane is parked or moving at an extremely slow speed.

* Not available on all models

Mexican models

■ Examples of other limitations on detection or system operation

- When the oncoming vehicle is specially-shaped.
- When the camera cannot correctly identify the shape of the oncoming vehicle.

Mexican models

■ With Little Chance of a Collision

The Road Departure Mitigation system may activate in the below conditions.

- When driving through curves, your vehicle comes to a point where an oncoming vehicle is right in front of you.

Adaptive Cruise Control (ACC)

Helps to maintain a constant vehicle speed and a set following-interval behind a vehicle detected ahead of yours, without you having to keep your foot on the brake or the accelerator.

When ACC slows your vehicle by applying the brakes, your vehicle's brake lights will illuminate.

When to use



The front wide view camera is located behind the rearview mirror.



■ Vehicle speed for ACC: Desired speed in a range above roughly 30 km/h (18 mph)

Continuously variable transmission models

■ Shift position for ACC: In **D** or **S**

Manual transmission models

■ Shift position for ACC: In **2** or higher position

Adaptive Cruise Control (ACC)

⚠ WARNING

Improper use of ACC can lead to a crash.

Use ACC only when driving on motorways and in good road and weather conditions.

⚠ WARNING

ACC has limited braking capability. When your vehicle speed drops below 25 km/h (16 mph), ACC will automatically cancel and no longer will apply your vehicle's brakes. Always be prepared to apply the brake pedal when conditions require.

Important Reminder


As with any system, there are limits to ACC. Use the brake pedal whenever necessary, and always keep a safe interval between your vehicle and other vehicles.

You can read about handling information for the camera equipped with this system.

📖 **Front Wide View Camera** P. 374

■ How to activate the system

How to use



▶ Adaptive Cruise Control (ACC)

ACC may not work properly under certain conditions.

▶ **ACC Conditions and Limitations** P. 345

When not using ACC: Turn off adaptive cruise by pressing the button.

Do not use ACC under the following conditions:

- On roads with frequent lane change or continuous stop and go traffic, ACC cannot keep an appropriate distance between your vehicle and the vehicle ahead of you.
- On roads with sharp turns.
- On roads with steep downhill sections, as the set vehicle speed can be exceeded by coasting. In such cases, ACC will not apply the brakes to maintain the set speed.
- On roads with toll collection facilities or other objects between lanes of traffic, or in parking areas, or facilities with drive through access.
- On roads with bad weather (rain, fog, snow, etc.), ACC may not detect the distance between your vehicle and the vehicle ahead of you properly.
- On roads with slippery or icy surfaces. The wheels may spin out and your vehicle may lose the control on the condition.

» Adaptive Cruise Control (ACC)

The Adaptive Cruise Control (ACC), vehicle stability assist (VSA) system, vehicle stability assist (VSA) **OFF**, safety support, low tyre pressure/deflation warning system*, Collision Mitigation Braking System (CMBS), and Road Departure Mitigation indicator may come on in amber along with a message in the driver information interface when you set the power mode to ON after reconnecting the battery.


Drive a short distance at more than 20 km/h (12 mph). Each indicator should go off. If any do not, have your vehicle checked by a dealer.

Manual transmission models

When the engine speed slows down, try to downshift.

When the engine speed goes up, try to upshift. You can maintain the set speed if you change gear within five seconds.

■ To Set the Vehicle Speed



Take your foot off the pedal and press the **RES/+** or **SET/-** button when you reach the desired speed.

The moment you release the **RES/+** or **SET/-** button, the set speed is fixed, and ACC begins.

*1: Models with A-type meter

*2: Models with B-type meter


▶▶ To Set the Vehicle Speed

Mexican models

You can switch the displayed set speed measurements on the driver information interface between km/h and mph.

▶ **Speedometer** P. 128

▶ **Settings** P. 142, 167




When ACC starts operating, the vehicle icon, interval bars and set speed appear on the gauge.

■ When in Operation

■ There is a vehicle ahead


ACC monitors if a vehicle ahead of you enters the ACC range. If a vehicle is detected doing so, the ACC system maintains or decelerates your vehicle's set speed in order to keep the vehicle's set following-interval from the vehicle ahead.

➤ **To Set or Change Following-interval** P. 350




» When in Operation


If the vehicle ahead of you slows down abruptly, or if another vehicle cuts in front of you, the beeper sound and a message appears on the driver information interface.



Depress the brake pedal, and keep an appropriate interval from the vehicle ahead.




Models with A-type meter



Set Vehicle Speed

A vehicle icon appears on the gauge.

Models with B-type meter



Set Vehicle Speed

A vehicle icon appears on the gauge.

When a vehicle whose speed is slower than your set speed comes in or cuts in front of you and is detected by the camera, your vehicle starts to slow down.

When in Operation

Even if the interval between your vehicle and the vehicle detected ahead is short, ACC may start accelerating your vehicle under the following circumstances:

- The vehicle ahead of you is going at almost the same speed as, or faster than, your vehicle.
- A vehicle that cuts in front of you is going faster than your vehicle, gradually increasing the interval between the vehicles.

You can also set the system to beep when a vehicle detected in front of you comes in and goes out of the ACC detecting range.

A vehicle detect beep on and off can be selected.

🔧 **Settings** P. 142, 167

Limitations

You may need to use the brake to maintain a safe interval when using ACC. Additionally, ACC may not work properly under certain conditions.

🔧 **ACC Conditions and Limitations** P. 345


■ There is no vehicle ahead

Models with A-type meter



A vehicle icon with line contour appears on the gauge.

Models with B-type meter



A vehicle icon with line contour appears on the gauge.

Your vehicle maintains the set speed without having to keep your foot on the brake or accelerator pedal.

If there previously was a vehicle detected ahead that kept your vehicle from travelling at the set speed, ACC accelerates your vehicle to the set speed, and then maintains it.


■ When you depress the accelerator pedal

You can temporarily increase the vehicle speed. In this case, there is no audible or visual alert even if a vehicle is in the ACC range.

ACC stays on unless you cancel it. Once you release the accelerator pedal, the system resumes the set speed.

▶▶ When in Operation

- ACC may temporarily control the interval between your vehicle and the vehicle in adjacent lane or surroundings of your vehicle depending on the road conditions (e.g., curves) or vehicle conditions (e.g., operating the steering wheel or the vehicle location in the lane).



- When the vehicle ahead of you moves away, such as when entering an interchange or rest area, ACC may continue to maintain the set following-interval for a short time.

■ ACC Conditions and Limitations

The system may automatically shut off under certain conditions. Some examples of these conditions are listed below. Other conditions may reduce some of the ACC functions.


📷 **Front Wide View Camera** P. 374

■ Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes between light and dark, such as the entrance or exit of a tunnel or the shadows of trees, buildings, etc.
- Strong light is reflected onto vehicles or road surfaces.
- Water is sprayed by or snow blown from a vehicle ahead.
- Driving at night or in a dark place such as a tunnel (due to low-light conditions, the whole vehicle may not be illuminated).
- Driving into low sunlight (e.g., at dawn or dusk).

■ Roadway conditions

- Driving on curvy, winding, undulating, or sloping roads.



- Driving on rutted roads (snowy or unpaved roads, etc.).
- Puddles or a film of water is on the road surface.
- Your vehicle is strongly shaken on uneven road surfaces.

■ Vehicle conditions

- The vehicle is tilted due to heavy luggage in the boot or rear seats.
- Tyre chains* are installed.
- The front of the camera is obstructed by dirt, fog, rain, mud, wet snow, accessories, decals, stickers, film, etc.
- Driving at night or in a dark place (e.g., a tunnel) with the headlights off.
- There is residue on the windscreen from the windscreen wipers.
- When lighting is weak due to dirt covering the headlight lenses, or there is poor visibility in a dark place due to the headlights being improperly adjusted.
- An abnormal tyre or wheel condition (incorrect sizes, varied sizes or construction, improperly inflated, compact spare tyre*/temporary spare tyre*, etc.).
- The suspension has been modified.


■ **Examples of conditions under which the camera may not correctly detect the vehicle ahead of you**

- A vehicle suddenly crosses in front of you.
- The interval between your vehicle and the vehicle ahead of you is too short.
- When the vehicle ahead of you blends in with the background, preventing the system from recognising it.
- When the height of a vehicle ahead of you is low.
- The headlights of the vehicle ahead of you are lit on one side or not lit on either side in a dark place.

■ **Examples of conditions under which the system may not work properly**

- A vehicle ahead of you stops and the speed difference between your vehicle and the vehicle ahead of you is significantly large.
- When the vehicle ahead of you slows suddenly.
- When the vehicle ahead of you is a three-wheeled vehicle* or specially shaped vehicle.
- When a vehicle is lower in the rear than the front such as lorries that are not carrying a load, or a narrow vehicle.

Camera detects upper section
of an empty carrier lorry.



- When your vehicle or the vehicle ahead of you is driving on the edge of the lane.
- When the vehicle ahead of you is a narrow vehicle such as a motorcycle.
- When the minimum ground clearance of a vehicle ahead of you is extremely high.




- When the camera cannot correctly identify the shape of the vehicle ahead of you.

* Not available on all models

■ To Adjust the Vehicle Speed

Increase or decrease the vehicle speed using the **RES/+** or **SET/-** button on the steering wheel.




- Each time you press the **RES/+** or **SET/-** button, the vehicle speed is increased or decreased by about 1 km/h or 1 mph accordingly.
- If you press and hold the **RES/+** or **SET/-** button, the vehicle speed increases or decreases by about 10 km/h or 10 mph accordingly.

▣ To Adjust the Vehicle Speed

If a vehicle detected ahead is going at a speed slower than your increased set speed, ACC may not accelerate your vehicle. This is to maintain the set interval between your vehicle and the vehicle ahead.

When you depress the accelerator pedal and then push and release the **RES/+** or **SET/-** button, the current speed of the vehicle is set.

■ To Set or Change Following-interval



Press the interval button to change the ACC following-interval.

Each time you press the button, the following-interval (the interval behind a vehicle detected ahead of you) setting cycles through extra long, long, middle, and short following-intervals.

Determine the most appropriate following-interval setting based on your specific driving conditions. Be sure to adhere to any following-interval requirements set by local regulation.


The higher your vehicle's following-speed is, the longer the short, middle, long, or extra long following-interval becomes. See the following examples for your reference.

Following-interval		When the Set Speed is:	
		80 km/h (50 mph)	104 km/h (65 mph)
Short		26.6 metres 1.2 sec	33.7 metres 1.2 sec
Middle		34.6 metres 1.6 sec	44.9 metres 1.6 sec
Long		44.0 metres 2.0 sec	57.1 metres 2.0 sec
Extra Long		53.6 metres 2.4 sec	70.0 metres 2.4 sec

To Set or Change Following-interval

The driver must in all circumstances preserve a sufficient braking interval from the vehicle which precedes it and be aware that minimum intervals or times of spacing can be provided by the provisions of the Motorway Code locally applicable and that it is the driver's responsibility to respect those laws.

To Cancel



To cancel ACC, do any of the following:

- Press the **CANCEL** button.
 - ▶ The indicator (green) on the gauge changes to the indicator (white).
- Press the button.
 - ▶ indicator (green) goes off.
- Depress the brake pedal while the vehicle is moving forward.
 - ▶ The indicator (green) on the gauge changes to the indicator (white).

Manual transmission models

- Depress the clutch pedal for five seconds or more.
 - ▶ The indicator (green) on the gauge changes to the indicator (white).

To Cancel

Resuming the prior set speed: After you have cancelled ACC, you can activate the ACC with the prior set speed displayed on the gauge (in grey) by pressing the **RES/+** button.

When you turn the ACC off by pressing the **CANCEL** button or depressing the brake pedal, the prior set speed is displayed on the gauge in grey.

When pressing the **RES/+** button, the ACC is activated with displayed speed.

If the indicator (white) is displayed and you press the **RES/+** button, but no prior set speed (in grey) is displayed, the speed will be set to your vehicle's current speed.


■ Automatic cancellation

The beeper sounds and a message appears on the driver information interface when ACC is automatically cancelled. Any of these conditions may cause the ACC to automatically cancel:


- Bad weather (rain, fog, snow, etc.)
- The vehicle ahead of you cannot be detected.
- An abnormal tyre condition is detected, or the tyres are skidding.
- Driving on a mountainous road for extended periods, or driving off road.
- Abrupt steering wheel movement.
- When the ABS, VSA, or CMBS is activated.
- When the VSA system indicator comes on.
- When vehicle speed is less than 25 km/h (16 mph).
- Water is sprayed by or snow blown from a vehicle ahead.
- Driving into low sunlight (e.g., at dawn or dusk).
- When the detected vehicle within the ACC range is too close to your vehicle.
- When accelerating rapidly.
- The front of the camera is obstructed by dirt, fog, rain, mud, wet snow, accessories, decals, stickers, film, etc.
- The vehicle is loaded heavy luggage in the boot or rear seats.
- When passing through a dark place, such as tunnel.
- When the parking brake and brake system indicator (amber) comes on.
- The vehicle has repeatedly applied the brakes to maintain the set speed (for example, you are descending a long slope).
- When the system doesn't detect any driving actions from the driver for a certain amount of time while the LKAS is also activated.

▶▶ To Cancel

Models with A-type meter



Models with B-type meter



The set speed cannot be set or resumed when ACC has been turned off using the  button. Press the  button to activate the system, then set the desired speed.

If the vehicle speed is less than 30 km/h (18 mph) you cannot resume.

Continued

Manual transmission models

- Ignoring shift up or down indication shown in the gauge will cancel the ACC after about 10 seconds.
- The engine speed goes into the tachometer red zone.
- The engine speed goes to below 1,000 rpm.
- You shift into neutral temporarily when shifting into a higher or lower gear.
- When the transmission is put into **[N]** without depressing the clutch pedal.

Lane Keeping Assist System (LKAS)

Except Mexican models

Provides steering input to help to keep the vehicle in the middle of a detected lane and provides tactile, audible and visual alerts if the vehicle is detected drifting out of its lane.

Mexican models

Provides steering input to help to keep the vehicle in the middle of a detected lane and provides tactile and visual alerts if the vehicle is detected drifting out of its lane.

▶▶ Lane Keeping Assist System (LKAS)

Important Safety Reminders

The LKAS is for your convenience only. It is not an autonomous driving system and always requires driver attention and control. The system does not work if you take your hands off the steering wheel or fail to steer the vehicle.

The LKAS is convenient when it is used on motorways or a dual carriage way.

Do not place objects on the instrument panel. Objects may reflect on the windscreen and prevent correct detection of the traffic lanes.

The LKAS only alerts you when lane drift is detected without a turn signal in use. The LKAS may not detect all lane markings or lane departures; accuracy will vary based on weather, speed, and lane marker condition. It is always your responsibility to safely operate the vehicle and avoid collisions.

The LKAS may not function as designed while driving in frequent stop and go traffic, or on roads with sharp curves.

You can read about handling information for the camera equipped with this system.

📺 **Front Wide View Camera** P. 374

The LKAS may not work properly or may work improperly under the certain conditions:

📺 **LKAS Conditions and Limitations** P. 364


Continued

■ Steering input assist

The system applies torque to the steering to keep the vehicle between the left and right lane lines. The applied torque becomes stronger as the vehicle gets closer to either of the lane lines.



■ Front wide view camera
Monitors the lane lines



Except Mexican models

■ Tactile, audible and visual alerts

Rapid vibrations on the steering wheel, audible and a warning display alert you that the vehicle is drifting out of a detected lane.

Mexican models

■ Tactile and visual alerts
Rapid vibrations on the steering wheel and a warning display alert you that the vehicle is drifting out of a detected lane.

When you operate the turn signals to change lanes, the system is suspended, and resumes after the signals are off.

If you make a lane change without operating the turn signals, the LKAS alerts activate, and torque is applied to the steering.

*1: Models with A-type meter


*2: Models with B-type meter

▶▶ Lane Keeping Assist System (LKAS)

When it fails to detect lanes, the system will temporarily be cancelled. When a lane is detected, the system will recover automatically.

■ Lane Keep Support Function

Provides assistance to keep the vehicle in the centre of the lane. When the vehicle nears a white or yellow line, steering force of the electric power steering will become stronger.




■ Lane Departure Warning Function

Except Mexican models

When the vehicle enters the warning area, the LKAS alerts you with slight steering wheel vibration, and audible and visual warnings.

Mexican models

When the vehicle enters the warning area, the LKAS alerts you with slight steering wheel vibration as well as a warning display.



*1: Models with A-type meter

*2: Models with B-type meter

When the System can be Used

The system can be used when the following conditions are met.

- The lane in which you are driving has detectable lane markers on both sides, and your vehicle is in the centre of the lane.
- You are driving on a straight or slightly curved road.
- The turn signals are off.
- The brake pedal is not suddenly depressed.


Except Mexican models

- The vehicle is travelling between about 72 and 180 km/h.

Mexican models

- The vehicle is travelling between about 72 and 145 km/h (45 and 90 mph).

How to activate the system



1. Press the LKAS button.

- ▶ LKAS indicator (white) appears on the gauge.
The system is standby.
- ▶ If traffic lane lines are detected, white lines appear on the gauge.

*1: Models with A-type meter

*2: Models with B-type meter

When the System can be Used

If the vehicle drifts towards either left or right lane line due to the system applying torque, turn off the LKAS and have your vehicle checked by a dealer.

Follow the points below to properly activate the system:

- Always keep the windscreen around the camera clean.
- When cleaning the windscreen, be careful not to apply windscreen cleanser to the camera lens.
- Do not touch the camera lens.
- Do not attach a sticker to the area around the camera.

If LKAS button is pressed when the system can be used, LKAS is on without standby.

Models with A-type meter

Green Lines



LKAS Indicator (green)

Models with B-type meter


Green Lines



LKAS Indicator (green)

2. Keep your vehicle near the centre of the lane while driving.
 - ▶ The LKAS indicator changes from white to green, and white lines change to green once the system starts operating after detecting the left and right lane markings.

■ To Cancel



Press the LKAS button.

The LKAS is turned off every time you stop the engine, even if you turned it on the last time you drove the vehicle.

■ The LKAS may be automatically suspended when:

When the LKAS is suspended under the following circumstances, green lines on the gauge change to white lines or disappear, and the beeper sounds (if activated).

Models with A-type meter

White Lines



LKAS Indicator (white)

Models with B-type meter

White Lines



LKAS Indicator (white)

- Decrease the vehicle speed to about 64 km/h (40 mph) or less.
▶ Increasing the vehicle speed to about 72 km/h (45 mph) or more resumes the LKAS.
- Your vehicle is driving to the right or the left of the lane.
- The system fails to detect lane lines.
- The steering wheel is turned quickly.
- You fail to steer the vehicle.
- Driving through a sharp curve.

Except Mexican models

- Driving at a speed in excess of approximately 185 km/h.

Mexican models

- Driving at a speed in excess of approximately 150 km/h (93 mph).

All models

- The ABS or VSA system engages.
 - The brake pedal is suddenly depressed.
- Once these conditions no longer exist, the LKAS automatically resumes.

▶▶ The LKAS may be automatically suspended when:

LKAS suspended beep on and off can be selected.

▶ **Settings** P. 142, 167

■ The LKAS may be automatically cancelled when:

In the following cases, traffic lane lines may disappear on the gauge, the beeper may sound, and the LKAS may be automatically cancelled:

- The camera temperature gets extremely high.
- The camera behind the rearview mirror, or the area around the camera, including the windscreen, is dirty.

■ LKAS Conditions and Limitations


The system may not detect lane markings (in white or yellow), and LKAS may not function properly under certain conditions, including the following:

■ Environmental conditions


- There is little contrast between lane lines and the roadway surface.
- Driving in bad weather (rain, fog, snow, etc.).
- Driving on a snowy or wet roadway.
- Driving into low sunlight (e.g., at dawn or dusk).
- Shadows of adjacent objects (trees, buildings, guard rails, vehicles, etc.) are parallel to white (or yellow) lines.
- Sudden changes between light and dark, such as the entrance or exit of a tunnel or the shadows of trees, buildings, etc.
- Driving at night or in a dark place such as a tunnel (due to low-light conditions, lane lines or the road surface may not be illuminated).
- The distance between your vehicle and the vehicle ahead of you is too short, and lane lines and the road surface are not visible.
- Strong light is reflected onto the roadway.

■ Roadway conditions

- Driving on a road with temporary lane markings.
- Faint, multiple, or varied lane markings are visible on the roadway due to road repairs or deteriorated lane markings.




- The roadway has merging, split, or crossing lines, such as at an intersection or crosswalk.
- The lane markings are extremely narrow, wide, or changing.



- Part of the lane markings are hidden by an object, such as a vehicle.
- The road is hilly or the vehicle is approaching the crest of a hill.
- Your vehicle is strongly shaken on uneven road surfaces.
- When objects on the road (curb, guard rail, pylons, etc.) are recognised as white (or yellow) lines.
- Driving on rough or unpaved roads, or over bumpy surfaces.

- Driving on roads with double lane lines.
- Driving on snowy or slippery roads.
- The pavement is only partially visible due to snow or puddles on the road.
- There is a film of water or puddles on the road surface.
- White (or yellow) lines are not recognised correctly due to road conditions such as curves, twists, or hills.
- Driving on unpaved or rutted roads.
- Passing through a junction.




■ Vehicle conditions

- When lighting is weak due to dirt covering the headlight lenses, or there is poor visibility in a dark place due to the headlights being improperly adjusted.
- The front of the camera is obstructed by dirt, fog, rain, mud, wet snow, accessories, decals, stickers, film, etc.
- Driving at night or in a dark place (e.g., a tunnel) with the headlights off.
- There is residue on the windscreen from the windscreen wipers.
- An abnormal tyre or wheel condition (incorrect sizes, varied sizes or construction, improperly inflated, compact spare tyre*/temporary spare tyre*, etc.).
- The vehicle is tilted due to a heavy luggage in the boot or rear seats.
- The suspension has been modified.
- Tyre chains* are installed.

* Not available on all models

Lead Car Departure Notification System*

Informs you with visual and audible alerts when your vehicle is stopped even though the vehicle ahead of you has started moving.



▶▶ Lead Car Departure Notification System*

⚠ WARNING

Lead Car Departure Notification System is an supplemental system that provides driving assistance. It is not a system that informs you if it is safe to start driving.

Improper use of this system may lead to a collision.

Always visually confirm the safety of your surroundings before driving the vehicle and maintain a safe following-interval when driving.

You can read about handling information for the camera equipped with this system.

📺 **Front Wide View Camera** P. 374

Like other assistance systems, this system may not function properly depending on weather, environmental conditions, and so on.

*1: Models with A-type meter

*2: Models with B-type meter

* Not available on all models

How the system works

The system detects a stopped vehicle in front of you, on the condition that the vehicles are within 10 m of each other and both vehicles have been stopped for a period of time. When the detected vehicle moves but yours does not, the system will activate.

Continuously variable transmission models

■ When the shift position is in **D** or **S**

The system will work when the brake pedal is depressed.

■ When the shift position is in **N**

The system will work when the vehicle is stopped, the brake pedal is depressed, or the parking brake is in operation.

Manual transmission models

The system will work when the brake pedal is depressed, or the parking brake is in operation.

All models

You can choose from two system operation timing modes, **Normal** and **Early**.

🔧 **Settings** P. 142, 167

In **Normal** mode, the system operates when the vehicle ahead of you has moved approximately 3 m from where it stopped.

In **Early** mode, the system operates as soon as movement has been detected.

Lead Car Departure Notification System*


You can turn off the Lead Car Departure Notification System.

🔧 **Settings** P. 142, 167

The Lead Car Departure Notification System will not activate while the Adaptive Cruise Control (ACC) Indicator is on.

🔧 **Adaptive Cruise Control (ACC)** P. 337

■ When the System Activates



The beeper sounds and a message appears on the driver information interface when the system is activated.

*1: Models with A-type meter

*2: Models with B-type meter

■ Lead Car Departure Notification System Conditions and Limitations

In the following conditions, the system may or may not activate regardless of whether the vehicle ahead of you starts to move.

■ Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Water is sprayed by or snow blown from a vehicle ahead.
- Sudden changes between light and dark, such as the entrance or exit of a tunnel or the shadows of trees, buildings, etc.
- Strong light is reflected onto vehicles or road surfaces.
- Driving at night or in a dark place such as a tunnel (due to low-light conditions, the whole vehicle may not be illuminated).
- Driving into low sunlight (e.g., at dawn or dusk).

■ Roadway conditions

- Driving on curvy, winding, undulating, or sloping roads or immediately after turning to the left or right.

■ Vehicle conditions

- The vehicle is tilted due to heavy luggage in the boot or rear seats.
- The vehicle is only stopped for a short time.
- The front of the camera is obstructed by dirt, fog, rain, mud, wet snow, accessories, decals, stickers, film, etc.
- Driving at night or in a dark place (e.g., a tunnel) with the headlights off.
- There is residue on the windscreen from the windscreen wipers.
- When lighting is weak due to dirt covering the headlight lenses, or there is poor visibility in a dark place due to the headlights being improperly adjusted.
- An abnormal tyre or wheel condition (incorrect sizes, varied sizes or construction, improperly inflated, temporary spare tyre*, etc.).
- The suspension has been modified.

■ Examples of conditions under which the camera may not correctly detect the vehicle ahead of you

- The vehicle ahead of you is only stopped for a short time.
- The space between your vehicle and the vehicle ahead of you is too short.
- The vehicle ahead of you is moving too slowly.
- The vehicle ahead of you suddenly turns around or to the left or right.
- The vehicle ahead of you blends into the scenery and can't be detected.
- The vehicle ahead of you has only one or neither of their taillights on.

■ Examples of other limitations on detection

- There is a pedestrian, bicycle, motorcycle, or other specially-shaped vehicle in front of you.
- Another vehicle, pedestrian, or bicycle comes between your vehicle and the vehicle in front of you.
- The vehicle ahead of you is not directly in front of you.


■ Examples of other limitations on system operation

- The camera cannot correctly detect the shape of the vehicle ahead of you.
- The vehicle ahead of you has very high ground clearance.
- The vehicle ahead of you, such as a lorry without a trailer, has a rear that is smaller than the front.

Front Wide View Camera

The camera, used in systems such as Collision Mitigation Braking System (CMBS), Road Departure Mitigation System, Adaptive Cruise Control (ACC), Lane Keeping Assist System (LKAS), Lead Car Departure Notification System*, and auto high-beam system, is designed to detect an object that triggers any of the systems to operate its functions.

Camera Location and Handling Tips



This camera is located behind the rearview mirror.

To help to reduce the likelihood that high interior temperatures will cause the camera's sensing system to shut off, find a shady area or face the front of the vehicle away from the sun when parking. If you use a reflective sun shade, do not allow it to cover the camera housing. Covering the camera can concentrate heat on it.

Front Wide View Camera

Never apply a film or attach any objects to the windshield, the bonnet, or the front grille that could obstruct the camera's field of vision and cause the system to operate abnormally.

Scratches, nicks, and other damage to the windshield within the camera's field of vision can cause the system to operate abnormally. If this occurs, we recommend that you replace the windshield with a genuine Honda replacement windshield. Making even minor repairs within the camera's field of vision or installing an aftermarket replacement windshield may also cause the system to operate abnormally.

After replacing the windshield, have a dealer recalibrate the camera. Proper calibration of the camera is necessary for the system to operate properly.

Do not place an object on the top of the instrument panel. It may reflect onto the windshield and prevent the system from detecting lane lines properly.

▶▶ Front Wide View Camera

If the **Some driver assist systems cannot operate: Camera temperature too high***1/**Some Driver Assist Systems Cannot Operate: Camera Temperature Too High***2 message appears:

- Use the climate control system to cool down the interior and, if necessary, also use demister mode with the airflow directed towards the camera.
- Start driving the vehicle to lower the windscreen temperature, which cools down the area around the camera.

Models with A-type meter

If the **Some driver assist system cannot operate: Clean front windshield or poor viewing condition**/**Some driver assist systems cannot operate: Clean front windscreen or poor viewing condition** message appears:

- Park your vehicle in a safe place, and make sure the windscreen is clean. Clean the windscreen if it is dirty. If the message does not disappear after driven for a while, have your vehicle checked by a dealer.

Models with B-type meter

If the **Some Driver Assist Systems Cannot Operate: Clean Front Windshield Or Poor Viewing Condition***3/**Some Driver Assist Systems Cannot Operate: Clean Front Windscreen Or Poor Viewing Condition***4 message appears:

- Park your vehicle in a safe place, and make sure the windscreen is clean. Clean the windscreen if it is dirty. If the message does not disappear after driven for a while, have your vehicle checked by a dealer.

*1: Models with A-type meter

*2: Models with B-type meter


*3: Mexican models

*4: Except Mexican models

Brake System


Parking Brake

Use the parking brake to keep the vehicle stationary when parking.



To apply:

Pull the lever fully up without pressing the release button.



To release:

1. Pull the lever slightly, and press and hold the release button.
2. Lower the lever down all the way, then release the button.

» Brake System

Thai models

When you depress the brake pedal, you may hear a whirring sound from the engine compartment. This is because the brake system is in operation, and it is normal.

» Parking Brake

NOTICE

Release the parking brake fully before driving. The rear brakes and axle can be damaged if you drive with the parking brake applied.

If you start driving without fully releasing the parking brake, a buzzer sounds as a warning, and **Release parking brake**^{*1}/**Release Parking Brake**^{*2} appears on the driver information interface*.

Always apply the parking brake when parking.

*1: Models with A-type meter

*2: Models with B-type meter

* Not available on all models

Foot Brake

Malaysian models with 16 inch wheel

Vietnamese models with keyless access system

Your vehicle is equipped with disc brakes at all four wheels.

A vacuum power assist helps reduce the effort needed on the brake pedal.

Other models

Your vehicle is equipped with disc brakes at the front, and drum brakes in the rear wheels.

A vacuum power assist helps to reduce the effort needed on the brake pedal.

All models

The brake assist system increases the stopping force when you depress the brake pedal hard in an emergency situation. The anti-lock brake system (ABS) helps you retain steering control when braking very hard.

➤ **Brake Assist System** P. 379

➤ **Anti-lock Brake System (ABS)** P. 378

Foot Brake

Check the brakes after driving through deep water, or if there is a buildup of road surface water. If necessary, dry the brakes by lightly depressing the pedal several times.

If you hear a continuous metallic friction sound when applying the brakes, the brake pads need to be replaced. Have your vehicle checked by a dealer.

Constantly using the brake pedal while going down a long hill builds up heat, which reduces the brake effectiveness. Apply engine braking by taking your foot off the accelerator pedal and downshifting to a lower gear/speed position. With manual transmission use a lower gear for greater engine braking.

Do not rest your foot on the brake pedal while driving, as it will lightly apply the brakes and cause them to lose effectiveness over time and reduce pad life. It will also confuse drivers behind you.

Thai models

Whenever the brakes are activated by CMBS or another system that automatically controls braking, the brake pedal is depressed and released in accordance with braking function.

Anti-lock Brake System (ABS)

■ ABS

Helps to prevent the wheels from locking up, and helps you to retain steering control by pumping the brakes rapidly, much faster than you can.

The electronic brake distribution (EBD) system, which is part of the ABS, also balances the front-to-rear braking distribution according to vehicle loading.

You should never pump the brake pedal. Let the ABS work for you by always keeping firm, steady pressure on the brake pedal. This is sometimes referred to as “stomp and steer.”

■ ABS operation

The brake pedal may pulsate slightly when the ABS is working. Depress the brake pedal and keep holding the pedal firmly down. On dry pavement, you will need to press on the brake pedal very hard before the ABS activates. However, you may feel the ABS activate immediately if you are trying to stop on snow or ice.

ABS may activate when you depress the brake pedal when driving on:

- Wet or snow covered roads.
- Roads paved with stone.
- Roads with uneven surfaces, such as potholes, cracks, manholes, etc.

When the vehicle speed goes under 10 km/h (6 mph), the ABS stops.

►► Anti-lock Brake System (ABS)

NOTICE

The ABS may not function correctly if you use a tyre of the incorrect size or type.

If the **ABS** indicator comes on while driving, there may be a problem with the system. While normal braking will not be affected, there is a possibility that the ABS will not be operating. Have your vehicle checked by a dealer immediately.

The ABS is not designed for the purpose of reducing the time or distance it takes for a vehicle to stop: It is designed to limit brake lockup which can lead to skidding and loss of steering control.

In the following cases, your vehicle may need more distance to stop than a vehicle without the ABS:

- You are driving on rough or uneven road surfaces, such as gravel or snow.
- The tyres are equipped with tyre chains*.

The following may be observed with the ABS system:

- Motor sounds coming from the engine compartment when the brakes are applied, or when system checks are being performed after the engine has been started and while the vehicle accelerates.
- Brake pedal and/or the vehicle body vibration when ABS activates.

These vibrations and sounds are normal to ABS systems and are no cause for concern.

Brake Assist System

Is designed to assist the driver by generating greater braking force when you depress the brake pedal hard during emergency braking.

■ Brake assist system operation

Press the brake pedal firmly for more powerful braking.


When brake assist operates, the pedal may wiggle slightly and an operating noise may be heard. This is normal. Keep holding the brake pedal firmly down.

Except Mexican models

Emergency Stop Signal

Activates when you brake hard while driving at 60 km/h or above to alert drivers behind you about sudden braking by rapidly flashing hazard warning lights. This may help to alert drivers behind you to take appropriate means to avoid a possible collision with your vehicle.

■ When the system activates:



The hazard warning lights stop flashing when:

- You release the brake pedal.
- The ABS is deactivated.
- Your vehicle's decelerating speed becomes moderate.
- You press the hazard warning button.

» Emergency Stop Signal

The emergency stop signal is not a system that can prevent a possible rear-end collision caused by your hard braking. It flashes the hazard warning lights at the time you are braking hard. It is always recommended to avoid hard braking unless it is absolutely necessary.

The emergency stop signal does not activate with the hazard warning button pressed in.

If the ABS stops working for a certain period during braking, the emergency stop signal may not activate at all.

When Stopped

1. Depress the brake pedal firmly.
2. Apply the parking brake.

Continuously variable transmission models

3. Change the shift position to **P**.
4. Turn off the engine.

Manual transmission models

3. Move the shift lever to **N**.
4. Turn off the engine and move the shift lever to **R** or **1**.

Always set the parking brake, especially if you are parked on an incline.

» Parking Your Vehicle

Continuously variable transmission models

⚠ WARNING

The vehicle can roll away if left unattended without confirming that Park is engaged.

A vehicle that rolls away could cause a crash resulting in serious injury or death.

Always keep your foot on the brake pedal until you have confirmed that **P** is shown on the shift position indicator.

Continuously variable transmission models

NOTICE

The following can damage the transmission:

- Depressing the accelerator and brake pedals simultaneously.
- Holding the vehicle in place when facing uphill by depressing the accelerator pedal.
- Change the shift position to **P** before the vehicle stops completely.

All models

Do not park your vehicle near flammable objects, such as dry grass, oil, or timber.
Heat from the exhaust can cause a fire.


►► Parking Your Vehicle

In extremely cold temperatures, the parking brake may freeze up if applied. If such temperatures are expected, do not apply the parking brake. If parking on a slope, either turn the front wheels so they will contact the curb if the vehicle rolls down the slope or block the wheels to keep the vehicle from moving. If you do not take either precaution, the vehicle may roll unexpectedly, leading to a crash.

Parking Sensor System *

The rear corner* and centre sensors monitor obstacles behind your vehicle, and the beeper and driver information interface* lets you know the approximate distance between your vehicle and the obstacle.

■ The Sensor Location and Range



Models without parking sensor system button

The system activates when the transmission is in **[R]**, and the vehicle speed is less than 9 km/h (6 mph).

⚠ Parking Sensor System *

Even when the system is on, always confirm if there is no obstacle near your vehicle before parking.

The system may not work properly when:

- The sensors are covered with snow, ice, mud, or dirt.
- The vehicle has been out in hot or cold weather.
- There is something nearby that emits ultrasonic waves or high frequency sounds.
- Driving in bad weather (rain, fog, snow, etc.).

The system may not detect these obstacles:


- Thin or low objects.
- Sonic-absorptive materials, such as snow, cotton, or sponge.
- Objects directly under the bumper.

The system may falsely detect obstacles in the following situations:

- The vehicle is on uneven surface, such as grass, bumps, or a hill.
- When close to other vehicles with sonar sensors or other objects that emit ultrasonic waves.
- There is splashing water near the sensors due to heavy rains, etc.

Models with parking sensor system button

■ Parking Sensor System On and Off



With the power mode in ON, press the parking sensor system button to turn on or off the system. The indicator in the button comes on when the system is on.

The rear centre and corner sensors start to detect an obstacle when the shift lever is in **[R]**, and the vehicle speed is less than 9 km/h (6 mph).

»» Parking Sensor System*

Do not put any accessories on or around the sensors.

Models with parking sensor system button

► If you put any accessories (such as bicycle rack) on or around the rear sensors, the system may activate if it detects these accessories as an obstacle. In this case, turn off the rear sensor.

➤ **Turning off All Rear Sensors** P. 386

»» Parking Sensor System On and Off

When you set the power mode to ON, the system will be in the previously selected condition.

When the Distance Between Your Vehicle and Obstacles Becomes Shorter

Interval between beeps	Distance between the Bumper and Obstacle		Indicator* ¹	Driver information interface* ¹
	Corner Sensors*	Centre Sensors		
Moderate	—	About 60-110 cm	Blinks in Yellow* ²	 Indicators light up where the sensor detects an obstacle
Short	About 45-62 cm	About 50-60 cm	Blinks in Amber	
Very short	About 35-45 cm	About 40-50 cm		
Continuous	About 35 cm or less	About 40 cm or less	Blinks in Red	

*1: Models with driver information interface

*2: At this stage, only the centre sensors detect obstacles.

Models with parking sensor system button

■ Turning off All Rear Sensors

To deactivate the rear sensors, please take the following steps:

1. Make sure that the parking sensor system is not activated.
 - The indicator in the button turns off.
2. Set the power mode to VEHICLE OFF.
3. Press and hold the parking sensor system button, and set the power mode to ON.
4. Keep pressing the button for 10 seconds. Release the button when the indicator in the button flashes.
 - The beeper sounds once.
5. While the indicator is flashing, press the button again. The indicator in the button turns off.
 - The beeper sounds twice. The rear sensors are now turned off. They will remain turned off until manually turned back on again. To turn the rear sensors on again, follow the above procedure. The beeper sounds three times when the rear sensors come back on.

►► Turning off All Rear Sensors

When you set the shift position to **[R]**, the indicator in the parking sensor system button blinks as a reminder that the rear sensors have been turned off.

Fuel Information

■ Fuel recommendation

Indian, Bhutanese and Nepalese models

Unleaded petrol/gasohol up to E20 (80% petrol and 20% ethanol), research octane number 91 or higher

Use of lower octane petrol can cause a persistent, heavy metallic knocking noise that can lead to engine damage.

Thai models

Unleaded premium petrol/gasohol up to E20 (80% petrol and 20% ethanol), research octane number 95 or higher

Use of lower octane number petrol can cause occasional metallic knocking noise in the engine and will result in decreased engine performance.

Use of petrol with a research octane number less than 91 can lead to engine damage.

Except Indian, Bhutanese, Nepalese and Thai models

Unleaded petrol, research octane number 91 or higher

Use of lower octane petrol can cause a persistent, heavy metallic knocking noise that can lead to engine damage.

■ Fuel tank capacity: 40 L

» Fuel Information

NOTICE

Use of petrol that contains lead presents the following risks:

- Damage to the exhaust system including the catalytic converter
- Damage to the engine and fuel system
- Detrimental effects on the engine and other systems

Thai models




■ **Engine cleaner**

Fuel quality varies by region. Add genuine injector cleaner agent according to the time and distance instructions in the maintenance schedule.

Please use a genuine Honda injector cleaner agent. If not available, please use a PEA (polyetheramine) based cleaning agent instead.

Regular use of injector cleaner may be needed in countries or regions without a maintenance schedule. Consult your dealer for more information.

How to Refuel



1. Stop your vehicle with the service station pump on the left side of the vehicle in the rear.
2. Turn off the engine.
3. Pull on the fuel fill door release handle under the driver's side lower outside corner of the dashboard.
 - ▶ The fuel fill door opens.
4. Remove the fuel fill cap slowly. If you hear a release of air, wait until this stops, then turn the knob slowly to open the fuel fill cap.
5. Place the fuel fill cap in the holder.
6. Insert the fuel filler nozzle fully.
 - ▶ When the tank is full, the filler nozzle will click off automatically. This leaves space in the fuel tank in case the fuel expands with a change in the temperature.
7. After filling, replace the fuel fill cap, tightening it until you hear it click at least once.
 - ▶ Shut the fuel fill door by hand.

How to Refuel

⚠ WARNING

Petrol is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flames away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

⚠ CAUTION

The filler nozzle automatically stops to leave space in the fuel tank so that fuel does not overflow as a result of changes in air temperature.

Do not continue to add fuel after the filler nozzle has automatically stopped. Additional fuel can exceed the full tank capacity and cause fuel to spill.

Improving Fuel Economy and Reducing CO₂ Emissions

Achieving fuel economy and reducing CO₂ emissions is dependent on several factors, including driving conditions, load weight, idling time, driving habits, and vehicle condition. Depending on these and other factors, you may not achieve the rated fuel economy of this vehicle.

Maintenance and Fuel Economy

You can optimize your fuel economy with proper maintenance of your vehicle. Follow the maintenance schedule and, if necessary, consult the service information provided for your vehicle.

➤ Maintenance Schedule P. 404


- Use engine oil with the viscosity recommended.

➤ Recommended Engine Oil P. 415

- Maintain the specified tyre pressure.
- Do not load the vehicle with excess luggage.
- Keep your vehicle clean. A buildup of snow or mud on your vehicle's underside adds weight and increases wind resistance.

» Improving Fuel Economy and Reducing CO₂ Emissions

Direct calculation is the recommended method to determine actual fuel consumed while driving.



GCC country models

You can improve the mileage and reduce the CO₂ emissions of your vehicle by following these tips:

- Operate your vehicle correctly.
- Regularly maintain your vehicle.
- Maintain proper tyre pressure.
- Avoid carrying excessive loads.
- Adopt efficient driving techniques, such as driving at lower speeds, reducing idling time, and avoiding aggressive driving.

Handling Precautions

The turbocharger is a high-precision device to obtain greater horsepower by delivering a large volume of compressed air into the engine using a turbine driven by the engine's exhaust gas pressure.

- When the engine is cold just after starting, avoid revving the engine or sudden acceleration.
- Always replace the engine oil and engine oil filter according to the Oil Monitor System. The turbine rotates at very high speeds over 100,000 rpm and its temperature reaches over 700°C. It is lubricated and cooled by engine oil. If you fail to replace the engine oil and filter at the scheduled distance or interval, deteriorated engine oil may cause failure such as sticking and abnormal noise of the turbine bearing.

▶ Turbo Engine Vehicle*

The scheduled maintenance intervals for replacing the engine oil and filter is indicated on the driver information interface. Follow the information on replacement timing.

▶ **Oil Monitor System*** P. 397

▶ **Recommended Engine Oil** P. 415

The **Engine temperature too hot. Do not drive. Allow engine to cool.** or **Engine temperature near limit. Avoid strong acceleration and high speed.** message may appear on the driver information interface when you restart the engine after driving under high load conditions such as at high speed or in hilly terrain. This is normal. The message goes off after you idle or drive the vehicle for about one minute.

* Not available on all models

Maintenance

This chapter discusses basic maintenance.



Before Performing Maintenance

Inspection and Maintenance	394
Safety When Performing Maintenance ..	395
Parts and Fluids Used in Maintenance Service	396

Oil Monitor System*

Maintenance Reminder*

Maintenance Schedule

Maintenance Under the Bonnet

Maintenance Items Under the Bonnet ..	411
Opening the Bonnet	413
Recommended Engine Oil	415
Oil Check	417

Adding Engine Oil

Engine Coolant

Transmission Fluid

Brake/Clutch* Fluid

Refilling Window Washer Fluid

Fuel Filter

Replacing Light Bulbs

Checking and Maintaining Wiper

Blades

Checking and Maintaining Tyres

Checking Tyres

Wear Indicators

Tyre Service Life

Tyre and Wheel Replacement

Tyre Rotation

Snow Traction Devices

Battery

Remote Transmitter Care

Replacing the Remote Battery

Heating System* and Cooling System*/Climate

Control System* Maintenance

Cleaning

Interior Care

Exterior Care

Accessories and Modifications

* Not available on all models

Inspection and Maintenance

For your safety, perform all listed inspections and maintenance to keep your vehicle in good condition. If you become aware of any abnormality (noise, smell, insufficient brake fluid, oil residue on the ground, etc.), have your vehicle inspected by a dealer. Refer to the maintenance schedule in this owner's manual for detailed maintenance and inspection information.

➤ **Maintenance Schedule** P. 404

■ Types of Inspection and Maintenance

■ Routine inspections

Perform inspections before long distance trips, when washing the vehicle, or when refueling.

■ Periodic inspections

- Check the brake/clutch* fluid level monthly.
 - **Brake/Clutch* Fluid** P. 425
- Check the tyre pressure monthly. Examine the tread for wear and foreign objects.
 - **Checking and Maintaining Tyres** P. 439
- Check the operation of the exterior lights monthly.
 - **Replacing Light Bulbs** P. 428
- Check the condition of the wiper blades at least every six months.
 - **Checking and Maintaining Wiper Blades** P. 437

Safety When Performing Maintenance

Some of the most important safety precautions are given here. However, we cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether you should perform a given task.

Maintenance Safety

- To reduce the possibility of fire or explosion, keep cigarettes, sparks, and flames away from the battery and all fuel related parts.
- Never leave rags, towels, or other flammable objects under the bonnet.
 - Heat from the surrounding parts can ignite them, causing a fire.
- To clean parts, use a commercially available degreaser or parts cleaner, not petrol.
- Wear eye protection and protective clothing when working with the battery or compressed air.
- Engine exhaust contains carbon monoxide, which is poisonous and can kill you.
 - Only operate the engine if there is sufficient ventilation.

⚠ Safety When Performing Maintenance

⚠ WARNING

Improperly maintaining this vehicle or failing to correct a problem before driving can cause a crash in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations and schedules in this owner's manual.

⚠ WARNING

Failure to properly follow maintenance instructions and precautions can cause you to be seriously hurt or killed.

Always follow the procedures and precautions in this owner's manual.

■ Vehicle Safety

- The vehicle must be in a stationary condition.
 - Make sure your vehicle is parked on level ground, the parking brake is set, and the engine is off.
- Make sure that the radiator fan is stopped before inspecting the engine compartment.
 - Depending on the vehicle condition, the radiator fan may operate even when the power mode is in VEHICLE OFF.
- Be aware that hot parts can burn you.
 - Make sure to let the engine and exhaust system cool thoroughly before touching vehicle parts.
- Be aware that moving parts can injure you.
 - Do not start the engine unless instructed, and keep your hands and limbs away from moving parts.

Models with Auto Idle Stop


- Do not open the bonnet while the Auto Idle Stop function is activated.

Parts and Fluids Used in Maintenance Service

The use of Honda Genuine Parts and fluids is recommended when maintaining and servicing your vehicle. Honda Genuine Parts are manufactured according to the same high quality standards used in Honda vehicles.

The warning message notifies you when to change the engine oil, or when to bring your vehicle to a dealer for indicated maintenance services.

Displaying the Oil Monitor System Information



1. Set the power mode to ON.
2. Press the **(home) Button**.
3. Roll the left selector wheel until is displayed.
4. Press the left selector wheel to go to the oil monitor system information screen.
The engine oil life appears on the driver information interface.

The system message indicator () stays on in the instrument panel after the maintenance period reached. Have the indicated maintenance done by a dealer immediately.

Displaying the Oil Monitor System Information

Based on the engine operating and engine oil conditions, the remaining distance to the next maintenance period is calculated and displayed.

By driving conditions, actual travel distance might be shorter than the displayed distance.

Regardless of what the oil monitor system information indicates, perform maintenance regularly. Please refer to the maintenance schedule for more details.

 **Maintenance Schedule** P. 404

Oil Monitor System Information on the Driver Information Interface


Warning Message	Oil Life Display	Information
Normal	 Distance to engine oil replacement ----- km	When you reset the remaining distance after an oil change, a series of dots will appear in the oil life display. These dots will remain displayed until the system determines, based on the driving conditions, the remaining distance until the next oil change, or the next oil and filter change.
	 Distance to engine oil and filter replacement ----- km	
	 Distance to engine oil replacement 2000 km	When you select the oil monitor system information screen, the remaining engine oil life, or the remaining engine oil and oil filter life is displayed.
	 Distance to engine oil and filter replacement 2000 km	

Warning Message	Oil Life Display	Information
Replacement Due Soon  Engine oil replacement due soon  Engine oil and filter replacement due soon	 Distance to engine oil replacement 1490 km  Distance to engine oil and filter replacement 1490 km	The engine oil, or the engine oil and oil filter are approaching the end of their life.
Replacement Due Now  Engine oil replacement due now  Engine oil and filter replacement due now	 Distance to engine oil replacement 490 km  Distance to engine oil and filter replacement 490 km	The engine oil, or the engine oil and oil filter have almost reached the end of their service life, and the maintenance service item(s) should be inspected and serviced as soon as possible.

Warning Message	Oil Life Display	Information
Replacement Past Due  Engine oil replacement overdue  Engine oil and filter replacement overdue	 Distance to engine oil replacement - 10 km  Distance to engine oil and filter replacement - 10 km	The engine oil, or the engine oil and oil filter have passed their service life. The maintenance service item(s) must be inspected and serviced immediately.

Resetting the Display

Reset the engine oil monitor system information if you have performed the maintenance service.



1. Set the power mode to ON.
2. Press the (home) button.
3. Roll the left selector wheel until **Clock & vehicle settings** is displayed.
4. Roll the left selector wheel until **Maintenance reset** is displayed.
5. Roll the left selector wheel to select **Reset** (You can also select **Cancel** to end the process).
6. Press the left selector wheel to reset the selected item.
 - ▶ When the oil monitor system information display is reset, the engine oil life is reset to ----- km.

Resetting the Display

NOTICE

Failure to reset the engine oil life after a maintenance service results in the system showing incorrect maintenance intervals, which can lead to serious mechanical problems.

The dealer will reset the engine oil life display after completing the required maintenance service. If someone other than a dealer performs maintenance service, reset the engine oil life display yourself.

When your vehicle’s travel distance has been accumulated, you will see a message that reminds you it is time to take your vehicle in for scheduled maintenance.

➤ **Maintenance Schedule** P. 404

When Required Maintenance Approaches

A message appears on the driver information interface every time you set the power mode to ON.

Reminder Message on the Driver Information Interface


Reminder Message	Explanation	Information
	Your vehicle’s accumulated distance is between 8,500 km and 10,000 km. Once you switch the display by rolling the left selector wheel, this message will go off.	Your vehicle should be inspected and serviced soon.
	Your vehicle’s accumulated distance has exceeded 10,000 km without performing scheduled maintenance. Rolling the left selector wheel to switch to another display.	Have the scheduled maintenance performed as soon as possible.

The system message indicator (i) comes on along with the service reminder information.

Maintenance

■ Resetting the Display

Reset the maintenance reminder display if you have performed the maintenance services.



1. Set the power mode to ON
2. Press the  (home) button and roll the left selector to select , then press the left selector wheel.
3. Roll the left selector wheel until **Maintenance Reset** appears on the display.
4. Press the left selector wheel.
5. Roll the left selector to select **Reset**, then press the left selector wheel to reset the accumulated distance for the scheduled maintenance.
 - ▶ If you want to cancel the maintenance required display reset mode, select **Cancel**.

▣ Resetting the Display

The dealer will reset the maintenance reminder display after completing the required maintenance services. If someone other than a dealer performs maintenance service, reset the display yourself.

Maintenance Schedule

If your vehicle comes with the service book (Warranty booklet), the maintenance schedule for your vehicle is available in the book. For vehicles without the service book (Warranty booklet), refer to the following maintenance schedules.

The maintenance schedule outlines the minimum required maintenance that you should perform to ensure the troublefree operation of your vehicle. Due to regional and climatic differences, some additional servicing may be required. Please consult the service information provided for your vehicle for a more detailed description.

Maintenance work should be performed by properly trained and equipped technicians. Your authorised dealer meets all of these requirements.

Except Thai models

Service at the indicated distance or time - whichever comes first.	km x 1,000	20	40	60	80	100	120	140	160	180	200
	months	12	24	36	48	60	72	84	96	108	120
Replace engine oil	Normal	Every 10,000 km or 1 year									
	Severe	Every 5,000 km or 6 months									
Replace engine oil filter	Normal	Every 20,000 km or 2 years									
	Severe	Every 10,000 km or 1 year									
Replace air cleaner element		Every 30,000 km* ² Every 20,000 km* ³									
Inspect valve clearance* ¹		Every 120,000 km									

*1:Sensory Method: Adjust the valves during service 120,000 km if they are noisy.

*2:Except Indian models

*3:Indian models

Service at the indicated distance or time - whichever comes first.	km x 1,000		20	40	60	80	100	120	140	160	180	200
	months		12	24	36	48	60	72	84	96	108	120
Replace spark plugs	Every 100,000 km											
Inspect drive belt	• • • • •											
Replace engine coolant	At 200,000 km or 10 years, thereafter every 100,000 km or 5 years											
Replace transmission fluid	MT	Normal						•				
		Severe			•			•			•	
	CVT			•		•		•		•		•
Replace dust and pollen filter	• • • • • • • • • • • •											
Inspect front and rear brakes	Every 10,000 km or 1 year											
Replace fuel filter*1	Normal		Every 120,000 km*2, *3, *4 Every 140,000 km*5									
	Severe		Every 60,000 km*2, *3, *4 Every 90,000 km*5									
Replace brake fluid	Every 3 years											
Check parking brake adjustment	• • • • • •											
Rotate tyres (Check tyre inflation and condition at least once per month)	Every 10,000 km											

*1: It is recommended that you replace the fuel filter if the fuel you are using is suspected to be contaminated with dust, etc. because the filter may be clogged sooner.

*2: Indian, Zambian, Zimbabwe, Botswana, Namibian, Mozambique, Seychelles, Mauritius, Kenya, Guyana, Suriname and Indonesian models

*3: GCC country models

*4: African models

*5: Models for other countries

Service at the indicated distance or time - whichever comes first.	km x 1,000	20	40	60	80	100	120	140	160	180	200
	months	12	24	36	48	60	72	84	96	108	120

Visually inspect the following items:

Tie rod ends, steering gear box, and boots Suspension components Driveshaft boots	Every 10,000 km or 1 year										
Battery electrolyte level*1	Every 10,000 km or 6 months										
Brake hoses and lines (including ABS/VSA) All fluid levels and condition of fluid Exhaust system Fuel lines and connections	•	•	•	•	•	•	•	•	•	•	•

*1:GCC country models

Thai models

Service at the indicated distance or time - whichever comes first.	km x 1,000 months	20 12	40 24	60 36	80 48	100 60	120 72	140 84	160 96	180 108	200 120
Replace engine oil		When indicator comes on or 1 year									
Replace engine oil filter		When indicator comes on or 2 year									
Replace air cleaner element		Every 30,000 km									
Inspect valve clearance* ¹		Every 120,000 km									
Replace spark plugs		Every 100,000 km									
Replace timing belt						•					•
Inspect drive belt			•		•		•		•		•
Replace engine coolant		At 200,000 km or 10 years, thereafter every 100,000 km or 5 years									
Replace transmission fluid			•		•		•		•		•
Inspect front and rear brakes		Every 10,000 km or 1 year									

*1: Sensory Method: Adjust the valves during service 120,000 km if they are noisy.

Service at the indicated distance or time - whichever comes first.	km x 1,000 months	20	40	60	80	100	120	140	160	180	200
		12	24	36	48	60	72	84	96	108	120
Replace brake fluid		Every 3 years									
Replace fuel filter	Normal	Every 140,000km									
	Severe	Every 90,000km* ¹									
Check parking brake adjustment		•	•		•		•		•		•
Replace dust and pollen filter		•	•	•	•	•	•	•	•	•	•
Rotate tyres (Check tyre inflation and condition at least once per month)		Every 10,000 km									
Visually inspect the following items:											
Tie rod ends, steering gear box, and boots		Every 10,000 km or 1 year									
Suspension components											
Driveshaft boots											
Brake hoses and lines (including ABS/VSA)											
All fluid levels and condition of fluid		•	•	•	•	•	•	•	•	•	•
Exhaust system											
Fuel lines and connections											

*1: It is recommended that you replace the fuel filter if the fuel you are using is suspected to be contaminated with dust, etc. because the filter may be clogged sooner.

All models

If you drive your vehicle under severe conditions, you must have the following items served to the maintenance schedule indicated as Severe.

Items	Condition
Engine oil and oil filter	A, B, C, D and E
Transmission fluid	B, D

►► Maintenance Schedule

The condition is considered as severe when you drive:

- A. less than 8 km, or less than 16 km in freezing temperatures per trip.
- B. In extremely hot temperature above 35°C.
- C. With extensive idling or long periods of stop-and-go.
- D. With a loaded roof rack, or in mountains.
- E. On muddy, dusty or de-iced roads.

Maintenance Record

Have your servicing dealer record all required maintenance below. Keep receipts for all work done on your vehicle.

	Km or Month	Date	Sign or Stamp
	20,000 km (or 12 Mo.)		
	40,000 km (or 24 Mo.)		
	60,000 km (or 36 Mo.)		
	80,000 km (or 48 Mo.)		
	100,000 km (or 60 Mo.)		
	120,000 km (or 72 Mo.)		
	140,000 km (or 84 Mo.)		
	160,000 km (or 96 Mo.)		
	180,000 km (or 108 Mo.)		
	200,000 km (or 120 Mo.)		

Maintenance Items Under the Bonnet

Except Thai models

Right-hand Drive Type

Brake/Clutch* Fluid
(Black Cap)

Engine Oil Dipstick
(Orange)

Engine Oil Fill Cap

Washer Fluid
(Blue Cap)


Left-hand Drive Type

Brake/Clutch* Fluid
(Black Cap)

Battery


Engine Coolant
Reserve Tank

Radiator Cap




* Not available on all models



Thai models



Opening the Bonnet



1. Park the vehicle on a level surface, and set the parking brake.
2. Pull the bonnet release handle under the driver's side lower outside corner of the dashboard.
► The bonnet will pop up slightly.



3. Pull up the bonnet latch lever (located under the front edge of the bonnet to the centre) and raise the bonnet. Once you have raised the bonnet slightly, you can release the lever.

Opening the Bonnet

NOTICE

Do not open the bonnet when the wiper arms are raised. The bonnet will strike the wipers, resulting in possible damage to the bonnet and/or the wipers.


When closing the bonnet, check that the bonnet is securely latched.

If the bonnet latch lever moves stiffly, or if you can open the bonnet without lifting the lever, the latch mechanism should be cleaned and lubricated.

Models with Auto Idle Stop

Do not open the bonnet while the Auto Idle Stop function is activated.

Continued



4. Remove the support rod from the clamp using the grip. Mount the support rod in the bonnet.



When closing, remove the support rod and stow it in the clamp, then gently lower the bonnet. Remove your hand at a height of approximately 30 cm and let the bonnet close.

Recommended Engine Oil

Use a genuine engine oil or another commercial engine oil of suitable type and viscosity (for the ambient temperature) as shown in the image that follows.

Oil is a major contributor to your engine's performance and longevity. If you drive the vehicle with insufficient or deteriorated oil, the engine may fail or be damaged.

Except Thai models

Genuine Engine Oil	Commercial Engine Oil
- Honda Engine Oil #1.0^{*1} - Honda Green Oil - Honda Genuine Motor Oil	- API service SN or higher grade fuel-efficient oil - API Certification Mark "Starburst" or "Shield" - ACEA A5/B5
 Ambient Temperature	 Ambient Temperature

*1: Formulated to improve fuel economy.

Recommended Engine Oil

Engine Oil Additives

Your vehicle does not require oil additives. In fact, they may adversely affect the engine performance and durability.

The following seal indicates the oil is energy conserving and that it meets the American Petroleum Institute's latest requirements.





Except Thai models



Continued

Thai models

Genuine Engine Oil	Commercial Engine Oil
Honda Genuine Motor Oil	- API service SN or higher grade fuel-efficient oil - API Certification Mark "Starburst" - ACEA A5/B5
	



*1:Formulated to improve fuel economy.

Oil Check

We recommend that you check the engine oil level every time you refuel.

Park the vehicle on level ground.

Wait approximately three minutes after turning the engine off before you check the oil.




1. Remove the dipstick (orange).
2. Wipe the dipstick with a clean cloth or paper towel.
3. Insert the dipstick back all the way into its hole.

Oil Check


If the oil level is near or below the lower mark, slowly add oil, being careful not to overfill.

Continued

Except Thai models





Thai models



4. Remove the dipstick again, and check the level. It should be between the upper and lower marks. Add oil if necessary.

Adding Engine Oil



1. Unscrew and remove the engine oil fill cap.
2. Add oil slowly.
3. Reinstall the engine oil fill cap, and tighten it securely.
4. Wait for three minutes and recheck the engine oil dipstick.

Adding Engine Oil

NOTICE

Do not fill the engine oil above the upper mark. Overfilling the engine oil may result in leaks and engine damage.

If any oil spills, wipe it away immediately. Spilled oil may damage the engine compartment components.

Engine Coolant

Specified coolant: Honda All Season Antifreeze/Coolant Type 2

This coolant is premixed with 50% antifreeze and 50% water. Do not add any straight antifreeze or water.

Except Thai models

We recommend you check the engine coolant level every time you refuel. Check the reserve tank first. If it is completely empty, also check the coolant level in the radiator. Add the engine coolant accordingly.

Thai models

We recommend you check the engine coolant level every time you refuel. Check the reserve tank. Add the engine coolant accordingly.

» Engine Coolant

Except Thai models

WARNING

Removing the radiator cap while the engine is hot can cause the coolant to spray out, seriously scalding you.

Always let the engine and radiator cool down before removing the radiator cap.

Thai models

WARNING

Removing the reserve tank cap while the engine is hot can cause the coolant to spray out, seriously scalding you.



Always let the engine and radiator cool down before removing the reserve tank cap.

NOTICE

If temperatures consistently below -30°C are expected, the coolant mixture should be changed to a higher concentration. Consult your Honda dealer for details about a suitable coolant mixture.

Except Thai models

Reserve Tank



1. **Make sure the engine and radiator are cool.**
2. Check the amount of coolant in the reserve tank.
 - If the coolant level is below the **MIN** mark, add the specified coolant until it reaches the **MAX** mark.
3. Inspect the cooling system for leaks.


Engine Coolant

If Honda antifreeze/coolant is not available, you may use another major brand of non-silicate coolant as a temporary replacement. Check that it is a high quality coolant recommended for aluminium engines. Continued use of any non-Honda coolant can result in corrosion, causing the cooling system to malfunction or fail. Have the cooling system flushed and refilled with Honda antifreeze/coolant as soon as possible.

Do not add rust inhibitors or other additives to your vehicle's cooling system. They may not be compatible with the coolant or with the engine components.

Continued


Radiator



1. **Make sure the engine and radiator are cool.**
2. Turn the radiator cap 1/8th turn anticlockwise and relieve any pressure in the cooling system.
3. Push down and turn the radiator cap anticlockwise to remove it.
4. The coolant level should be up to the base of the filler neck. Add coolant if it is low.
5. Put the radiator cap back on, and tighten it fully.

Thai models

Checking the Coolant




1. **Make sure the engine and radiator are cool.**
2. Check the amount of coolant in the reserve tank.
 - If the coolant level is below the **MIN** mark, add the specified coolant until it reaches the **MAX** mark.
3. Inspect the cooling system for leaks.

►► Radiator

NOTICE


Pour the fluid slowly and carefully so you do not spill any. Clean up any spills immediately; they can damage components in the engine compartment.

■ Adding the Coolant



1. **Make sure the engine and radiator are cool.**
2. Turn the reserve tank cap 1/8th turn anticlockwise and relieve any pressure in the cooling system.
3. Turn the reserve tank cap anticlockwise to remove it.
4. Pour coolant into the reserve tank until it reaches the **MAX** mark.
5. Put the reserve tank cap back on, and tighten it fully.

■ Radiator Cap *



- Never open when hot.
- Hot coolant will scald you.
- Relief pressure valve begins to open at 108 kPa.

►► Adding the Coolant

NOTICE

Pour the fluid slowly and carefully so you do not spill any. Clean up any spills immediately; they can damage components in the engine compartment.

* Not available on all models

Transmission Fluid

Manual transmission models

Manual Transmission Fluid

Specified fluid: Honda MTF

Have a dealer check the fluid level and replace if necessary.
Follow your vehicle's maintenance service timing of when to change manual transmission fluid.

➤ **Maintenance Schedule** P. 404

Do not attempt to check or change the manual transmission fluid yourself.

Continuously variable transmission models

Continuously Variable Transmission (CVT) Fluid

Specified fluid: Honda HCF-2

Have a dealer check the fluid level and replace if necessary.
Follow your vehicle's maintenance service timing of when to change continuously variable transmission fluid.

➤ **Maintenance Schedule** P. 404

Do not attempt to check or change the continuously variable transmission fluid yourself.

►► Manual Transmission Fluid

NOTICE

If Honda MTF is not available, you may use the API certificated SAE 0W-20 or 5W-20 viscosity motor oil as a temporary measure.

Replace with MTF as soon as possible. Motor oil does not contain the proper additives for the transmission and continued use can cause decreased shifting performance and lead to transmission damage.

►► Continuously Variable Transmission (CVT) Fluid

NOTICE

Do not mix Honda HCF-2 with other transmission fluids.

Using a transmission fluid other than Honda HCF-2 may adversely affect the operation and durability of your vehicle's transmission, and damage the transmission.

Any damage caused by using a transmission fluid that is not equivalent to Honda HCF-2 is not covered by Honda's new vehicle limited warranty.


Brake/Clutch * Fluid

Specified fluid: Brake Fluid with DOT 3 or DOT 4

■ Checking the Brake Fluid


Except Thai models

Right-hand Drive Type



Except Thai models

Left-hand Drive Type



The fluid level should be between the **MIN** and **MAX** marks on the side of the reserve tank.

Manual transmission models

The brake fluid reserve tank is also used for your vehicle's clutch fluid. As long as you keep the brake fluid level as instructed above, there is no need for checking the clutch fluid level.

» Brake/Clutch * Fluid

NOTICE


Brake fluid marked DOT 5 is not compatible with your vehicle's braking system and can cause extensive damage.

We recommend using a genuine product.

If the brake fluid level is at or below the **MIN** mark, have a dealer inspect the vehicle for leaks or worn brake pads as soon as possible.


* Not available on all models

Continued




Refilling Window Washer Fluid

Check the amount of window washer fluid by looking at the reservoir.



If the level is low, fill the washer reservoir.

Pour the washer fluid carefully. Do not overflow the reservoir.



Fuel Filter

Replace fuel filter according to the time and distance recommendations in the maintenance schedule.

Have a qualified technician change the fuel filter. Fuel in the system can spray out and create a hazard if all fuel line connections are not handled correctly.

Refilling Window Washer Fluid

NOTICE

Do not use engine antifreeze or a vinegar/water solution in the windscreen washer reservoir. Antifreeze can damage your vehicle's paint. A vinegar/water solution can damage the windscreen washer pump. Use only commercially available windscreen washer fluid. Avoid prolonged use of hard water to prevent lime scale buildup.

Headlight Bulbs

Headlights are LED type. Have an authorised Honda dealer inspect and replace the light assembly.

Front Turn Signal, Position/Daytime Running Lights


Front turn signal, position/daytime running lights are LED type. Have an authorised Honda dealer inspect and replace the light assembly.

Side Turn Signal/Emergency Indicator Light Bulbs

Fender type

When replacing, use the following bulbs.

Side Turn Signal Light: 5 W Amber (WY5W)



Door mirror type

Door mirror side turn lights are LED type. Have an authorised Honda dealer inspect and replace the light assembly.


» Headlight Bulbs

The headlight aim is set by the factory, and does not need to be adjusted. However, if you regularly carry heavy items in the boot, have the aiming readjusted at a dealer or by a qualified technician.


Brake Light, Rear Side Marker/Taillight and Rear Turn Signal Light Bulbs

When replacing, use the following bulbs.

Brake Light:	LED Type
Rear Side Marker/Taillight:	LED Type
Rear Turn Signal Light:	21W Amber (WY21W)




1. Remove the holding clips using a flat-tip screwdriver, then pull the lining back.




2. Pry on the edge of the cover using a flat-tip screwdriver to remove the cover.
► Wrap the flat-tip screwdriver with a cloth to prevent scratches.

► Brake Light, Rear Side Marker/Taillight and Rear Turn Signal Light Bulbs


Brake lights, rear side marker/taillights are LED type. Have an authorised Honda dealer inspect and replace the light assembly.



3. Use a Phillips-head screwdriver or socket to remove the bolts.



4. Pull the light assembly out of the rear pillar.





5. Turn the socket anticlockwise and remove it.
6. Remove the old bulb and insert a new bulb.

Back-Up Light and Taillight Bulb(s)

When replacing, use the following bulbs.

Back-Up Light: 16 W (W16W)

Taillight: LED Type



1. Remove the holding clips using a flat-tip screwdriver, then pull the lining back.
2. Turn the socket anticlockwise and remove it.
3. Remove the old bulb and insert a new bulb.


Back-Up Light and Taillight Bulb(s)

Taillights are LED type. Have an authorised Honda dealer inspect and replace the light assembly.


Rear Licence Plate Light Bulbs

When replacing, use the following bulb.

Rear Licence Plate Light: 5 W (W5W)



1. Remove the holding clips using a flat-tip screwdriver, then pull the lining back.



2. Remove the licence plate light assembly by squeezing the tabs on both sides of the socket.
3. Remove the old bulb and insert a new bulb.

High-Mount Brake Light

High-mount brake light is LED type. Have an authorised Honda dealer inspect and replace the light assembly.

Rear Fog Light*

Rear fog light is LED type. Have an authorised Honda dealer inspect and replace the light assembly.

Grille Light*

Grille Light is LED type. Have an authorised Honda dealer inspect and replace the light assembly.


* Not available on all models

Other Light Bulbs


■ Ceiling Light Bulb*

When replacing, use the following bulb.

Ceiling Light: 8 W



1. Pry on the edge of the cover using a flat-tip screwdriver to remove the cover.
► Wrap the flat-tip screwdriver with a cloth to prevent scratches.




2. Remove the old bulb and insert a new bulb.


■ Ceiling Light Bulb*

When replacing, use the following bulb.

Ceiling Light: 8 W



1. Pry on the edge of the cover using a flat-tip screwdriver to remove the cover.
► Wrap the flat-tip screwdriver with a cloth to prevent scratches.




2. Remove the old bulb and insert a new bulb.

Models with sunroof


■ Map Light Bulbs*

When replacing, use the following bulbs.

Map Light: 8 W



1. Push on the lens of the opposite side you are replacing.
2. Pry on the edge of the cover using a flat-tip screwdriver to remove the cover.
► Wrap the flat-tip screwdriver with a cloth to prevent scratches.




3. Remove the old bulb and insert a new bulb.

Models without sunroof


Map Light Bulbs*

When replacing, use the following bulbs.

Map Light: 8 W



- 1.** Push on the lens of the opposite side you are replacing.
- 2.** Pry on the edge between the lenses using a flat-tip screwdriver to remove the cover.
 - Wrap the flat-tip screwdriver with a cloth to prevent scratches.




3. Remove the old bulb and insert a new bulb.

* Not available on all models


■ Boot Light Bulb

When replacing, use the following bulb.

Boot Light: 5 W



1. Pry on the edge of the cover using a flat-tip screwdriver to remove the cover.
 - Wrap the flat-tip screwdriver with a cloth to prevent scratches.




2. Remove the old bulb and insert a new bulb.


Checking Wiper Blades

If the wiper blade rubber has deteriorated, it will leave streaks and become noisy, and the hard surfaces of the blade may scratch the window glass.

Changing the Wiper Blade Rubber



1. Lift the driver side wiper arm first, then the passenger side.




2. Press up on and hold the tab, then slide the holder off the wiper arm.


Changing the Wiper Blade Rubber

NOTICE

Avoid dropping the wiper arm onto the windshield, as it may damage the wiper arm and/or the windshield.



3. Slide the wiper blade out of the holder by pulling the tabbed end out.



4. Remove the retainers from the wiper blade that has been removed, and mount to a new wiper blade.
 - Correctly align the wiper blade protrusion and the retainer grooves.
5. Slide the new wiper blade onto the holder from the bottom end.
 - The tab on the holder should fit in the indent of the wiper blade.
6. Slide the holder onto the wiper arm securely.
7. Lower the passenger side wiper arm first, then the driver side.

Checking Tyres

To safely operate your vehicle, your tyres must be of the proper type and size, in good condition with adequate tread, and properly inflated.

■ Inflation guidelines

Properly inflated tyres provide the best combination of handling, tread life, and comfort. Refer to the driver's doorjamb label for the specified pressure.

Underinflated tyres wear unevenly, adversely affect handling and fuel economy, and are more likely to fail from overheating.

Overinflated tyres make your vehicle ride harshly, are more prone to road hazards, and wear unevenly.

Every day before you drive, look at each of the tyres. If one looks lower than the others, check the pressure with a tyre gauge.

At least once a month or before long trips, use a gauge to measure the pressure in all tyres, including the spare*. Even tyres in good condition can lose 10-20 kPa (0.1-0.2 bar, 1-2 psi) per month.

⌘ Checking Tyres

⚠ WARNING

Using tyres that are excessively worn or improperly inflated can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding tyre inflation and maintenance.

Measure the air pressure when tyres are cold. This means the vehicle has been parked for at least three hours, or driven less than 1.6 km. If necessary, add or release air until the specified pressure is reached.

If checked when hot, tyre pressure can be as much as 30-40 kPa (0.3-0.4 bar, 4-6 psi) higher than if checked when cold.

Have a dealer check the tyres if you feel a consistent vibration while driving. New tyres and any that have been removed and reinstalled should be properly balanced.

Models with deflation warning system

Whenever tyre pressure is adjusted, you must calibrate the deflation warning system.

➤ **Deflation Warning System*** P. 301

* Not available on all models

■ Inspection guidelines

Every time you check inflation, also examine the tyres and valve stems.

Look for:

- Bumps or bulges on the side or in the tread. Replace the tyre if you find any cuts, splits, or cracks in the side of the tyre. Replace it if you see fabric or cord.
- Remove any foreign objects and inspect for air leaks.
- Uneven tread wear. Have a dealer check the wheel alignment.
- Excessive tread wear.
 - **Wear Indicators** P. 441
- Cracks or other damage around valve stem.

» Checking Tyres

High speed driving

We recommend that you do not drive faster than the posted speed limits and conditions allow. If you drive at sustained high speeds (over 160 km/h), adjust the cold tyre pressures as shown below to avoid excessive heat buildup and sudden tyre failure.

Models with 185/60R15 84H tyre

Tyre Size	185/60R15 84H
Pressure*1	Front: 240 kPa (2.4 bar, 35 psi) Rear: 230 kPa (2.3 bar, 33 psi)
Pressure*2	Front: 250 kPa (2.5 bar, 36 psi) Rear: 230 kPa (2.3 bar, 33 psi)

*1: Indian models

*2: Models for other countries


Models with 185/55R16 83H tyre

Tyre Size	185/55R16 83H
Pressure	Front: 250 kPa (2.5 bar, 36 psi) Rear: 240 kPa (2.4 bar, 35 psi)

Models with 185/55R16 87H tyre

Tyre Size	185/55R16 87H
Pressure	Front: 260 kPa (2.6 bar, 38 psi) Rear: 240 kPa (2.4 bar, 35 psi)

Wear Indicators



The groove where the wear indicator is located is about 1.6 mm shallower than elsewhere on the tyre. If the tread has worn so that the indicator is exposed, replace the tyre.

Worn out tyres have poor traction on wet roads.

Tyre Service Life

The life of your tyres is dependent on many factors, including driving habits, road conditions, vehicle loading, inflation pressure, maintenance history, speed, and environmental conditions (even when the tyres are not in use).

In addition to regular inspections and inflation pressure maintenance, it is recommended that you have annual inspections performed once the tyres reach five years old. All tyres, including the spare, should be removed from service after 10 years from the date of manufacture, regardless of their condition or state of wear.

Tyre and Wheel Replacement

Replace your tyres with radials of the same size, load range, speed rating, and maximum cold tyre pressure rating (as shown on the tyre's sidewall). Using tyres of a different size or construction can cause certain vehicle systems such as the ABS and Vehicle Stability Assist (VSA) system to work incorrectly.

It is best to replace all four tyres at the same time. If that isn't possible, replace the front or rear tyres in pairs.

Make sure that the wheel's and wheel nut's specifications match those of the original wheels.

►► Tyre and Wheel Replacement

⚠ WARNING

Installing improper wheel, wheel nuts and tyres on your vehicle can affect handling and stability. This can cause a crash in which you can be seriously hurt or killed.

Always use the size and type of tyres recommended in the tyre information label on your vehicle.


Tyre Rotation

Rotating tyres according to the maintenance schedule helps to distribute wear more evenly and increase tyre life.

■ Your Vehicle's Tyre Rotation Pattern


Models with a compact/temporary spare tyre

Rotate the tyres as shown here.



Models with a full-size spare tyre


Rotate the tyres, including a spare, as shown here.



* Not available on all models

► Tyre Rotation

Tyres with directional tread patterns should only be rotated front to back (not from one side to the other). Directional tyres should be mounted with the rotation indication mark facing forward, as shown below.



When the tyres are rotated, make sure the air pressures are checked.

► Models with deflation warning system

Whenever tyres are rotated, you must calibrate the deflation warning system.

► **Deflation Warning System*** P. 301

Wheel nut torque for the tyres that come standard-equipped with your vehicle is as follows.

Wheel nut torque:
108 N·m (11 kgf·m, 80 lbf·ft)

Snow Traction Devices

If driving on snowy or frozen roads, mount winter tyres, or tyre chains; reduce speed; and maintain sufficient distance between vehicles when driving.

Be particularly careful when operating the steering wheel or brakes to prevent skidding.

Use tyre chains, winter tyres, or all season tyres when necessary or according to the law.

When mounting, refer to the following points.

For winter tyres:

- Select the size and load ranges that are the same as the original tyres.
- Mount the tyres to all four wheels.

For tyre chains:

- Consult a dealer before purchasing any type of chains for your vehicle.
- Install them on the front tyres only.
- Because your vehicle has limited tyre clearance, we strongly recommend using the chains listed below:

Bhutanese, Cambodian, Indian, Laotian, Nepalese, and Philippines models

Original Tyre Size*1	Chain Type
185/60R15 84H	RUD-matic classic 48478
185/55R16 83H	RUD-matic classic 48479
185/55R16 87H	

*1:Original tyre size is mentioned on the tyre information label on the driver’s doorjamb.

» Snow Traction Devices

⚠ WARNING

Using the wrong chains, or not properly installing chains, can damage the brake lines and cause a crash in which you can be seriously injured or killed.

Follow all instructions in this owner’s manual regarding the selection and use of tyre chains.

NOTICE

Traction devices that are the wrong size or improperly installed can damage your vehicle’s brake lines, suspension, body, and wheels. Stop driving if they are hitting any part of the vehicle.

- Follow the chain manufacturer's instruction when installing. Mount them as tightly as you can.
- Check that the chains do not touch the brake lines or suspension.
- Drive slowly.

❏ Snow Traction Devices


When tyre chains are mounted, follow the chain manufacturer's instructions regarding vehicle operational limits.

Use tyre chains only in an emergency or when they are legally required for driving through a certain area.

Use greater caution when driving with tyre chains on snow or ice. They may have less-predictable handling than good winter tyres without chains.

If your vehicle is equipped with summer tyres, be aware that these tyres are not designed for winter driving conditions. For more information, contact a dealer.


Checking the Battery



Models with test indicator window on the battery

Check the battery condition monthly. Look at the test indicator window and check the terminals for corrosion.

The battery condition is monitored by the sensor on the negative terminal. If there is a problem with the sensor, the warning message on information display*/driver information interface* will let you know. Have your vehicle checked by a dealer.



Models without test indicator window on the battery

The condition of the battery is monitored by a sensor located on the negative terminal of the battery. If there is a problem with this sensor, the information display*/driver information interface* will display a warning message. If this happens, have your vehicle inspected by a dealer.

Check the battery terminals for corrosion monthly.

If your vehicle's battery is disconnected or goes dead:

- The clock resets.

🔧 Clock P. 180

» Battery

⚠ WARNING

The battery gives off explosive hydrogen gas during normal operation.

A spark or open flame can cause the battery to explode with enough force to kill or seriously hurt you.

Keep all sparks, open flames, and smoking materials away from the battery.

Wear protective clothing and a face shield, or have a skilled technician do any battery maintenance.

⚠ WARNING

The battery contains sulfuric acid (electrolyte) which is highly corrosive and poisonous.

Getting electrolyte in your eyes or on your skin can cause serious burns. Wear protective clothing and eye protection when working on or near the battery.

Swallowing electrolyte can cause fatal poisoning if immediate action is not taken.

KEEP OUT OF THE REACH OF CHILDREN

Charging the Battery

Disconnect both battery cables to prevent damaging your vehicle's electrical system. Always disconnect the negative (-) cable first, and reconnect it last.

⚠ Battery

Emergency Procedures

Eyes: Flush with water from a cup or other container for at least 15 minutes. (Water under pressure can damage the eye.) Call a physician immediately.

Skin: Remove contaminated clothing. Flush the skin with large quantities of water. Call a physician immediately.

Swallowing: Drink water or milk. Call a physician immediately.

When you find corrosion, clean the battery terminals by applying a baking powder and water solution. Clean the terminals with a damp towel. Cloth/towel dry the battery. Coat the terminals with grease to help prevent future corrosion.

When replacing the battery, the replacement must be of the same specifications. Consult a dealer for more information.

Models with test indicator window on the battery

The test indicator's colour information is on the battery.

The location of the test indicator window may vary depending on the model.

►► Battery

Models with Auto Idle Stop

The 12-volt battery installed in this vehicle is specifically designed for a model with Auto Idle Stop. Using a 12-volt battery other than this specified type may shorten the battery life, and prevent Auto Idle Stop from activating. If you need to replace the battery, make sure to select the specified type and size. Ask a dealer for more details.

▣ Specifications P. 524

The Adaptive Cruise Control (ACC)*, vehicle stability assist (VSA) system, vehicle stability assist (VSA) **OFF**, safety support*, low tyre pressure/deflation warning system*, Collision Mitigation Braking System (CMBS)*, and Road Departure Mitigation* indicators may come on in amber along with a message in the driver information interface when you set the power mode to ON after reconnecting the battery. Drive a short distance at more than 20 km/h (mph). Each indicator should go off. If any do not, have your vehicle checked by a dealer.

Battery Label *



▶▶ Battery Label *

DANGER

- Keep flames and sparks away from the battery. The battery produces explosive gas that can cause an explosion.
- Wear eye protection and rubber gloves when handling the battery to avoid risk of burns or loss of eyesight if exposed to battery electrolyte.
- Do not allow children to handle the battery, under any circumstance. Ensure that anyone handling the battery has a proper understanding of the hazards and correct handling procedures involved.
- Handle battery electrolyte with extreme care, as it contains dilute sulfuric acid. Exposure to eyes or skin can cause burns or loss of eyesight.
- Read this manual carefully, and understand it before handling the battery. Failure to do so can cause personal injury and damage to the vehicle.
- Do not use the battery if the level of electrolyte is at or below the recommended level. Using the battery with low electrolyte can cause it to explode, causing serious injury.

* Not available on all models


Replacing the Remote Battery

If the indicator does not come on when the button is pressed, replace the battery.



Battery type: CR2032

1. Remove the built-in key.
2. With the buttons facing down, remove the upper half of the cover by carefully prying on the edge with a coin.
 - Wrap a coin with a cloth to prevent scratching the keyless remote.
3. Make sure to replace the battery with the correct polarity.



» Replacing the Remote Battery

⚠ ⚠ WARNING

CHEMICAL BURN HAZARD

The battery that powers the remote transmitter can cause severe internal burns and can even lead to death if swallowed. Keep new and used batteries away from children.

If you suspect that a child has swallowed the battery, seek medical attention immediately.

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

CAUTION: Do not exposed to excessive heat such as sunshine, fire or the like, that can result in an explosion or the leakage of flammable liquid or gas during use, storage or transportation.

CAUTION: Do not dispose of a battery into fire or a hot oven, or give mechanically crushing or cutting of a battery, that can result in an explosion.

CAUTION: Do not subjected to extremely low air pressure at high altitude that may result in an explosion or the leakage of flammable liquid or gas.

A warning mark is located adjacent to the button battery*.

» Replacing the Remote Battery

NOTICE

An improperly disposed of battery can damage the environment. Always confirm local regulations for battery disposal.

Replacement batteries are commercially available or at a dealer.

Dust and Pollen Filter

■ When to Replace the Dust and Pollen Filter


Replace the dust and pollen filter according to your vehicle's recommended maintenance schedule. It is recommended to replace the filter even sooner if the vehicle has been driven in a dusty environment.

➤ **Maintenance Schedule** P. 404

■ How to Replace the Dust and Pollen Filter



1. Open the glove box.




2. Disengage the two tabs by pushing on each side panel.

3. Pivot the glove box out of the way.

» Dust and Pollen Filter

If the airflow from the heating system* and cooling system*/climate control system* deteriorates noticeably, and the windows fog up easily, the filter may need to be replaced.

The dust and pollen filter collects pollen, dust, and other debris in the air.



4. Push in the tabs on the corners of the filter case cover, and remove it.
5. Remove the filter from the case.
6. Install a new filter in the case.
 - Put the **AIR FLOW** arrow directed side down.

▣ Dust and Pollen Filter

If you are not sure how to replace the dust and pollen filter, have it replaced by a dealer.

* Not available on all models

Interior Care

Use a vacuum cleaner to remove dust before using a cloth.

Use a damp cloth with a mixture of mild detergent and warm water to remove dirt.

Use a clean cloth to remove detergent residue.

Cleaning Seat Belts

Use a soft brush with a mixture of mild soap and warm water to clean the seat belts. Let the belts air dry. Wipe the openings of the seat belt anchorages using a clean cloth.



Cleaning the Window

Wipe using a glass cleaner.

» Interior Care

Do not spill liquids inside the vehicle. Electrical devices and systems may malfunction if liquids are splashed on them.

Do not use silicone-based sprays on electrical devices such as audio devices and switches.

Doing so may cause the items to malfunction or cause a fire inside the vehicle.

If a silicone-based spray is inadvertently used on electrical devices, consult a dealer.

Depending on their composition, chemicals and liquid aromatics may cause discolouration, wrinkles, and cracking to resin-based parts and textiles.

Do not use alkali solvents or organic solvents such as benzene or petrol.

After using chemicals, make sure to gently wipe them away using a dry cloth.

Do not place used cloths on top of resin-based parts or textiles for long periods of time without washing.


Be careful not to spill a liquid type air freshener.

» Cleaning the Window

Wires are mounted to the inside of the rear window. Wipe along the same direction as the wires with a soft cloth so as not to damage them.

Be careful not to spill fluids, such as water or glass cleaner, on or around the cover of the electrical components* around the rearview mirror.

Floor Mats



The driver's floor mat hooks over floor anchorages, which keep the mat from sliding forward.

Do not put any additional floor mats on top of the anchored mat.

Maintaining Genuine Leather*

To properly clean leather:

1. Use a vacuum or soft dry cloth first to remove any dirt or dust.
2. Clean the leather with a soft cloth dampened with a solution comprised of 90% water and 10% neutral soap.
3. Wipe away any soap residue with a clean damp cloth.
4. Wipe away residual water and allow leather to air dry in the shade.

* Not available on all models

Floor Mats

If you use any floor mats that were not originally provided with your vehicle, make sure they are designed for your specific vehicle, fit correctly, and are securely anchored by the floor anchorages. Position any rear seat floor mats properly. If not properly positioned, the floor mats can interfere with the front seat functions.

Maintaining Genuine Leather*

It is important to clean or wipe away dirt or dust as soon as possible. Spills can soak into leather, resulting in stains. Dirt or dust can cause abrasions in the leather. In addition, please note that some dark coloured clothing can rub onto the leather seats, resulting in discolouration or stains.

Exterior Care

Dust off the vehicle body after you drive. Regularly inspect your vehicle for scratches on painted surfaces. A scratch on a painted surface can result in body rust. If you find a scratch, promptly repair it.

■ Washing the Vehicle

Wash the vehicle regularly. Wash more frequently when driving in the following conditions:

- If driving on roads with road salt.
- If driving in coastal areas.
- If tar, soot, bird droppings, insects, or tree sap is stuck to painted surfaces.

■ Using an Automated Car Wash


- Make sure to follow the instructions indicated on the automated car wash.
- Fold in the door mirrors.
- For models equipped with automatic intermittent wipers, turn the wipers off.

■ Using High Pressure Cleaners

- Keep sufficient distance between the cleaning nozzle and the vehicle body.
- Take particular care around the windows. Standing too close may cause water to enter the vehicle interior.
- Do not spray high pressure water directly into the engine compartment. Instead, use low pressure water and a mild detergent.
- Do not spray water directly onto the camera* or the area around it. Water may enter the lens and cause the camera to malfunction.

►► Washing the Vehicle

Do not spray water into the air intake vents. It can cause a malfunction.



If water and any chemicals are on the brakes when your vehicle is being washed, drive a short distance and apply the brakes several times before parking. Parking while brakes are wet may cause them to be stuck by rust.

■ Applying Wax

A good coat of automotive body wax helps to protect your vehicle's paint from the elements. Wax will wear off over time and expose your vehicle's paint to the elements, so reapply as necessary.

■ Maintaining the Bumpers and Other Resin-Coated Parts

If you get petrol, oil, engine coolant, or battery fluid on resin-coated parts, they may stain or the coating may peel. Promptly wipe it away using a soft cloth and clean water.

■ Cleaning the Window

Wipe using a glass cleaner.

■ Maintaining Aluminium Wheels *

Aluminium is susceptible to deterioration caused by salt and other road contaminants. When necessary, as early as possible use a sponge and mild detergent to wipe away these contaminants. Do not use a stiff brush or harsh chemicals (including some commercial wheel cleaners). These can damage the protective finish on aluminium alloy wheels, resulting in corrosion. Depending on the type of finish, the wheels also may lose their lustre or appear burnished. To avoid water stains, wipe the wheels dry with a cloth while they are still wet.

» Applying Wax

NOTICE

Chemical solvents and strong cleaners can damage the paint, metal, and plastic on your vehicle. Wipe away spills immediately.

» Maintaining the Bumpers and Other Resin-Coated Parts

Ask a dealer about the correct coating material when you want to repair the painted surface of the parts made of resin.

* Not available on all models

■ Fogged Exterior Light Lenses

The inside lenses of exterior lights (headlights, brake lights, etc.) may fog temporarily if you have driven in the rain, or after the vehicle has been run through a car wash. Dew condensation also may build up inside the lenses when there is a significant enough difference between the ambient and inside lens temperatures (similar to vehicle windows fogging up in rainy conditions). These conditions are natural processes, not structural design problems in the exterior lights.

Lens design characteristics may result in moisture developing on the light lens frame surfaces. This also is not a malfunction.

However, if you see large amounts of water accumulation, or large water drops building up inside the lenses, have your vehicle inspected by a dealer.

Accessories

When installing accessories, check the following:

- Do not install accessories on the windscreen. They can obstruct your view and delay your reaction to driving conditions.
- Do not install any items other than Honda Genuine Accessories designated for your vehicle over areas marked **SRS AIRBAG**, on the sides or backs of the front seats*, on front or side pillars*, or near the side windows.
Items other than Honda Genuine Accessories designated for your vehicle installed in these areas may interfere with proper operation of the vehicle's airbags or may be propelled into you or another occupant if the airbags deploy.
- Be sure electronic accessories do not overload electrical circuits or interfere with proper operation of your vehicle.
 **Fuses** P. 503
- Before installing any electronic accessory, have the installer contact a dealer for assistance. If possible, have a dealer inspect the final installation.

Accessories and Modifications

WARNING

Improper accessories or modifications can affect your vehicle's handling, stability, and performance, and cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding accessories and modifications.

When properly installed, mobile phones, alarms, two-way radios, radio antennas, and low-powered audio systems should not interfere with your vehicle's computer controlled systems, such as your airbags and anti-lock brakes.

Honda Genuine Accessories are recommended to ensure proper operation on your vehicle.

Some Honda Genuine Accessories are supplied with an exclusive owner's manual for the operation and care detail of the product. If an accessory owner's manual is provided to you, please refer to it for full detail.

* Not available on all models

Modifications

Do not modify your vehicle in a manner that may affect its handling, stability, or reliability, or install non-genuine Honda parts or accessories that may have a similar effect.

Even minor modifications to vehicle systems can affect overall vehicle performance. Always make sure all equipment is properly installed and maintained, and do not make any modification to your vehicle or its systems that might cause your vehicle to no longer meet your country's and local regulations.

The on-board diagnostic port (OBD-II/SAE J1962 connector) installed on this vehicle is intended to be used with automobile system diagnostic devices or with other devices that Honda has approved. Use of any other type of device may adversely affect the vehicle's electronic systems or allow them to be compromised, possibly resulting in a system malfunction, drained battery, or other unexpected problems.

Do not modify or attempt to repair any of the electrical components.

►► Accessories and Modifications

If any Honda Genuine Accessories become inoperable, refer to the separate accessory owner's manual (if applicable) or consult a dealer for assistance to troubleshoot the potential faulty condition.

Handling the Unexpected

This chapter explains how to handle unexpected troubles.

Tools

Types of Tools 462

If a Tyre Goes Flat

Models with tyre repair kit

Temporarily Repairing a Flat Tyre 463

Models with spare tyre

Changing a Flat Tyre 473

Models with tyre repair kit

Handling of the Jack 482

Engine Does Not Start

Checking the Engine 483

If the Keyless Remote Battery is Weak .. 485

Emergency Engine Stop 487

If the Battery Is Dead 488

Shift Lever Does Not Move 492

Overheating

How to Handle Overheating 493

Indicator Coming On/Blinking

Models with information display

If the Low Oil Pressure Indicator Comes On .. 497

Models with driver information interface

If the Engine oil pressure low Warning

Appears 498

If the Charging System Indicator Comes On.. 499

If the Malfunction Indicator Lamp Comes

On or Blinks 500

If the Brake System Indicator (Red) Comes

On 500

If the Electric Power Steering (EPS) System

Indicator Comes On 501

Models with Deflation Warning System

If the Low Tyre Pressure/Deflation

Warning System Indicator Comes On

or Blinks 502

Fuses

Fuse Locations 503

Inspecting and Changing Fuses 516

Emergency Towing 517

Emergency Call (eCall)* 518


* Not available on all models

Types of Tools


Types of Tools

The tools are stored in the boot.

Models with spare tyre



Models with tyre repair kit



Models with tyre repair kit

Temporarily Repairing a Flat Tyre

If the tyre has a large cut or is otherwise severely damaged, you will need to have the vehicle towed. If the tyre only has a small puncture, from a nail for instance, you can use the temporary tyre repair kit so that you can drive to the nearest service station for a more permanent repair.


If a tyre goes flat while driving, grasp the steering wheel firmly, and brake gradually to reduce speed. Then, stop in a safe place.

1. Park the vehicle on a firm, level, non-slippery surface and apply the parking brake.
2. Put the transmission into **P**.
3. Turn on the hazard warning lights and set the power mode to VEHICLE OFF.

Temporarily Repairing a Flat Tyre

The kit should not be used in the following situations. Instead, contact a dealer or a roadside assistant to have the vehicle towed.

- The tyre sealant has expired.
- More than one tyre is punctured.
- The puncture or cut is larger than 4 mm.
- The tyre side wall is damaged or the puncture is outside the contact area.





When the puncture is:	Kit Use
Smaller than 4 mm	Yes
Larger than 4 mm	No

- Damage has been caused by driving with the tyres extremely under inflated.
- The tyre bead is no longer seated.
- The rim is damaged.

Do not remove a nail or screw that punctured the tyre. If you remove it from the tyre, you may not be able to repair the puncture using the kit.

■ Getting Ready to Temporarily Repair the Flat Tyre




1. Open the boot floor lid.
2. Take the kit and sealant bottle out of the case.
3. Place the kit, face up, on flat ground near the flat tyre, away from traffic. Do not place the kit on its side.

►► Getting Ready to Temporarily Repair the Flat Tyre


Speed restriction labels are applied to the side of the temporary tyre repair kit.

When making a temporary repair, carefully read the instruction label provided on the kit.

■ Injecting the Sealant and Air



1. Take the air compressor hose and plug cord out of the back of the air compressor.



2. Remove the cap from the air compressor.

► Injecting the Sealant and Air

⚠ WARNING

Tyre sealant contains substances that are harmful and can be fatal if swallowed.

If accidentally swallowed, do not induce vomiting. Drink plenty of water and get medical attention immediately.

For skin or eye contact, flush with cool water and get medical attention if necessary.


Keep the sealant bottle out of the reach of children.

In cold temperatures, the sealant may not flow easily. In this situation, warm it by keeping the bottle in the passenger compartment before using.


The sealant is latex based and can permanently stain clothing and other materials. Be careful during handling and wipe up any spills immediately.

Do not remove the empty bottle after injecting the sealant.

See a Honda dealer for a replacement of sealant bottle and proper disposal of the empty bottle.




3. Shake the bottle well.






4. Remove the bottle cap.

► Do not remove the sealed cover.



5. Screw the sealed bottle onto the air compressor.

► Screw the bottle tightly so that it does not become loose.



6. Remove the valve cap from the tyre valve stem.

7. Screw the air compressor hose onto the tyre valve.

- Make sure the air valve is closed and the air compressor is turned off.

8. Plug in the compressor to the accessory power socket.

- Be careful not to pinch the cord in a door or window.
- Do not plug any other electric devices into other accessory power sockets*.

► **Accessory Power Sockets** P. 250

9. Start the engine.

► **Carbon Monoxide Gas** P. 99

►► Injecting the Sealant and Air

⚠ WARNING

Running the engine with the vehicle in an enclosed or even partly enclosed area can cause a rapid buildup of toxic carbon monoxide.

Breathing this colourless, odourless gas can cause unconsciousness and even death. Only run the engine to power the air compressor with the vehicle outdoors.


Turn the air compressor off when connecting the air compressor hose.

You hear a motor sound coming from the activated air compressor. This is normal.

If the required air pressure is not reached within 10 minutes, the tyre may be too severely damaged for the kit to provide the necessary seal and your vehicle will need to be towed.

If you want to measure the air pressure using a gauge, turn the air compressor off first.

* Not available on all models



- 10.** Turn the air compressor switch on to inflate the tyre.
 - The compressor starts injecting sealant and air into the tyre.
 - Refer to the driver's doorjamb label for the specified pressure.
- 11.** After the air pressure reaches to specified pressure, turn off the compressor.
 - Check the air pressure gauge on the air compressor.
 - If overinflated, release the air by turning the air valve. Be careful not to spill any sealant.
- 12.** Unplug the kit from the accessory power socket.
- 13.** Unscrew the air compressor hose from the tyre valve. Install the valve cap.
 - Be careful not to spill any sealant when the hose is disconnected. Wipe away any spills.
- 14.** Store the tyre repair kit in the boot.
 - Do not remove the sealant bottle from the air compressor.

►► Injecting the Sealant and Air


Inform the use of tyre sealant when you ask a Honda dealer or the road assistant service for replacing or repairing the flat tyre.

This air compressor is designed for the automotive tyre. Check the following:

- The power supply of the air compressor is limited to your vehicle's 12-volt DC accessory power socket.
- Do not operate the temporary tyre repair kit compressor for more than 10 minutes. The compressor can overheat and become permanently damaged.

Make it cool down when using the compressor continuously.

Distributing the Sealant in the Tyre



1. Apply the speed restriction label to the location as shown.
2. Drive the vehicle for about 10 minutes or 3 to 10 kilometres.
► Do not exceed 80 km/h.
3. Stop the vehicle in a safe place.

⌘ Distributing the Sealant in the Tyre


⚠ WARNING

Running the engine with the vehicle in an enclosed or even partly enclosed area can cause a rapid buildup of toxic carbon monoxide.

Breathing this colourless, odourless gas can cause unconsciousness and even death. Only run the engine to power the air compressor with the vehicle outdoors.

Refer to the driver's doorjamb label for the specified pressure.

Continued



4. Recheck the air pressure using the gauge on the compressor.
 - Do not turn the air compressor switch on to check the pressure.
5. If the air pressure is

- Less than 130 kPa (1.3 bar, 19 psi): Do not add air or continue driving. The leak is too severe. Call for help and have your vehicle towed.

✚ **Emergency Towing** P. 517

- Specified air pressure (See the label on driver's doorjamb.) or more: Continue driving until you reach the nearest service station. Do not exceed 80 km/h.
- Greater than 130 kPa (1.3 bar, 19 psi), but less than specified air pressure (See the label on driver's doorjamb.): Inflate the tyre to the specified air pressure.

✚ **Inflating an Under-inflated Tyre**

P. 471

And repeat steps 2 to 4 until you reach the nearest service station. Do not exceed 80 km/h.

- The distance to the nearest service station has to be within about 200 kilometres.



6. Repackage and properly stow the kit.

✚ **Distributing the Sealant in the Tyre**

Make sure to store the air compressor with the empty bottle in the boot.

■ Inflating an Under-inflated Tyre

You can use the kit to inflate a non-punctured under-inflated tyre.



1. Open the boot floor lid.
 ➤ **Getting Ready to Temporarily Repair the Flat Tyre** P. 464
2. Place the kit, face up, on flat ground near the tyre to inflate, away from traffic. Do not place the kit on its side.
3. Remove the valve cap.
4. Attach the hose onto the tyre valve stem. Screw it until it is tight.
 ► Make sure the air valve is closed.
5. Plug in the compressor to the accessory power socket.
 ► Be careful not to pinch the cord in a door or window.
 ► Do not plug any other electric devices into other accessory power sockets*.
 ➤ **Accessory Power Sockets** P. 250
6. Start the engine.
 ➤ **Carbon Monoxide Gas** P. 99


►► Inflating an Under-inflated Tyre

⚠ WARNING

Running the engine with the vehicle in an enclosed or even partly enclosed area can cause a rapid buildup of toxic carbon monoxide.

Breathing this colourless, odourless gas can cause unconsciousness and even death. Only run the engine to power the air compressor with the vehicle outdoors.

* Not available on all models



7. Turn the air compressor switch on to inflate the tyre.
 - The compressor starts to inject air into the tyre.
 - If you have started the engine, leave it running while injecting air.
8. Inflate the tyre to the specified air pressure.
9. Turn off the air compressor.
 - Check the pressure gauge on the air compressor.
 - If overinflated, turn the air valve to deflate.
10. Turn off the engine, then unplug the air compressor from the accessory power socket.
11. Unscrew the air compressor hose from the tyre valve stem. Reinstall the valve cap.
12. Repackage and properly stow the kit.

►► Inflating an Under-inflated Tyre

NOTICE

Do not operate the temporary tyre repair kit compressor for more than 10 minutes. The compressor can overheat and become permanently damaged.

Models with spare tyre

Changing a Flat Tyre

If a tyre goes flat while driving, grasp the steering wheel firmly, and brake gradually to reduce speed. Then, stop in a safe place. Replace the flat tyre with a spare tyre. Go to a dealer as soon as possible to have the regular tyre repaired or replaced.

1. Park the vehicle on a firm, level, non-slippery surface and apply the parking brake.

Continuously variable transmission models

2. Put the transmission into **P**.

Manual transmission models

2. Put the transmission into **R**.

All models

3. Turn on the hazard warning lights and set the power mode to VEHICLE OFF.

Changing a Flat Tyre

Follow compact/temporary spare* precautions:

Compact spare tyre

Periodically check the tyre pressure of the compact spare. It should be set to the specified pressure. Specified Pressure: 420 kPa (4.2 bar, 60 psi)

Temporary spare tyre

Check the air pressure of the 185/60R15 size temporary spare tyre every time you check the other regular tyres. It should be inflated to the recommended air pressure on the label attached to the driver's doorjamb.

Compact spare tyre

When driving with the compact spare tyre, keep the vehicle speed under 80 km/h. Replace with a regular tyre as soon as possible.

Temporary spare tyre




When driving with the temporary spare tyre, keep the vehicle speed under 120 km/h. Replace with a regular tyre as soon as possible.

Compact/Temporary spare tyre

The compact/temporary spare tyre and wheel in your vehicle are specifically for this model. Do not use them with another vehicle. Do not use another type of compact/temporary spare tyre or wheel with your vehicle.

* Not available on all models

■ Getting Ready to Replace the Flat Tyre



1. Open the boot floor lid.
2. Take the tool kit and jack out of the boot.
 - Remove the jack by turning the jack's end bracket to the left to loosen it.
3. Unscrew the wing bolt, and remove the spacer cone. Then, remove the spare tyre.
4. Place a wheel block or rock in front and rear of the wheel diagonal to the flat tyre.

►► Changing a Flat Tyre

Compact/Temporary spare tyre

Do not mount tyre chains on a compact/temporary spare tyre. If a chain-mounted front tyre goes flat, remove one of the regular rear tyres and replace it with the compact/temporary spare tyre. Remove the flat front tyre and replace it with the regular tyre that was removed from the rear. Mount the tyre chains on the front tyre.


Compact spare tyre

A compact spare tyre gives a harsher ride and less traction on some road surfaces. Use greater caution while driving.


Compact/Temporary spare tyre

The compact/temporary spare tyre is smaller than the regular tyre. Your vehicle's ground clearance reduces when the compact/temporary spare tyre is installed. Driving over road debris or bumps could possibly damage the underside of your vehicle.

WARNING: The jack can only be used for helping an emergency vehicle breakdown, not for changing the regular seasonal tyre or any other normal maintenance or repair operation.




5. Place the spare tyre (wheel side up) under the vehicle body, near the tyre that needs to be replaced.



Models with wheel cover

6. Put the flat tip of the jack handle bar into the edge of the wheel cover. Carefully pry the edge and remove the cover.
 - Wrap a cloth around the flat tip of the jack handle bar to prevent scratches on the cover.



All models

7. Loosen each wheel nut about one turn using the wheel nut wrench.

► Changing a Flat Tyre



NOTICE

Do not use the jack if it doesn't work properly. Call your dealer or a professional towing service.

Compact/Temporary spare tyre

Do not use more than one compact/temporary spare tyre at the same time.

■ How to Set Up the Jack



1. Place the jack under the jacking point closest to the tyre to be changed.

2. Turn the end bracket clockwise as shown in the image until the top of the jack contacts the jacking point.
 - Make sure that the jacking point tab is resting in the jack notch.


►► How to Set Up the Jack

⚠ WARNING

The vehicle can easily roll off the jack, seriously injuring anyone underneath.

Follow the directions for changing a tyre exactly, and no person should place any portion of their body under a vehicle that is supported by a jack.

WARNING: The jack shall be placed on a flat and stable surface on the same level as the vehicle is parked.



3. Raise the vehicle, using the jack handle bar and the jack handle, until the tyre is off the ground.

How to Set Up the Jack



Do not use the jack with people or luggage in the vehicle.

Use the jack provided in your vehicle. Other jacks may not support the weight ("load") or may not fit the jacking point.

The following instructions must be followed to use the jack safely:

- Do not use while the engine is running.
- Use only where the ground is firm and level.
- Use only at the jacking points.
- Do not get in the vehicle while using the jack.
- Do not put anything on top of or underneath the jack.

■ Replacing the Flat Tyre




1. Remove the wheel nuts and flat tyre.
2. Wipe the mounting surfaces of the wheel with a clean cloth.
3. Mount the spare tyre.
4. Screw the wheel nuts until they touch the lips around the mounting holes, then stop rotating.

►► Replacing the Flat Tyre


Do not over tighten the wheel nuts by applying extra torque using your foot or a pipe.


Models with wheel cover

Make sure the wire support ring is hooked into the clips around the edge of the wheel cover.



Align the valve mark on the wheel cover to the tyre valve on the wheel, then install the wheel cover.





5. Lower the vehicle and remove the jack. Tighten the wheel nuts in the order indicated in the image. Go around, tightening the nuts, two to three times in this order.


Wheel nut torque:

108 N·m (11 kgf·m, 80 lbf·ft)

► Replacing the Flat Tyre



Models with wheel cover

Make sure the wire support ring is on the outer side of the tyre valve as shown.



■ Storing the Flat Tyre

Models with aluminium wheel



Models with aluminium wheel

1. Remove the centre cap.

All models

2. Place the flat tyre face down in the spare tyre well.
3. Remove the spacer cone from the wing bolt, flip it over, and insert it back on the bolt. Secure the flat tyre with the wing bolt.
4. Securely store the wheel nut wrench and jack handle bar back in the tool bag. Store the tool bag and jack in the boot.

►► Storing the Flat Tyre

⚠ WARNING

Loose items can fly around the interior in a crash and can seriously injure the occupants.
Store the wheel, jack, and tools securely before driving.

Models with Deflation Warning System

■ Deflation Warning System and the Spare Tyre

Compact/Temporary spare tyre

If you replace a flat tyre with the spare tyre, the low tyre pressure/deflation warning system indicator comes on while you are driving. After driving for a few kilometres (miles), **Tyre pressure monitor system problem^{*1}/Tyre pressure monitor system problem. Check tire pressure. See your dealer.^{*2}/Tyre Pressure Monitor System Problem^{*3}/Tire Pressure Monitor System Problem. Check Tire Pressure. See Your Dealer.^{*4}** will appear on the driver information interface and the indicator will start blinking for a short time and then stay on; however, this is normal and is no cause for concern.

Calibrate the deflation warning system when you replace the tyre with a specified regular tyre.

🔧 **Deflation Warning System Initialisation/Calibration** P. 303

Regular spare tyre

Calibrate the deflation warning system when you replace the tyre with a regular spare tyre.

🔧 **Deflation Warning System Initialisation/Calibration** P. 303

*1: Except Mexican models with A-type meter

*2: Mexican models with A-type meter


*3: Except Mexican models with B-type meter

*4: Mexican models with B-type meter

Handling of the Jack

Models with tyre repair kit

Your vehicle has jacking points as shown.
When replacing your tyres, consult a dealer.



Checking the Engine

If the engine does not start, check the starter.

Starter condition	Checklist
Starter doesn't turn or turns over slowly. The battery may be dead. Check each of the items on the right and respond accordingly.	Check for a message on the driver information interface*. - If the To start, touch start button with emblem side of remote*¹/To Start, Hold Remote Near Start Button*² message appears ➤ If the Keyless Remote Battery is Weak P. 485 ➤ Make sure the keyless remote is in its operating range ➤ ENGINE START/STOP Button Operating Range P. 209
The starter turns over normally but the engine doesn't start. There may be a problem with a fuse. Check each of the items on the right and respond accordingly.	Review the engine start procedure. Follow its instructions, and try to start the engine again. ➤ Starting the Engine P. 272 Check the immobilizer system indicator. When the immobilizer system indicator is blinking, the engine cannot be started. ➤ Immobilizer System P. 198 ➤ Immobilizer System Indicator P. 114 Check the fuel level. There should be enough fuel in the tank. ➤ Fuel Gauge P. 128 Check the fuses. Check all fuses, or have the vehicle checked by a dealer. ➤ Inspecting and Changing Fuses P. 516 If the problem continues: ➤ Emergency Towing P. 517

If you cannot start the engine after checking all the items in the list above, have your vehicle checked by a dealer.

*1: Models with A-type meter

*2: Models with B-type meter

* Not available on all models

If you must start the vehicle immediately, use an assisting vehicle or booster battery to jump start it.

➤ **If the Battery Is Dead** P. 488

Do not hold the **ENGINE START/STOP** button for more than 15 seconds.

If the Keyless Remote Battery is Weak


If the beeper sounds, the **ENGINE START/STOP** button flashes, and the engine won't start.

Models with driver information interface

To start, touch start button with emblem side of remote^{*1}/To Start, Hold Remote Near Start Button^{*2} message appears on the driver information interface.

All models


Start the engine as follows:



1. Press the **ENGINE START/STOP** button.
 - ▶ The beeper sounds and the **ENGINE START/STOP** button flashes for about 30 seconds.
2. Touch the centre of the **ENGINE START/STOP** button with the **H** logo on the keyless remote while the **ENGINE START/STOP** button is flashing. The buttons on the keyless remote should be facing you.
 - ▶ The beeper sounds, and the **ENGINE START/STOP** button stays on for about 10 seconds.

*1: Models with A-type meter

*2: Models with B-type meter



3. Depress the brake pedal (continuously variable transmission) or clutch pedal (manual transmission) and press the **ENGINE START/STOP** button while the **ENGINE START/STOP** button is on.

- The engine starts.
- If you don't depress the pedal, the mode will change to ACCESSORY.

Emergency Engine Stop

The **ENGINE START/STOP** button may be used to stop the engine due to an emergency situation even while driving. If you must stop the engine, do either of the following operations:

- Press and hold the **ENGINE START/STOP** button for about two seconds.
- Firmly press the **ENGINE START/STOP** button three times.

The steering wheel will not lock. However, because turning off the engine disables the power assist the engine provides to the steering and braking systems, it will require significantly more physical effort and time to steer and slow the vehicle. Use both feet on the brake pedal to slow down the vehicle and stop immediately in a safe place.

Continuously variable transmission models

The power mode is in ACCESSORY when the engine is stopped.

To change the mode to VEHICLE OFF, put the transmission into **[P]** after the vehicle comes to a complete stop.

Then, press the **ENGINE START/STOP** button twice without depressing the brake pedal.

Manual transmission models

The power mode changes to VEHICLE OFF.

Emergency Engine Stop


NOTICE

Do not press the **ENGINE START/STOP** button while driving unless it is absolutely necessary for the engine to be turned off.

If you press the **ENGINE START/STOP** button while driving, the beeper sounds.

Jump Starting Procedure

Turn off the power to electric devices, such as audio and lights. Turn off the engine, then open the bonnet.



1. Open the terminal cover on your vehicle's battery positive ⊕ terminal.

Jump Starting Procedure

⚠ WARNING

A battery can explode if you do not follow the correct procedure, seriously injuring anyone nearby.


Keep all sparks, open flames, and smoking materials away from the battery.

NOTICE


If a battery sits in extreme cold, the electrolyte inside can freeze. Attempting to jump start with a frozen battery can cause it to rupture.

Securely attach the jumper cables clips so that they do not come off when the engine vibrates. Be careful not to tangle the jumper cables or allow the cable ends to touch each other while attaching or detaching the jumper cables.

Battery performance degrades in cold conditions and may prevent the engine from starting.



2. Connect the first jumper cable to your vehicle's battery $\oplus$ terminal.
3. Connect the other end of the first jumper cable to the booster battery $\oplus$ terminal.
 - Use a 12-volt booster battery only.
 - When using an automotive battery charger to boost your 12-volt battery, select a lower charging voltage than 15-volt. Check the charger manual for the proper setting.
4. Connect the second jumper cable to the booster battery $\ominus$ terminal.



5. Connect the other end of the second jumper cable to the stud bolt as shown. Do not connect this jumper cable to any other part.
6. If your vehicle is connected to another vehicle, start the assisting vehicle's engine and increase its RPM slightly.
7. Attempt to start your vehicle's engine. If it turns over slowly, check that the jumper cables have good metal-to-metal contact.

■ What to Do After the Engine Starts

Once your vehicle's engine has started, remove the jumper cables in the following order.

1. Disconnect the jumper cable from your vehicle's ground.
2. Disconnect the other end of the jumper cable from the booster battery $\ominus$ terminal.
3. Disconnect the jumper cable from your vehicle's battery $\oplus$ terminal.
4. Disconnect the other end of the jumper cable from the booster battery $\oplus$ terminal.

Have your vehicle inspected by a nearby service station or a dealer.

⌘ If the Battery Is Dead

The Adaptive Cruise Control (ACC)*, vehicle stability assist (VSA) system, vehicle stability assist (VSA) **OFF**, safety support*, low tyre pressure/deflation warning system*, Collision Mitigation Braking System (CMBS)*, and Road Departure Mitigation* indicator may come on in amber along with a message in the driver information interface when you set the power mode to ON after reconnecting the battery. Drive a short distance at more than 20 km/h (12 mph). Each indicator should go off. If it does not, have your vehicle checked by a dealer.


* Not available on all models

Shift Lever Does Not Move

Continuously variable transmission models

Follow the procedure below if you cannot move the shift lever out of the **P** position.

Releasing the Lock



1. Set the parking brake.
2. Remove the built-in key from the keyless remote.
3. Insert the key into the shift lock release slot.
4. While pushing the key down, press the shift lever release button, and place the shift lever into **N**.
 - The lock is now released. Have the shift lever checked by a dealer as soon as possible.

How to Handle Overheating

Overheating symptoms are as follows:

Models with information display

- The high temperature indicator comes on or the engine suddenly loses power.

Models with driver information interface

- The **Engine temperature too hot. Do not drive. Allow engine to cool.**^{*1/} **Engine Temperature Too Hot. Allow Engine To Cool.**^{*2/} **Engine Temperature Too Hot. Do Not Drive. Allow Engine To Cool.**^{*3} message appears on the driver information interface.

All models

- Steam or spray comes out of the engine compartment.

■ First thing to do

1. Immediately park the vehicle in a safe place.
2. Turn off all accessories and turn on the hazard warning lights.
 - ▶ **No steam or spray present:**
Keep the engine running and open the bonnet.
 - ▶ **Steam or spray is present:**
Turn off the engine and wait until it subsides. Then, open the bonnet.

*1: Models with A-type meter

*2: Except Mexican models with B-type meter

*3: Mexican models with B-type meter

▶▶ How to Handle Overheating

⚠ WARNING

Steam and spray from an overheated engine can seriously scald you.

Do not open the bonnet if steam is coming out.

Models with information display

NOTICE


Continuing to drive with the high temperature indicator on may damage the engine.

Models with driver information interface

NOTICE

Continuing to drive with the **Engine temperature too hot. Do not drive. Allow engine to cool.**^{*1/} **Engine Temperature Too Hot. Allow Engine To Cool.**^{*2/} **Engine Temperature Too Hot. Do Not Drive. Allow Engine To Cool.**^{*3} message on the driver information interface may damage the engine.

■ Next thing to do



Models with information display

1. Check that the cooling fan is operating and stop the engine once the high temperature indicator goes off.
 - If the cooling fan is not operating, immediately stop the engine.

Models with driver information interface

1. Check that the cooling fan is operating and stop the engine once the **Engine temperature too hot. Do not drive. Allow engine to cool.*1/Engine Temperature Too Hot. Allow Engine To Cool.*2/Engine Temperature Too Hot. Do Not Drive. Allow Engine To Cool.*3** message on the driver information interface disappears.
 - If the cooling fan is not operating, immediately stop the engine.

►► How to Handle Overheating

Except Thai models

⚠ WARNING

Removing the radiator cap while the engine is hot can cause the coolant to spray out, seriously scalding you.

Always let the engine and radiator cool down before removing the radiator cap.

Thai models

⚠ WARNING

Removing the reserve tank cap while the engine is hot can cause the coolant to spray out, seriously scalding you.

Always let the engine and radiator cool down before removing the reserve tank cap.

All models

If the coolant is leaking, contact a dealer for repairs.

Use water as an emergency/temporary measure only. Have a dealer flush the system with proper antifreeze as soon as possible.

*1: Models with A-type meter
 *2: Except Mexican models with B-type meter
 *3: Mexican models with B-type meter

All models

2. Once the engine has cooled down, inspect the coolant level and check the cooling system components for leaks.
 - If the coolant level in the reserve tank is low, add coolant until it reaches the **MAX** mark.

Except Thai models

- If there is no coolant in the reserve tank, check that the radiator is cool. Cover the radiator cap with a heavy cloth and open the cap. If necessary, add coolant up to the base of the filler neck, and put the cap back on.

Thai models

- If there is no coolant in the reserve tank, check that the radiator is cool. Cover the reserve tank cap with a heavy cloth and open the cap. If necessary, add coolant up to the base of the filler neck, and put the cap back on.

■ Last thing to do

Models with information display

Once the engine has cooled sufficiently, restart it and check the high temperature indicator.

If the high temperature indicator is off, resume driving. If it stays on, contact a dealer for repairs.

Models with driver information interface

Once the engine has cooled sufficiently, restart it.

If the **Engine temperature too hot. Do not drive. Allow engine to cool.**^{*1/}

Engine Temperature Too Hot. Allow Engine To Cool.^{*2/Engine Temperature}

Too Hot. Do Not Drive. Allow Engine To Cool.^{*3} message does not appear, resume driving. If it appears again, contact a dealer for repairs.

*1: Models with A-type meter

*2: Except Mexican models with B-type meter

*3: Mexican models with B-type meter

Models with information display

If the Low Oil Pressure Indicator Comes On



■ Reasons for the indicator to come on

Comes on when the engine oil pressure is low.

■ What to do as soon as the indicator comes on

1. Immediately park the vehicle on level ground in a safe place.
2. If necessary, turn the hazard warning lights on.

■ What to do after parking the vehicle

1. Stop the engine and let it sit for approximately three minutes.
2. Open the bonnet and check the oil level.

🔧 **Oil Check** P. 417

3. Start the engine and check the low oil pressure indicator.

- ▶ The indicator goes off: Start driving again.
- ▶ The indicator does not go off within 10 seconds: Immediately stop the engine and contact a dealer for repairs.

⌘ If the Low Oil Pressure Indicator Comes On


NOTICE

Running the engine with low oil pressure can cause serious mechanical damage almost immediately.



Models with driver information interface

If the Engine oil pressure low Warning Appears

Models with A-type meter



Models with B-type meter



Reasons for the warning to appear

Appears when the engine oil pressure is low.

What to do as soon as the warning appears

1. Immediately park the vehicle on level ground in a safe place.
2. If necessary, turn the hazard warning lights on.

What to do after parking the vehicle

1. Stop the engine and let it sit for approximately three minutes.
2. Open the bonnet and check the oil level.
 ▣ **Oil Check** P. 417
3. Start the engine and check the **Engine oil pressure low**^{*3}/**Engine Oil Pressure Low**^{*4} warning.
 - The warning disappears: Start driving again.
 - The warning does not disappear: Immediately stop the engine and contact a dealer for repairs.

►► If the Engine oil pressure low Warning Appears

NOTICE

Running the engine with low oil pressure can cause serious mechanical damage almost immediately.

*1 : Mexican models

*2 : Except Mexican models

*3 : Models with A-type meter

*4 : Models with B-type meter

If the Charging System Indicator Comes On



■ Reasons for the indicator to come on

Comes on when there is a problem with the charging system.

■ What to do when the indicator comes on

Models with information display

Turn off the heating* and cooling system*/climate control system*, rear demister, and other electrical systems, and immediately contact a dealer for repairs.

Models with driver information interface

Stop in a safe place and have your vehicle checked by a dealer immediately.

▶▶ If the Charging System Indicator Comes On

If you need to stop temporarily, do not turn off the engine. Restarting the engine may rapidly discharge the battery.

* Not available on all models

If the Malfunction Indicator Lamp Comes On or Blinks



■ Reasons for the indicator lamp to come on or blink

- Comes on when there is a problem with the engine emissions control system.
- Blinks when engine misfiring is detected.

■ What to do when the indicator lamp comes on

Avoid high speeds and immediately get your vehicle inspected at a dealer.

■ What to do when the indicator lamp blinks

Park the vehicle in a safe place with no flammable items and wait at least 10 minutes or more with the engine stopped until it cools.

►► If the Malfunction Indicator Lamp Comes On or Blinks

NOTICE

If you drive with the malfunction indicator lamp on, the emissions control system and the engine could be damaged.

If the malfunction indicator lamp blinks again when restarting the engine, drive to the nearest dealer at 50 km/h (31 mph) or less. Have your vehicle inspected.

If the Brake System Indicator (Red) Comes On



■ Reasons for the indicator to come on

- The brake fluid is low.
- There is a malfunction in the brake system.

■ What to do when the indicator comes on while driving

Depress the brake pedal lightly to check pedal pressure.

- If normal, check the brake fluid level the next time you stop.
- If abnormal, take immediate action. If necessary, downshift the transmission to slow the vehicle using engine braking.

►► If the Brake System Indicator (Red) Comes On

Have your vehicle repaired immediately. It is dangerous to drive with low brake fluid. If there is no resistance from the brake pedal, stop immediately in a safe place. If necessary downshift the gears.

If the brake system indicator (red) and **ABS** indicator come on simultaneously, the electronic brake distribution system is not working. This can result in vehicle instability under sudden braking. Have your vehicle inspected by a dealer immediately.

If both red and amber brake system indicators come on, stop the vehicle in a safe place and have it inspected by a dealer immediately.

If the Electric Power Steering (EPS) System Indicator Comes On



■ Reasons for the indicator to come on

Comes on when there is a problem with the EPS system.

■ What to do when the indicator comes on

- Stop the vehicle in a safe place and restart the engine.
If the indicator comes on and stays on, immediately have your vehicle inspected by a dealer.

Models with driver information interface

- If **Do not drive**^{*1}/**Do Not Drive**^{*2} displays on the driver information interface, immediately stop in a safe place and contact a dealer.

*1: Models with A-type meter

*2: Models with B-type meter

Models with Deflation Warning System

If the Low Tyre Pressure/Deflation Warning System Indicator Comes On or Blinks



■ Reasons for the indicator to come on or blink

A tyre pressure is significantly low, or the deflation warning system has not been calibrated. If there is a problem with the deflation warning system, the indicator blinks for about one minute, and then stays on. If the compact/temporary spare tyre* is installed, the indicator will either come on or it will first blink for about one minute, then stay on.

■ What to do when the indicator comes on

Drive carefully and avoid abrupt cornering and hard braking. Stop your vehicle in a safe place. Check the tyre pressure and adjust the pressure to the specified level. The specified tyre pressure is on a label on the driver side doorjamb.

- Calibrate the deflation warning system after the tyre pressure is adjusted.

🔧 Deflation Warning System Initialisation/Calibration P. 303

If the compact/temporary spare tyre* causes the indicator to come on, change the tyre to a regular tyre. The indicator goes off after calibrating the deflation warning system.

■ What to do when the indicator blinks, then remains on

Have the tyre inspected by a dealer as soon as possible. If the compact/temporary spare tyre* causes the indicator first blink, and then stays on, change the tyre to a regular tyre.

The indicator goes off after calibrating the deflation warning system.

►► If the Low Tyre Pressure/Deflation Warning System Indicator Comes On or Blinks

NOTICE

Driving on an extremely underinflated tyre can cause it to overheat. An overheated tyre can fail. Always inflate your tyres to the prescribed level.



Fuse Locations

If any electrical devices are not working, set the power mode to VEHICLE OFF and check to see if any applicable fuse is blown.

There are two fuse boxes in the engine compartment.



Engine Compartment Fuse Box (Type A)

Located near the ⊕ terminal on the battery.





1. Open the ⊕ terminal cover.
 2. Remove the cover by pulling the tab as shown.
- Replacement of engine compartment fuses should be done by a dealer.

Except Thai models



Thai models



All models

■ Circuit protected and fuse rating

	Circuit Protected	Amps
a	 MAIN	100 A* ¹ 150 A* ²
b	 MAIN (FAN)	70 A
c	 MAIN (ENG)	80 A
d	 EPS	70 A


*1:Except Thai models

*2:Thai models


Engine Compartment Fuse Box (Type B)

Except Thai models

Located in the back side of the engine compartment on the left side.
Push the tabs to open the box.



Fuse locations are shown on the image below.
Locate the fuse in question by the fuse number in the image and chart.




■ Circuit protected and fuse rating

	Circuit Protected	Amps
1	Wiper	30 A
2	–	–
3	Hazard	10 A
4	Stop	10 A
5	–	–
6	–	–
7	–	–
8	IGP	15 A
9	IG Coil	15 A
10	DBW	15 A
11	ABS/VSA MTR	40 A
12	MAIN FAN	30 A
13	ST Magnetic SW	30 A
14	MG Clutch	7.5 A
15	Battery Sensor	7.5 A
16	Transmission Control Unit*	(10 A)
17	Back Up FI-ECU	10 A
18	Horn	10 A
19	–	–
20	–	–


	Circuit Protected	Amps
21	Back Up Main*	(15 A)
22	Back Up	10 A
23	Sub Fan*	(15 A)
24	ABS/VSA FSR	30 A
25	IGP2 Sub	7.5 A
26	IGPS (LAF)	10 A
27	–	–
28	–	–
29	–	–
30	–	–
31	Starter DIAG	7.5 A
32	–	–
33	–	–

Thai models

Located in the back of the engine compartment on the left side. Push the tabs to open the box.



Locate the fuse in question by the fuse number in the image and chart.




■ Circuit protected and fuse rating

	Circuit Protected	Amps
1	–	–
2	EOP	20 A
3	Hazard	10 A
4	–	–
5	Wiper	30 A
6	Stop	10 A
7	IGP	20 A
8	IG Coil	15 A
9	–	–
10	–	–
11	ABS/VSA MTR	40 A
12	Main Fan	30 A
13	ST Magnetic SW	30 A
14	MG Clutch	7.5 A
15	Back Up FI-ECU	10 A
16	TCU	10 A
17	Engine Water Pump	10 A
18	Horn	10 A
19	–	–
20	IGP2	15 A

	Circuit Protected	Amps
21	Back Up	10 A
22	–	–
23	Sub Fan	30 A
24	ABS/VSA FSR	30 A
25	Starter DIAG	7.5 A
26	–	–
27	–	–
28	–	–
29	Back Up 2	30 A
30	–	–
31	IGP2 Sub	7.5 A
32	–	–
33	–	–


Driver's Side Interior Fuse Box A

Located under the dashboard.



Fuse locations are shown on the image below.

Locate the fuse in question by the fuse number in the image and chart.



■ Circuit protected and fuse rating

	Circuit Protected	Amps
1	Accessory	7.5 A
2	Accessory Key Lock	7.5 A
3	–	–
4	–	–
5	Option	10 A
6	Option2	10 A
7	Meter	10 A
8	Fuel Pump	15 A
9	A/C	10 A
10	Rear Accessory Socket*	(20 A)
11	Mon	5 A
12	Right Side Door Lock	10 A
13	Left Side Door Unlock	10 A
14	Rear Left Power Window	20 A
15	Front Passenger's Power Window	20 A
16	Door Lock	20 A
17	Transmission Control Unit	10 A
18	–	–
19	Sunroof*	(20 A)
20	Starter Cut	7.5 A

	Circuit Protected	Amps
21	ACG	(10 A)* ¹ (15 A)* ²
22	Daytime Running Lights	7.5 A
23	Rear Fog Light*	(10 A)
24	Option	7.5 A
25	Driver's Door Lock*	(10 A)
26	Right Side Door Unlock	10 A
27	Rear Right Power Window	20 A
28	Driver's Power Window	20 A
29	Front Accessory Socket	20 A
30	Smart*	(10 A)
31	USB*	(10 A)
32	Seat Ventilators*	(20 A)
33	–	–
34	ABS/VSA	10 A
35	SRS	10 A
36	–	–
37	IMG*	(10 A)
38	Left Side Door Lock	10 A
39	Driver's Door Unlock*	(10 A)


*1:Except Thai models

*2:Thai models


Left-hand Drive Type

■ **Driver's Side Interior Fuse Box B**

Located under the dashboard.



Locate the fuse in question by the fuse number in the image and chart.



■ Circuit protected and fuse rating

	Circuit Protected	Amps
1	Fuse Box Main1* ¹	60 A
2	IG Main	30 A
3	IG Main 2	30 A
4	Relay Module1	30 A
5	Relay Module2	30 A
6	Fuse Box Main2	40 A
7	Fuse Box Option*	(40 A)
8	–	–
9	–	–
10	–	–
11	–	–
12	Heater Motor	30 A
13	Rear Demister	(30 A)* (40 A)*
14	SRS	10 A
15	–	–


	Circuit Protected	Amps
16	–	–
17	–	–
18	ACC Socket (Console2)*	(20 A)
19	USB Charger*	(10 A)
20	–	–
21	Washer	15 A
22	–	–
23	–	–
24	–	–
25	–	–

*1: Replacement of this fuses should be done by a dealer.

Right-hand Drive Type


Passenger's Side Interior Fuse Box A

Located under the dashboard.



Fuse locations are shown on the image below.

Locate the fuse in question by the fuse number in the image and chart.



■ Circuit protected and fuse rating

	Circuit Protected	Amps
1	Fuse Box Main1*1	60 A
2	IG Main	30 A
3	IG Main 2	30 A
4	Relay Module1	30 A
5	Relay Module2	30 A
6	Fuse Box Main2	40 A
7	Fuse Box Option*	(40 A)
8	–	–
9	Booster Motor*	(40 A)
10	DC/DC1*	(30 A)
11	–	–
12	Heater Motor	30 A
13	Rear Demister*	(30 A)
14	SRS	10 A
15	–	–

	Circuit Protected	Amps
16	–	–
17	–	–
18	ACC Socket (Console2)*	(20 A)
19	USB Charger*	(10 A)
20	Auto Retra*	(7.5 A)
21	Washer	15 A
22	–	–
23	–	–
24	–	–
25	–	–


*1: Replacement of this fuses should be done by a dealer.

Thai models


■ **Passenger's Side Interior Fuse Box B**

Located under the dashboard.


1. Open the glove box.



- 2. Disengage the two tabs by pushing on each side panel.
- 3. Pivot the glove box out of the way.




Locate the fuse in question by the fuse number in the image and chart.



■ **Circuit protected and fuse rating**

	Circuit Protected	Amps
1	ACC Cut VST	7.5 A
2	–	–
3	VST IG1-1	7.5 A
4	Back Up 2 Main	15 A

Inspecting and Changing Fuses



1. Set the power mode to VEHICLE OFF. Turn headlights and all accessories off.
2. Remove the fuse box cover.
3. Check the large fuses in the engine compartment.
 - If the fuse is blown, have it replace by a dealer.

4. Inspect the small fuses in the engine compartment and the vehicle interior.
 - If there is a blown fuse, remove it with a commercially available fuse puller and replace it with a new one.

►► Inspecting and Changing Fuses

NOTICE

Replacing a fuse with one that has a higher rating greatly increases the chances of damaging the electrical system.

Use the charts to locate the fuse in question and confirm the specified amperage.

► **Fuse Locations** P. 503

Replace with a fuse of the same specified amperage.

Call a professional towing service if you need to tow your vehicle.

■ Flatbed equipment

The operator loads your vehicle on the back of a truck.

This is the best way to transport your vehicle.

■ Wheel lift equipment


The tow truck uses two pivoting arms that go under the front tyres and lift them off the ground. The rear tyres remain on the ground. **This is an acceptable way to tow your vehicle.**

» Emergency Towing

NOTICE

Trying to lift or tow your vehicle by the bumpers will cause serious damage. The bumpers are not designed to support the vehicle's weight.

Do not use the hook on the rear of your vehicle for the towing of other vehicles or emergency removal of your vehicle. The hook may break. If your vehicle needs to be towed backward, contact a dealer or a professional towing service.




NOTICE

Improper towing such as towing behind a motorhome or other motor vehicle can damage the transmission.

Never tow your vehicle with just a rope or chain. It is very dangerous since ropes or chains may shift from side to side or break.

Automatic emergency call



If your vehicle is involved in a collision, the vehicle will attempt to connect to a Public Safety Answering Point (PSAP) operator. Once a connection is established, various information about the vehicle will be sent to a PSAP operator with whom you will be able to speak. This information includes:

- Vehicle identification number (VIN)
- Type of vehicle (passenger vehicle or light-weight commercial vehicle)
- Type of energy stored for vehicle propulsion (petrol/diesel/CNG/LPG/electricity/hydrogen)
- Last three locations of the vehicle
- Direction of travel
- Triggering mode (automatic or manual)
- Timestamp

When an emergency call is initiated, the vehicle speakers are disabled so that you can hear the operator.

When the power mode is set to ON, the eCall indicator lights up in green for 1 second, then in red for 1 second.

» Emergency Call (eCall)*

Your vehicle is equipped with the 999-based eCall service system.

The 999-based eCall service is a public service of general interest and is accessible free of charge.

The 999-based eCall in-vehicle system is activated when the power mode is set to ON. In the event of a collision, the system will determine the degree of the impact based on information collected from the on-board sensors and, depending on the severity of the collision, will initiate the emergency call.

The 999-based eCall in-vehicle system can also be triggered manually, if needed.

➤ **Manual emergency call** P. 520

Any processing of personal data through the 999-based eCall in-vehicle system shall comply with the personal data protection rules provided for in Directives 95/46/EC (replaced by 2016/679/EC) and 2002/58/EC, and in particular, shall be based on the necessity to protect the vital interests of the individuals in accordance with Article 7(d) of Directive 95/46/EC (replaced by 2016/679/EC).

Processing of such data is strictly limited to the purpose of for which the single European or other region emergency number 999 is designated.

If the eCall system is working properly, the indicator will light up in green.

- Green: eCall system is ready.
- Blinking in green: eCall system is connected and making an eCall to a PSAP operator.
- Repeating a pattern of short flashes of the red light: The eCall system has failed to connect to an operator. The eCall indicator will continue this pattern for 30 seconds, then it will light up in green.

If the or 999-based eCall system is disabled in the event of a critical system failure, the following warning will be given to the occupants of the vehicle:

- Red or blacked out: A problem with the eCall system has occurred. If the indicator stays red or blacked out even after you have restarted the vehicle, have the system check by a dealer.
- Blinking in red: The level of the backup battery is too low. While the power is in ON, the battery undergoes recharging. Once the battery has been recharged to a certain level, the eCall indicator lights up in green.

►►Emergency Call (eCall)*

Recipients of data processed by the 999-based eCall in-vehicle system are the relevant public safety answering points designated by the respective public authorities of the country in which they are located and are the first to receive and for which the single European or other region emergency 999 is designated.

Your vehicle may NOT be able to connect to a PSAP operator if:

- both the 12V battery and backup battery are too low.
- your vehicle is in an area without adequate cellular coverage.
- There is a problem with the eCall system itself or its peripheral equipment such as the microphone or speakers.


The backup battery is designed to operate for at least 3 years, after which it may need to be replaced.

The backup battery is not available for direct purchase. For replacement, visit a dealer.

This function cannot be used in regions where eCall is not available.

* Not available on all models

Manual emergency call



If you need to make an emergency call, you can establish a connection manually: Press the **SOS** button and hold it for more than 0.5 seconds.

To cancel a call, press the **SOS** cancel button for more than 0.5 seconds, before 5 seconds has elapsed since the **SOS** button was pressed.

The **SOS** button is protected by a cover. Open the cover to gain access.

When an emergency call is initiated, the vehicle speakers are disabled so that you can hear the operator.

Manual emergency call

Do NOT press the button while you are driving. If you need to contact an operator, park the vehicle in a safe place before you make a call.

If the eCall system at first fails to connect to a PSAP operator, it will try again until a connection is established. However, if 2 minutes have elapsed since the first try was attempted, the system will no longer attempt to establish a connection.

The **SOS** cancel button does not cancel a call once the system is connected to an operator.

» Emergency Call (eCall)*

Data privacy

The 999-based eCall in-vehicle system is designed to ensure that:

- Data contained in the system memory is not available outside the system before an eCall is triggered.
- It is not traceable or subject to any constant tracking during its normal operation status.
- Data in the internal memory of the system is automatically and continuously removed.

For the system to function normally, the vehicle location data is constantly overwritten in the internal memory of the system so that the last three locations of the vehicle are kept up-to-date.

The log of activity data in the 999-based eCall in-vehicle system is kept for no longer than necessary for attaining the purpose of handling the emergency eCall and in any case not beyond 13 hours from the moment an emergency eCall was initiated.

* Not available on all models

►► Emergency Call (eCall)*

Owner's rights


The data subject (the vehicle's owner) has a right of access to data and as appropriate to request the rectification, erasure or blocking of data, concerning him or her, the processing of which does not comply with the provisions of Directive 95/46/EC (replaced by 2016/679/EC).

Any third parties to whom the data have been disclosed have to be notified of such rectification, erasure or blocking carried out in compliance with this Directive, unless it proves impossible or involves a disproportionate effort.

The data subject has a right to complain to the competent data protection authority if he or she considers that his or her rights have been infringed as a result of the processing of his or her personal data.

Honda eCall Service Information:

If you have any questions about eCall, contact the office relevant to the country in which you reside. See the service booklet for list of offices.



Information

This chapter includes your vehicle's specifications, locations of identification numbers, and other information required by regulation.

Specifications	524
Identification Numbers	
Vehicle Identification Number (VIN), Engine Number and Transmission Number	529
Devices that Emit Radio Waves*	531
Open Source Licence	537

* Not available on all models

Vehicle Specifications

Model	CITY
	1,099-1,119 kg ^{*1}
	1,111-1,118 kg ^{*2}
	1,113-1,124 kg ^{*3}
	1,123-1,168 kg ^{*4}
	1,126-1,146 kg ^{*5, *6}
Curb Weight	1,117-1,140 kg ^{*7}
	1,117-1,133 kg ^{*8}
	1,088-1,098 kg ^{*9}
	1,138-1,141 kg ^{*10}
	1,144 kg ^{*11}
Maximum Permissible Weight	1,580 kg
Maximum Permissible Axle Weight	Front 850 kg ^{*12} 880 kg ^{*11}
	Rear 715 kg ^{*11} 735 kg ^{*12}

*1: Philippines, Laotian and Cambodian models

*2: Latin American left-hand drive type except Mexican models

*3: Bangladeshi, Bruneian and Singaporean models

*4: Indian, Bhutanese and Nepalese models

*5: Middle Eastern models

*6: African models

*7: Vietnamese models

*8: Malaysian models

*9: Latin American right-hand drive type models

*10: Mexican models

*11: Thai models

*12: Except Thai models

Engine Specifications

Type	Water-cooled in-line 3-cylinder DOHC ^{*1} Water-cooled in-line 4-cylinder DOHC ^{*2}
Bore x Stroke	73.0 x 78.7 mm ^{*1} 73.0 x 89.5 mm ^{*2}
Displacement	988 cm ³ ^{*1} 1,498 cm ³ ^{*2}
Compression Ratio	10.0 : 1 ^{*1} 10.6 : 1 ^{*2}
Spark Plugs	NGK ILZKAR8H8S ^{*1} DILZKAR7C11H ^{*2} DENSO DXE22HCR11H ^{*2}
Max. Power ^{*3}	89 kW (119 HP)/6,600 rpm
Max. Torque ^{*3}	145 N·m (14.8 kgf·m)/4,300 rpm
Max. Speed ^{*3}	190 km/h

*1: Thai models

*2: Except Thai models

*3: Bahraini, Iraqi, Kuwaiti, Omani, Qatari, Saudi Arabian and U.A.E. models

Fuel

Type	Unleaded petrol/gasohol up to E20 (80% petrol and 20% ethanol), research octane number 91 or higher ^{*1} Unleaded petrol, research octane number 91 or higher ^{*2} Unleaded premium petrol/gasohol up to E20 (80% petrol and 20% ethanol), research octane number 95 or higher ^{*3}
Fuel Tank Capacity	40 L

*1: Indian, Bhutanese and Nepalese models

*2: Except Indian, Bhutanese, Nepalese and Thai models

*3: Thai models

Battery

Capacity	27AH(5)30AH(20) ^{*1} 28AH(5)35AH(20) ^{*2} 48AH(5)60AH(20) ^{*3}
----------	---

*1: Except Thai and Mexican models

*2: Mexican models

*3: Thai models

Thai models

Idle Stop:

The battery installed in this vehicle is specifically designed for a model with Auto Idle Stop. If you need to replace the battery, make sure to select the specified type(LN2 EFB). Ask a dealer for more details.

Washer Fluid

Tank Capacity	1.8 L
---------------	-------

■ Light Bulbs

Headlights (High/Low Beams)	LED
Front Turn Signal Lights	LED
Position/Daytime Running Lights	LED
Grille Light*	LED
Side Turn Signal Lights (on Front Fenders)*	5 W Amber (WY5W)
Side Turn Signal Lights (on Door Mirrors)*	LED
Brake Lights	LED
Taillights/Rear Side Marker Lights	LED
Taillights	LED
Rear Turn Signal Lights	21 W Amber (WY21W)
Back-Up Light(s)	16 W (W16W)
Rear Fog Light*	LED
High-Mount Brake Light	LED
Rear Licence Plate Lights	5 W (W5W)
Interior Lights	
Front Map Lights	8W* ¹ LED* ²
Rear Map Lights*	LED
Ambient Light*	LED
Ceiling Light*	8W* ³ LED* ⁴
Centre Pocket Light	LED
Boot Light	5 W
Foot Lights*	LED
Door Pocket Lights*	LED
Door Inner Handle Lights*	LED

*1: Models without LED front map lights

*2: Models with LED front map lights

*3: Models without LED ceiling light

*4: Models with LED ceiling light

■ Air Conditioning

Refrigerant Type	HFC-134a (R-134a)
Charge Quantity	355 - 405 g ^{*1} 395 - 445 g ^{*2}

*1: Thai models

*2: Except Thai models

■ Brake/Clutch * Fluid

Specified	Brake Fluid with DOT 3 or DOT 4
-----------	---------------------------------

■ Manual Transmission Fluid *

Specified	Honda MTF
Capacity	Change 1.4 L

■ Continuously Variable Transmission Fluid *

Specified	Honda HCF-2
Capacity	Change 2.8 L

■ Engine Oil

Recommended	Except Thai models	
	·Honda Engine OIL #1.0 ·Honda Green OIL ·Honda Genuine Motor Oil 0W-16, 0W-20, 5W-30 ·ACEA A5/B5, API service SN or higher grade 0W-16, 0W-20, 5W-30	
	Thai models	
	·Honda Genuine Motor Oil 0W-20, 0W-30, 5W-30 ·ACEA A5/B5, API service SN or higher grade 0W-20, 0W-30, 5W-30	
Capacity	Change	3.1 L ^{*1} 3.5 L ^{*2}
	Change including filter	3.3 L ^{*1} 3.8 L ^{*2}

*1: Except Thai models

*2: Thai models

* Not available on all models

■ Engine Coolant

Specified	Honda All Season Antifreeze/Coolant Type 2
Ratio	50/50 with distilled water

Right-hand drive type models

Capacity	3.53 L ^{*1} (change including the remaining 0.42 L in the reserve tank)
	3.67 L ^{*2} (change including the remaining 0.42 L in the reserve tank)
	5.19 L ^{*3} (change including the remaining 0.6 L in the reserve tank)

Left-hand drive type models

Capacity	3.85 L ^{*4} (change including the remaining 0.42 L in the reserve tank)
	3.86 L ^{*5} (change including the remaining 0.42 L in the reserve tank)
	3.88 L ^{*6} (change including the remaining 0.42 L in the reserve tank)
	3.98 L ^{*7,*8} (change including the remaining 0.42 L in the reserve tank)

*1: Manual Transmission models

*2: Continuously Variable Transmission except Thai models

*3: Thai models

*4: Bahraini, Iraqi, Kuwaiti, Omani, Qatari, Saudi Arabian and U.A.E. models

*5: Mexican models

*6: Ghanaian, Benin, Ivory Coast, Tunisian, Egyptian, Jordanian and Lebanese models

*7: Latin American except Mexican models

*8: Southeast Asian models

■ Tyre

Regular	Size ^{*1}	185/60R15 84H 185/55R16 83H 185/55R16 87H
	Pressure	See the label on driver's doorjamb
Compact Spare [*]	Size ^{*1}	T135/80D15 99M T135/80D15 100M
	Pressure	420 (4.2) 60 kPa (bar) psi
Temporary Spare [*]	Size	185/60R15 84H
	Pressure	See the label on driver's doorjamb
Spare [*] (Full-size tyre)	Size ^{*1}	185/60R15 84H 185/55R16 87H
	Pressure	Same as the regular tyre. See the label on driver's doorjamb.
Wheel Size	Regular	15 x 6J ^{*2} 16 x 6J ^{*3}
	Compact Spare [*]	15 x 4T
	Temporary Spare [*]	15 x 5 1/2J
	Full-size Spare [*]	15 x 6J ^{*2} 16 x 6J ^{*3}

*1: Original tyre size is mentioned on the tyre information label on the driver's doorjamb.

*2: Models with 15 inch wheel

*3: Models with 16 inch wheel

Indian model only

The tyres fitted in the vehicles meet the requirement of the BIS and they comply with the requirements under the central motor vehicles rules (CMVR), 1989.

■ Brake

Type	Power assisted
Front	Ventilated disc
Rear	Solid disc ^{*1,*2} Drum ^{*3}
Parking	Mechanical

*1: Malaysian models with 16 inch wheel

*2: Vietnamese models with keyless access system

*3: Other models

■ Vehicle Dimensions

Malaysian models

Length	4,577 mm ^{*1}
	4,594 mm ^{*2}
Width	1,748 mm
Height	1,467 mm
Wheelbase	2,591 mm
Track	Front 1,496 mm ^{*3}
	1,497 mm ^{*4}
Rear	1,483 mm ^{*3}
	1,485 mm ^{*4}

*1: Models without boot spoiler

*2: Models with boot spoiler

*3: Models with 15 inch wheel

*4: Models with 16 inch wheel

Philippines, Laotian and Cambodian models

Length	4,580 mm ^{*1}
	4,589 mm ^{*2}
Width	1,748 mm
Height	1,457 mm
Wheelbase	2,591 mm
Track	Front 1,496 mm
	Rear 1,483 mm

*1: Models without boot spoiler

*2: Models with boot spoiler

Vietnamese models

Length	4,580 mm ^{*1}
	4,589 mm ^{*2}
Width	1,748 mm
Height	1,467 mm
Wheelbase	2,600 mm
Track	Front 1,495 mm
	Rear 1,483 mm ^{*3}
	1,485 mm ^{*4}

*1: Models without boot spoiler

*2: Models with boot spoiler

*3: Models with 15 inch wheel

*4: Models with 16 inch wheel

Middle Eastern and African models

Length	4,593 mm ^{*1}
	4,603 mm ^{*2}
Width	1,748 mm
Height	1,458 mm ^{*3, *4}
	1,467 mm ^{*5, *6}
Wheelbase	2,590 mm ^{*3, *4}
	2,600 mm ^{*5, *6}
Track	Front 1,495 mm ^{*5, *6}
	Rear 1,496 mm ^{*3, *4}
	1,483 mm

*1: Models without boot spoiler

*2: Models with boot spoiler

*3: Ghanaian, Angolan, Benin, Ethiopian, Gabonese, Ivory Coast, Madagascan, Tunisian and Egyptian models

*4: Jordanian and Lebanese models without continuously variable transmission fluid cooler

*5: Bahraini, Iraqi, Kuwaiti, Omani, Qatari, Saudi Arabian, Nigerian and U.A.E. models

*6: Jordanian and Lebanese models with continuously variable transmission fluid cooler

Indian, Bhutanese and Nepalese models

Length	4,594 mm
Width	1,748 mm
Height	1,489 mm
Wheelbase	2,600 mm
Track	Front 1,496 mm
	Rear 1,484 mm

Latin American right-hand drive type models

Length	4,588 mm
Width	1,748 mm
Height	1,477 mm
Wheelbase	2,600 mm

Latin American left-hand drive type except Mexican models

Length	4,588 mm
Width	1,748 mm
Height	1,477 mm
Wheelbase	2,600 mm
Track	Front 1,494 mm
	Rear 1,483 mm

Bangladeshi, Bruneian and Singaporean models

Length	4,577 mm* ¹	
	4,594 mm* ²	
Width	1,748 mm	
Height	1,467 mm	
Wheelbase	2,600 mm	
Track	Front	1,495 mm
	Rear	1,483 mm

*1: Models without boot spoiler
*2: Models with boot spoiler

Mexican models

Length	4,574 mm* ¹	
	4,583 mm* ²	
Width	1,748 mm	
Height	1,477 mm	
Wheelbase	2,591 mm	
Track	Front	1,497 mm
	Rear	1,483 mm

*1: Models without boot spoiler
*2: Models with boot spoiler

Thai models


Length	4,577 mm	
Width	1,748 mm	
Height	1,467 mm	
Wheelbase	2,589 mm	
Track	Front	1,495 mm
	Rear	1,483 mm

Vehicle Identification Number (VIN), Engine Number and Transmission Number


Your vehicle has a 17-digit vehicle identification number (VIN) used to register your vehicle for warranty purposes, and for licensing and insuring your vehicle. The locations of your vehicle's VIN, engine number and transmission number are shown as follows.

Except Thai models

Continuously Variable Transmission models



Manual Transmission models



* Not available on all models


Vehicle Identification Number (VIN), Engine Number and Transmission Number

The interior vehicle identification number (VIN) is located under the cover.


Southeast Asian and Latin American right-hand drive type models

Bangladeshi models

Left-hand drive type models




Indian, Bhutanese, Nepalese and Thai models



Continued

Thai models



Devices that Emit Radio Waves*

The following products and systems on your vehicle emit radio waves when in operation.

Keyless Access System*	
------------------------	--

Thai models	เครื่อง โทรคนาคนและอุปกรณ์นี้ มีความสอดคล้องตามข้อกำหนดของ กสทช
-------------	---

Keyless Access System	
Singaporean models	FOB: Complies with IMDA Standards DA107248

* Not available on all models

	Keyless Access System*	Emergency Call (eCall)*	Telematics Control Unit*
U.A.E. models	FOB: TRA REGISTERED No: ER54681/17 DEALER No: 0034163/10	BCM: TRA REGISTERED No: ER71902/19 DEALER No: DA39720/15	TRA REGISTERED No: ER73675/19 DEALER No: 0019826/09 —
Vietnamese models	FOB/BCM HONDAVN A00092011 	—	HONDAVN A00092011 

Keyless Access System*		
Egyptian, Laotian, Sint Maarten and Suriname models	FOB: http://www.alps.com/products/common/pdf/HandUnit/TWB1G0090.pdf	BCM: http://www.sws.co.jp/en/product/document/certificate/HAR0004
		
	Hereby, ALPSALPINE CO., LTD. declares that the radio equipment type TWB1G0090 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: http://www.alps.com/products/common/pdf/HandUnit/TWB1G0090.pdf Intended use: Short range device for remote control Postal address: 6-3-36, Nakazato, Furukawa, Osaki-city, Miyagi-pref., JAPAN 989-6181 Frequency band(s) in which the radio equipment operates; 433.92MHz. Maximum radio-frequency power transmitted in the frequency band(s) in which the radio equipment operates; 80.8dBuV/m@3m.	Hereby, Sumitomo Wiring Systems, Ltd. declares that the radio equipment type HAR0004 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: https://www.sws.co.jp/en/product/document/certificate/HAR0004 Intended use: Short range device for remote control Postal address: 1820, Nakanoike, Mikkaichi-cho, Suzuka, Mie 513-8631 JAPAN Frequency band(s) in which the radio equipment operates; 125kHz, 433.92MHz. Maximum radio-frequency power transmitted in the frequency band(s) in which the radio equipment operates; 107.2dBuV/m@10m.

Keyless Access System*	
Egyptian, Laotian, Sint Maarten and Suriname models	FOB/BCM:
	Egyptian models Importer Name: Nile Trading and Engineering Co. S.A.E. Postal address: Cairo Festival City, Fifth Province, Ring Road, Greater Cairo, Nearby Mubarak Academy, Egypt
	Laotian models Importer Name: NCX Co., Ltd. Postal address: Suphanouvong Road, Ban Wattayyaithong Sikhodtabong District, Vientiane Capital Lao P.D.R
	Sint Maarten models Importer Name: Motorworld Postal address: Welfare Road #20 Cole Bay, Sint Maarten Dutch West Indies
	Suriname models Importer Name: Fernandes Automotive (Fernandes Autohandel N.V.) Postal address: Keizerstraat 105-117, Paramaribo, Surinam

Keyless Access System		
Ghanaian models	FOB: Intended use: Short range device for remote control Postal address: 6-3-36, Nakazato, Furukawa, Osaki-city, Miyagi-pref., JAPAN 989-6181 Frequency band(s) in which the radio equipment operates; 433.92MHz. Maximum radio-frequency power transmitted in the frequency band(s) in which the radio equipment operates; 80.8dBuV/m@3m. Importer Name: THP Ghana Ltd. Postal address: P.O. BOX 3464, KANESHIE, ACCRA, GHANA	BCM: Intended use: Short range device for remote control Postal address: 1820, Nakanoike, Mikkaichi-cho, Suzuka, Mie 513-8631 JAPAN Frequency band(s) in which the radio equipment operates; 125kHz, 433.92MHz. Maximum radio-frequency power transmitted in the frequency band(s) in which the radio equipment operates; 107.2dBuV/m@10m. Importer Name: THP Ghana Ltd. Postal address: P.O. BOX 3464, KANESHIE, ACCRA, GHANA

Models under the FCC regulations

Each radio frequency device installed in the vehicle conforms to the requirements and standards of the regulation listed below:

As required by the FCC:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Mexican models

Keyless Access System* (BCM/FOB)

La operación de este equipo está sujeta a las siguientes dos condiciones: (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

Keyless Access System* (FOB)

- Brand: HONDA
- The device is operated with 20 mW or less of transmission output power and is typically used close to the head (especially near the ear) or at a distance of less than 200 mm from the human body.

■ TCU open source licence*

Free/Open Source Software Information

This product contains Free/Open Source Software(FOSS).

The licence information and/or the source code of such FOSS can be found at the following URL.

<https://www.denso.com/global/en/opensource/tcu/honda/>

* Not available on all models

Numbers

7-Speed Manual Shift Mode 284

A

ABS (Anti-lock Brake System)..... 378

ACC (Adaptive Cruise Control)..... 337

Accessories and Modifications 459

Accessory Power Socket 250

Adaptive Cruise Control (ACC)..... 337

Adding

Coolant 420

Engine Oil..... 419

Washer..... 427

Additives, Engine Oil..... 415, 417

Adjusting

Armrest 241

Front Seats 233

Head Restraints..... 239

Headlights 218

Mirrors 230

Rear Seats..... 236

Steering Wheel..... 229

Temperature 129

Agile Handling Assist..... 300

Air Conditioning System (Climate Control System) 259

Changing the Mode 259

Defrosting the Windscreen and

Windows 261

Dust and Pollen Filter 452

Recirculation/Fresh Air Mode 259, 260

Sensors 263

Using Automatic Climate Control 259

Air Conditioning System (Cooling System)

..... 254

Cooling 256

Defrosting the Windscreen and

Windows..... 257

Dust and Pollen Filter..... 452

Air Conditioning System (Heating and Cooling System)

Heating 255

Air Pressure 526

Airbags..... 51

After a Collision 54

Airbag Care..... 61

Event Data Recorder..... 1

Front Airbags (SRS)..... 53

Indicator..... 59, 109

Sensors 51

Side Airbag 56

Side Curtain Airbag 58

Anti-lock Brake System (ABS) 378

Indicator..... 109

Armrest 241

Auto Door Locking/Unlocking 194

Auto High-Beam..... 219

Auto Idle Stop 290

Auto Idle Stop OFF Button 291

Average Fuel Economy 132, 136, 161

Average Speed 138, 163

B

Battery 446

Charging System Indicator 105, 499

If the Battery Is Dead..... 488

Label..... 449

Maintenance (Checking the Battery) 446

Belts (Seat)..... 41

Beverage Holders 246

Booster Seats (For Children) 97

Boot 195

Lid 195

Light Bulb 436

Brake System 376

Anti-lock Brake System (ABS) 378

Brake Assist System..... 379

Fluid 425

Foot Brake 377

Indicator 104, 500

Parking Brake..... 376

Brightness Control (Instrument Panel) ... 226

Bulb Replacement 428

Back-Up Lights..... 431

Boot Light..... 436

Brake Lights 429

Ceiling Light 434

Headlights 428

High-Mount Brake Light..... 433

Interior Lights..... 434

Map Lights..... 434, 435

Position/Daytime Running Lights 428

Rear Fog Light..... 433

Rear Licence Plate Lights	432
Rear Side Marker Lights	429
Rear Turn Signal Lights.....	429
Side Turn Signal Lights	428
Taillights	429, 431
Bulb Specifications	525

C

Carbon Monoxide Gas	99
Carrying Luggage	269, 270
Certification Label	529
Changing Bulbs	428
Charging System Indicator	105, 499
Child Restraint System	62
Booster Seats	97
Child Restraint System for Infants.....	66
Child Restraint System for Small Children..	68
Installing a Child Restraint System with a Lap/Shoulder Seat Belt	93
Installing a Lower Anchorage-Compatible Child Restraint System.....	89
Larger Children	96
Rearward Facing Child Restraint System	66
Selecting a Child Restraint System.....	69
Using Tether	95
Child Safety	62
Childproof Door Locks	193
Cleaning the Exterior	456
Cleaning the Interior	454

Climate Control System	259
Changing the Mode	259
Defrosting the Windscreen and Windows	261
Dust and Pollen Filter	452
Recirculation/Fresh Air Mode	259, 260
Sensors.....	263
Using Automatic Climate Control	259
Clock	180
Clutch Fluid	425
CMBS (Collision Mitigation Braking System)	311
Coat Hook	248
Collision Mitigation Braking System (CMBS)	311
Compact Spare Tyre	526
Console Compartment	245
Continuously Variable Transmission	280
Creeping	280
Fluid	424
Kickdown	280
Operating the Shift Lever.....	281, 282
Shift Lever Does Not Move	492
Shifting	281
Controls	179
Coolant (Engine)	420
Adding the Coolant.....	422, 423
Checking the Coolant.....	420
High Temperature Indicator	110
Low Temperature Indicator.....	110
Overheating	493

Cooling System	254
Cooling	256
Defrosting the Windscreen and Windows.....	257
Dust and Pollen Filter.....	452
Creeping (Continuously Variable Transmission)	280
Cruise Control	294
Indicator.....	116
Cup Holders	246
Customize Display	140, 166
Customized Features	142, 167

D

Daytime Running Lights	222
Dead Battery	488
Deflation Warning System	301
Defrosting the Windscreen and Windows	257, 261
Devices that Emit Radio Waves	531
Diesel	26
Dimming Headlights.....	213
Dipstick (Engine Oil)	417
Directional Signals (Turn Signals)	212
Door Mirrors	231

Doors	183	Emergency Stop Signal	380	Flat Tyre	463
Auto Door Locking	194	Engine		Fluids	
Auto Door Unlocking	194	Coolant	420	Brake	425
Door/Boot Open Indicator	39, 110	If the Battery Is Dead	488	Clutch	425
Keys	183	Number	529	Continuously Variable Transmission	424
Locking/Unlocking the Doors from the Inside	192	Oil	415	Engine Coolant	420
Locking/Unlocking the Doors from the Outside	185	Starting	272	Manual Transmission	424
Lockout Prevention System	191	Switch Buzzer	209	Windscreen Washer	427
Driver Information Interface	133, 157	Engine Coolant	420	Fog Light	217
Switching the Display	133, 157	Adding the Coolant	422, 423	Folding Down the Rear Seats	236
Driver's Side Pocket	248	Checking the Coolant	420	Foot Brake	377
Driving	267	High Temperature Indicator	110	Front Airbags (SRS)	53
Braking	376	Low Temperature Indicator	110	Front Seat Ventilation	253
Continuously Variable Transmission	280	Overheating	493	Front Seats	234
Cruise Control	294	Engine Oil	415	Adjusting	234
Shifting Gear	281, 286	Adding	419	Front Wide View Camera	374
Starting the Engine	272	Checking	417	Fuel	26, 387
Dust and Pollen Filter	452	Engine Oil Pressure Low Warning	498	Average Fuel Economy	136
		Low Oil Pressure Indicator	105, 497	Fuel Economy and CO ₂ Emissions	390
		Recommended Engine Oil	415	Gauge	128
		ENGINE START/STOP Button	209	Instant Fuel Economy	128, 136, 161
		EPS (Electric Power Steering) System	111	Low Fuel Indicator	109
		Exhaust Hazard (Carbon Monoxide)	99	Range	132, 136
		Exterior Care (Cleaning)	456	Recommendation	387
		Exterior Mirrors	231	Refueling	387
				Fuel Economy and CO₂ Emissions	390
				Fuel Fill Cap	26, 389
				Fuel Fill Door	26, 389
				Fuses	503
				Inspecting and Changing	516
				Locations	503, 505, 509, 511, 513, 515
E		F			
eCall (Emergency Call)	518	Features	265		
Eco Assist System	12	Filter			
ECON Mode	289	Dust and Pollen	452		
Elapsed Time	138, 163				
Electric Power Steering (EPS) System Indicator	111, 501				
Emergency	517				
Emergency Call (eCall)	518				

G

Gauges	128
Gear Shift Lever Positions	
Continuously Variable Transmission	281
Manual Transmission	286
Glass (care)	454, 457
Glove Box	245
G-Meter	164

H

Halogen Bulbs	428
Hazard Warning Button	4, 5
Head Restraints	239
Headlights	213
Adjuster	218
Aiming	428
Dimming	213
Operating	213
Heating and Cooling System	
Heating	255
High-Beam Indicator	112
Honda SENSING	27, 308

I

Identification Numbers	529
Engine and Transmission	529
Vehicle Identification	529
Illumination Control	
Knob	226

Immobilizer System	198
Indicator	114
Indicators	102
ABS (Anti-lock Brake System)	109
Adaptive Cruise Control (ACC) (Amber) ...	121
Adaptive Cruise Control (ACC) (White/ Green)	121
Auto High-Beam	112
Auto Idle Stop (Green)	120
Auto Idle Stop System (Amber)	120
Brake System	105
Charging System	105
Collision Mitigation Braking System (CMBS) (Amber)	122
Collision Mitigation Braking System (CMBS) (Grey)	122
CRUISE CONTROL	116, 295
CRUISE MAIN	116, 294, 295
Door and Boot Open	110
ECO	116
ECON Mode	116
Electric Power Steering (EPS) System	111
Emergency Call (eCall)	117
Engine Oil Pressure Low Warning	498
High Temperature	110
High-Beam	112
Immobilizer System	114
KEY BATT	126
Keyless Access System	116
Lane Keeping Assist System (LKAS) (Amber)	122

Lane Keeping Assist System (LKAS) (White/Green)	122
Light Control	113
Lights On	112
Low Fuel	109
Low Oil Pressure	105
Low Temperature	110
Low Tyre Pressure/Deflation Warning System	118
M (7-speed manual shift mode) Indicator/ Shift	106
Malfunction Indicator Lamp	105
NO KEY	126
Parking Brake and Brake System	104
Rear Fog Light	113
Rear Seat Belt Reminder	109
Road Departure Mitigation (Amber)	123
Road Departure Mitigation (Grey)	123
Road Departure Mitigation System Steering Assist Auto OFF	123
Rotate Wheel	117
Safety Support (Amber)	124, 125
Safety Support (Green/Gray)	126
Seat Belt Reminder	108
Security System Alarm	115
Shift Down	107
Shift Position	107
Shift to Park	117
Shift Up	107
Speed Alarm	119
Starter System	117

Supplemental Restraint System	109
System Message	119
Transmission System	106
Turn Signal	112
Vehicle Stability Assist (VSA) System.....	111
VSA OFF	111, 299
Information Display	131
Information Message	127
Instant Fuel Economy	128, 136, 161
Instant Fuel Economy Gauge	128
Instrument Panel	101
Brightness Control	226
Interior Lights	242
Interior Rearview Mirror	230

J

Jack (Wheel Nut Wrench).....	476
Jacking Points	482
Jump Starting.....	488

K

Key Number Tag	184
Keys	183
Lockout Prevention	191
Number Tag	184
Rear Door Won't Open	193
Remote Transmitter	185
Types and Functions	183

Kickdown (Continuously Variable Transmission)	280
--	-----

L

Lane Keeping Assist System (LKAS)	355
Lead Car Departure Notification System	368
Light Switches	213
Lights.....	213, 428
Bulb Replacement	428
Daytime Running Lights.....	222
Fog Lights	217
High-Beam Indicator Light	112
Interior	242
Lights On Indicator	112
Turn Signals	212
LKAS (Lane Keeping Assist System)	355
Load Limits.....	270
Locking/Unlocking.....	183
Auto Door Locking/Unlocking.....	194
Childproof Door Locks.....	193
From Inside	192
From Outside	185
Keys	183
Using a Key	190
Lockout Prevention System	191
Low Battery Charge	499
Low Fuel Indicator.....	109
Low Oil Pressure Indicator.....	105, 497

Low Tyre Pressure/Deflation Warning System Indicator	118, 502
Lower Anchorages	89
Lubricant Specifications Chart	525
Luggage (Load Limit).....	270

M

Maintenance	393
Battery.....	446
Brake Fluid.....	425
Cleaning	454
Climate Control	452
Coolant	420
Cooling System.....	452
Oil	417
Oil Monitor System	397
Precautions	394
Radiator.....	422, 423
Remote Transmitter	450
Replacing Light Bulbs	428
Safety	395
Transmission Fluid.....	424
Tyres.....	439
Under the Bonnet	411
Maintenance Reminder	402
Maintenance Schedule	404
Malfunction Indicator Lamp	105, 500
Manual Transmission	286
Map Lights.....	243
Maximum Permissible Weight	270

Meters, Gauges	128
Mirrors	230
Adjusting	230
Door	231
Exterior	231
Interior Rear View	230
Modifications (and Accessories)	459

N

Numbers (Identification)	529
---------------------------------------	-----

O

Odometer	132
Oil (Engine)	415
Adding	419
Checking	417
Engine Oil Pressure Low Warning	498
Low Oil Pressure Indicator	105, 497
Recommended Engine Oil	415
Viscosity	415
Oil Monitor System	397
Open Source Licence	537
Opening/Closing	
Bonnet	413
Boot	195
Power Windows	202
Sunroof	207
Outside Temperature	129
Adjusting	129

Overheating	493
--------------------------	-----

P

Panic Mode	201
Parking Brake	376
Parking Brake and Brake System	
Indicator	104, 500
Parking Sensor System	383
Passing Indicators	213
Petrol	26, 387
Fuel Economy and CO ₂ Emissions	390
Gauge	128
Information	387
Instant Fuel Economy	128, 136
Low Fuel Indicator	109
Refueling	387
Precautions While Driving	279
Rain	279
Pregnant Women	48
Puncture (Tyre)	463

R

Radiator	422, 423
Range	132, 136, 161
Rear Demister Button	228
Rear Fog Light	217
Rear Seat Reminder	237
Rear Seats (Folding Down)	236
Rear Sunshade	251

Refueling	387
Fuel Gauge	128
Low Fuel Indicator	109
Petrol	387, 524
Remote Engine Start	274
Remote Transmitter	185
Replacement	
Battery	446, 450
Bulbs	428
Fuses	503, 505, 509, 511, 513, 515
Wiper Blade Rubber	437
Resetting a Trip Meter	132, 136, 161
Road Departure Mitigation	325
On and Off	332

S

Safe Driving	35
Safety Check	39
Safety Labels	100
Safety Message	0
Safety Support	139, 165
Seat Belts	41
Checking	49
Fastening	46
Installing a Child Restraint System with a Lap/Shoulder Seat Belt	93
Pregnant Women	48
Reminder	43
Warning Indicator	43, 108
Seat Ventilation	253

Seats	233	If the Battery Is Dead	488	Shift Lever Position Indicator	282
Adjusting	233	Steering Wheel	229	Trip Meter	132, 136, 161
Front Seats	234	Adjusting	229	TRIP/CLOCK Button	131
Rear Seats	236	Stopping	381	TRK (Temporary Repair Kit)	463
Security System	198	Sunroof	207	Troubleshooting	461
Immobilizer System Indicator	114	Supplemental Restraint System (SRS)	53	Blown Fuse	503, 505, 509, 511, 513, 515
Security System Alarm Indicator	115	Switches (Around the Steering		Brake Pedal Vibrates	31
Select Lever	281, 286	Wheel)	4, 6, 209	Buzzer Sounds When Opening Door	33
Selecting a Child Restraint System	69			Emergency Towing	517
Setting the Clock	180			Engine Won't Start	483
Settings	142, 167			Noise When Braking	33
Shift Lever	281, 286			Overheating	493
Operation	281, 286			Puncture/Flat Tyre	463, 473
Releasing	492			Rear Door Won't Open	32
Shift Lever Position Indicator	282			Shift Lever Won't Move	492
Won't Move	492			Warning Indicators	102
Shift Up/Down Indicators	287			Turbo Engine Vehicle	391
Shifting (Transmission)	281, 286			Turn signals	212
Side Airbags	56			Indicators (Instrument Panel)	112
Side Curtain Airbag	58			Tyres	439
Spare Tyre	526			Air Pressure	526
Spark Plugs	524			Checking and Maintaining	439
Specifications	524			Inspection	440
Specified Fuel	387			Puncture (Flat Tyre)	463, 473
Speed/Distance Units	141			Rotation	443
Speedometer	128			Spare Tyre	526
SRS Airbags (Airbags)	53			Tyre Chains	444
Starting Assist Brake Function	293			Wear Indicators	441
Starting the Engine	272			Winter	444
Does Not Start	483				
Engine Switch Buzzer	209				

T	
Tachometer	128
TCU Open Source Licence	537
Temperature	
High Temperature Indicator	110
Low Temperature Indicator	110
Outside Temperature Display	129
Temperature Sensor	129, 263
Temporarily Repairing a Flat Tyre	463
Temporary Repair Kit (TRK)	463
Time (Setting)	180
Tools	462
Towing a Trailer	271
Towing Your Vehicle	
Emergency	517
Transmission	281, 286
CVT	281
Fluid	424
Gear Position Indicator	106
Manual	286
Number	529

U

Under-Floor Storage Area	249
Unlocking the Doors	185
Unlocking the Driver's Doors from the Inside	192
USB Ports	252
Utility Pocket	248

V

Vanity Mirrors	9
Vehicle Identification Numbers	529
Vehicle Stability Assist (VSA)	298
Off Button	299
OFF Indicator	111
System Indicator	111
Ventilation	254, 259
Viscosity (Oil)	415, 525
VSA (Vehicle Stability Assist)	298

W

Warning Indicator On/Blinking	497
Warning Labels	100
Warnings	141
Watts	525
Wear Indicators (Tyre)	441
Wheel Nut Wrench (Jack Handle)	476
Window Washers	
Adding/Refilling Fluid	427
Switch	223

Windows (Opening and Closing)	202
-------------------------------------	-----

Windscreen

Cleaning	454, 457
Defrosting/Defogging	257, 261
Washer Fluid	427
Wiper Blades	437
Wipers and Washers	223

Winter Tyres..... 444

Tyre Chains	444
-------------------	-----

Wipers and Washers..... 223

Checking and Replacing Wiper Blades	437
---	-----

Worn Tyres..... 439

